

# **TWR-LCD**

# User's Manual

Rev. 1.3



# Contents

1 Overview	,
2 Reference Documents4	•
3 Hardware Features4	•
3.1 Power Supply4	:
3.2 LCD Display / Controller	)
3.2.1 Communication Mode	;
3.2.2 MCU Selection	5
3.2.3 Resistive Touch Overlay	)
3.3 MicroSD Card	/
3.4 5-way Navigation Switch	;
3.5 Mini-B USB Connection	;
3.6 Bootloader	ł
3.6.1 Obtaining the S19 file	)
3.6.2 Using the Bootloader	)
3.7 Elevator Connections	)
4 Jumper Table	
4.1 Mechanical Form Factor	į



# **1** Overview

The Tower LCD Module (TWR-LCD) adds a side mounting TFT QVGA Display to the Freescale Tower System. It can be used with a wide variety of Tower Processor Modules through a SPI and/or external bus interface (EBI).

The TWR-LCD features a 3.2" QVGA TFT LCD Display with touch sensitive overlay, 5-way navigation control, MicroSD Card slot, dedicated MCF51JM microcontroller, and a Piezo Buzzer for audible feedback. The LCD Display Controller is accessible to the dedicated MCF51JM microcontroller through the SPI. The LCD Display Controller is also accessible to any capable Tower MCU module utilizing either the SPI or the EBI. A block diagram for the TWR-LCD is shown in the figure below.



#### Figure 1 - TWR-LCD Block Diagram





Figure 2 - Tower System with TWR-LCD

# **2 Reference Documents**

The documents listed below should be referenced for more information on the Freescale Tower system and the TWR-LCD. Refer to <u>http://www.freescale.com/tower</u> for the latest revision of all Tower documentation.

- TWR-LCD Schematics
- TWR-LCD Quick Start Guide
- Truly TFT2N0451-E LCD Module Specification

# **3 Hardware Features**

This section provides more details about the features and functionality of the TWR-LCD.

# **3.1 Power Supply**

The TWR-LCD can be powered as a standalone device from the Mini-B USB connector. The TWR-LCD can also be powered from a source in an assembled Tower System via the 5.0V supply on the TWR-ELEV Side Expansion Port. When attached to a Tower Elevator board, it is required that the board be externally powered from the Elevator board; additionally the USB connector on the TWR-LCD can still be used to communicate over USB to the on-board MCF51JM MCU. On-board power regulation will provide the necessary core voltage (3.3V) and backlight driver voltage (15.5V).



# 3.2 LCD Display / Controller

The TWR-LCD features a Truly Semiconductor 3.2" TFT LCD with an analog resistive touch overlay.

### **3.2.1 Communication Mode**

The LCD utilizes a 240 RGB x 320 QVGA display controller. The display controller is accessible to the on-board MCF51JM MCU through SPI. The controller is also accessible to any compatible Tower MCU module through SPI or the External Bus Interface (EBI) via the primary Tower Side Expansion Ports.

Use SW1-DIP1 and DIP2 to configure the desired interface mode (SPI or EBI). Refer to Section 4 for more configuration details.

<b>SW1-DIP1</b> (PS2)	<b>SW1-DIP 2</b> (PS0)	Description
OFF	ON	Enables SPI communication mode to the LCD Display; can be driven by SPI0 on the Primary Elevator or by the on-board MCF51JM, selectable by JM/ELE (SW1-DIP3)
ON	OFF	Enables EBI (16b mode) communication to the LCD Display This interface is only accessible from the Tower Elevator MCU
ON <	ON	Enables EBI (8b mode) communication to the LCD Display This interface is only accessible from the Tower Elevator MCU

#### Table 1 - LCD Communication Mode Settings

### **3.2.2 MCU Selection**

The LCD can be controlled by either the on-board MCF51JM MCU or a compatible Tower MCU Module.

Use SW1-DIP3 to specify which MCU has access to the display controller. Refer to Section 4 for more configuration details.

JM/ELE	ON	Enables SPI connection from SPI0 of Primary Elevator Connector
(SW1-DIP3)	OFF	Enables SPI connection from on-board MCF51JM MCU

#### Table 2 - Display Driver MCU Selection

Setting the JM/ELE (SW1-DIP3) configuration switch to the "Off" position will isolate the SPI signals from the Tower MCU allowing a direct connection between the on-board MCF51JM MCU and the LCD display controller.

Setting the JM/ELE configuration switch to the "On" position will cause both the on-board MCF51JM MCU and Tower MCU SPI signals to be simultaneously connected to the LCD display controller. It is required that on-board MCF51JM MCU firmware detect the status of the JM/ELE signal and tri-state the on-board MCF51JM MCU SPI signals.



If utilizing a Tower MCU module to drive the SPI to the LCD display controller, use SW1-DIP5 to specify the desired SPI chip select.

Table 3 - Tow	er MCU SPI	<b>CS</b> Selection
---------------	------------	---------------------

SPI CS SEL	ON	Select SPI0 CS1 as the chip-select for LCD SPI interface
(SW1-DIP5)	OFF	Select SPI0 CS0 as the chip-select for LCD SPI interface

### **3.2.3 Resistive Touch Overlay**

The TWR-LCD display features an integrated analog resistive touch panel. The panel can be access by either the on-board MCF51JM MCU or a compatible Tower MCU module. The selection of which MCU interfaces the Touch Panel is independent of which MCU is driving the LCD display controller (designated by JM/ELE).

Use SW1-DIP6 to specify which MCU has access to the resistive touch panel. Refer to Section 4 for more configuration details.

#### Table 4 - Resistive Touch MCU Selection

TP SEL	ON	Disables MCF51JM connection to the LCD Touch Panel Use SW5 to enable ADC connection from Primary Elevator Connector
(SW1-DIP6)	OFF	Enables MCF51JM connection to the LCD Touch Panel Ensure that all switches on SW5 DIP are OFF

Setting the TP SEL (SW1-DIP6) configuration switch to the "Off" position will indicate to the on-board MCF51JM MCU that it is the interfacing MCU to the touch panel's analog signals.

Setting the TP SEL configuration switch to the "On" position will indicate to the on-board MCF51JM MCU that the tower MCU Module is the interfacing MCU to the touch panel's analog signals. It is required that on-board MCF51JM MCU firmware detect the status of the To SEL signal and tri-state the respective on-board MCF51JM MCU ADC signals.

SW5 is used to isolate the touch panel's analog signals from the Tower Elevator Side Expansion Port. This ensures correct isolation of the analog signals when the on-board MCF51JM MCU is used. SW5-DIP[4:1] should all be set to the "Off" position if the on-board MCF51JM MCU is being used to interface the resistive touch panel.



	Touch Panel	ON	Connects AN4 (TWR-ELEV) to XPLS Touch Panel Signal		
3005-DIF 1	Isolation (XPLS)	OFF	Disconnects AN4 from Touch Panel		
	Touch Panel	ON	Connects AN5 (TWR-ELEV) to XMNS Touch Panel Signal		
3005-DIF 2	Isolation (XMNS)	OFF	Disconnects AN5 from Touch Panel		
	Touch Panel	ON	Connects AN6 (TWR-ELEV) to YMNS Touch Panel Signal		
3003-DIP 3	Isolation (YMNS)	OFF	Disconnects AN6 from Touch Panel		
	Touch Panel	ON	Connects AN7 (TWR-ELEV) to YPLS Touch Panel Signal		
5W5-DIP 4	Isolation (YPLS)	OFF	Disconnects AN7 from Touch Panel		

#### **Table 5 - Resistive Touch Analog Isolation Settings**

# 3.3 MicroSD Card

The Tower System defines a Secure Digital interface as shown in 0. The SD Card interface is multiplexed over the SPI1 signals and two GPIOs such that the host can communicate with the SD memory card in the SD Card slot using the SPI mode or the one- or four-bit SD mode.

The MicroSD Card slot is accessible to either the on-board MCF51JM MCU or a compatible Tower MCU Module. Use SW1 –DIP4 to select which MCU has access to the MicroSD Card slot. Refer to Section 4 for more configuration details.

#### Table 6 - MicroSD Card Slot MCU Selection

ELE uSD	ON	MicroSD is connected to the SPI1 of Primary Elevator Connector
(SW1-DIP4)	OFF	MicroSD is connected to the on-board MCF51JM MCU

Setting the EuSD (SW1-DIP4) configuration switch to the "Off" position will isolate the SD signals from the Tower MCU allowing a direct connection between the on-board MCF51JM MCU and the MicroSD Card slot.

Setting the EuSD configuration switch to the "On" position will cause both the on-board MCF51JM MCU and Tower MCU SD signals to be simultaneously connected to the MicroSD Card slot. It is required that on-board MCF51JM MCU firmware detects the status of the EuSD signal and tri-state the on-board MCF51JM MCU SD signals.

Elevator Pin #	Name	Group	Description	I/O
B7	SDHC_CLK / SPI1_CLK	SDHC / SPI 1	SDHC or SPI Clock	0
 B9	SDHC_D3 / SPI1_CS0_b	SDHC / SPI 1	SDHC Chip Select / Data or SPI Chip Select	0
B10	SDHC_CMD / SPI1_MOSI	SDHC / SPI 1	SDHC Command or SPI Master Out / Slave In	0
B11	SDHC_D0 / SPI1_MISO	SDHC / SPI 1	SDHC Data or SPI Master In / Slave Out	I
B22	GPIO2 / SDHC_D1	GPIO / SDHC	General Purpose I/O or SDHC Data	I/O
A10	GPIO8 / SDHC_D2	GPIO / SDHC	General Purpose I/O or SDHC Data	I/O

Table 7 - Tower System SD Card Interface Pinout



The SD Card Detect signal is connected to KBI7 on the on-board MCF51JM MCU and, if configured via EuSD (SW1-DIP4), IRQ\_H on the Primary Tower Elevator. This will allow the host controller to monitor the presence of an SD memory card. To ensure that he SD Card Detect is handled properly, the MCF51JM must configure the SD Card Detect GPIO/KBI (PTG3 / KBIP7) as an internal pull-up. This is done by setting the appropriate register values for PTEPE (PTGPE3=1) for GPIO and additionally KBI1ES (KBEDG7=0) for KBI functionality. Refer to the MCF51JM128 Reference Manual, Section 9, for additional details. The SD Card Detect signal must be configured as an internal pull-up regardless of which host MCU is accessing the MicroSD Card slot.

# 3.4 5-way Navigation Switch

The TWR-LCD features a 5-way Navigation Switch. This switch will allow user interaction with the TWR-LCD providing a method to indicate Up (North), Down (South), Right (East), Left (West), and Select (Center). The corresponding directional signals are connected to the on-board MCF51JM MCU. It is intended that the on-board MCF51JM MCU firmware either respond directly to the Navigation Switch or relay the signal detection to the Tower MCU module through the I2C interface.

It is possible to connect the 5-way Navigation Switch directly to the Tower Elevator by making a hardware modification to the TWR-LCD.

The following resister will should to be populated to create a direct connection to the Tower Elevator: R19, R22, R23, R24, R26, R28, R29, R32, R41, R44

The resisters are intentionally unpopulated in the final design to ensure maximum compatibility with additional Freescale Tower MCU and Peripheral Modules.

Navigation Direction	<b>Tower Elevator Connection</b>		
Up (North)	GPIO7 (Pin A11)		
Down (South)	GPIO8 (Pin A10)		
Right (East)	GPIO5 (Pin B52)		
Left (West)	GPIO1 (Pin B21)		
Select (Center)	GPIO9 (Pin A9)		

Populating these resisters will enable to following connections:

Refer to the "Optional Nav Switch Connections to Elevator" section within the TWR-LCD schematics for additional details.

# **3.5 Mini-B USB Connection**

The TWR-LCD features a Mini-B USB connection on the lower right corner of the module. The USB connector is used to provide power to the TWR-LCD module when operating in stand-alone mode (not



connected to the tower system). The USB data signals are connected to the on-board MCF51JM MCU allow a connection to exist between a host device and the TWR-LCD.

In Boot Loader mode, if the USB cable is connected to a host PC, the TWR-LCD will enumerate as a Mass Storage Device. If an appropriate compiled binary (.s19) file is placed in the root directory of the enumerated storage drive, the TWR-LCD will parse the binary file and reprogram the main application running on the TWR-LCD. Refer to Section 3.6 for more details.

## **3.6 Bootloader**

The TWR-LCD includes a USB bootloader that allows simple "drag and drop" reprogramming. This section will describe how to use the bootloader.

### 3.6.1 Obtaining the S19 file

The bootloader accepts srecord or S19 files that it uses to program the board. In the example projects this file can be found in the <project directory>/bin/ folder and will end in an ".s19" file extension. This file will get overwritten every time the project is compiled.

To create an S19 file, click on the "Standard Settings..." button on your project, and look for the Linker category. Select "ColdFire Linker" and make sure that the "Generate S-Record File" option is checked. Also make sure that the "Max S-Record Length" field is set to 32.

### 3.6.2 Using the Bootloader

Connect the on-board USB connector to a Windows computer using the included mini-B to A USB cable and press reset while holding down the BTLD push button.

The badge board will then enumerate as a Mass Storage Device. Inside the newly added storage device, there will be an empty file named "READY.TXT".

Address 🖙 F:\					
Folders	×	Name 🔺	Size	Туре	Date Modified
🞯 Desktop		E READY.TXT	0 KB	Text Document	4/18/2008 8:20 AM
🗉 븝 My Documents					
🖃 😼 My Computer					
🗄 🧼 SYSTEM (C:)					
🕀 🕯 DATA (D:)					
🗉 🥝 DVD/CD-RW Drive (E:)					
🗄 🥯 Removable Disk (F:)					
🗉 📴 Control Panel					
🗉 😔 My Network Places					

Copy and paste the S19 file into the enumerated drive. Upon successful programming, you will hear two beeps from the board and the S19 file will appear on the removable drive.



Reset or power cycle to TWR-LCD to execute the new application.

For additional information regarding using and creating the TWR-LCD Bootloader refer to the TWR-LCD Lab Guide Document.

### **3.7 Elevator Connections**

The TWR-LCD features two 80-pin connectors that interface to the Side Expansion Ports on the Primary Elevator board in a Tower System. The Primary Elevator Side Expansion Port connectors, comprised of sides A and B, are utilized by the TWR-LCD. The table below provides the pinout for the Primary Elevator Connector. An "X" in the "Used" column indicated that there is a connection from the TWR-LCD to that pin on the Elevator connector. An "X" in the "Jmp" column indicates that a jumper is available that can configure or isolate the connection from the Elevator connector.

	TWR-LCD Primary Connector												
Pin	Name	Usage	Used	Jmp	Pin	Name	Usage	Used	Jmp				
B1	5V	5V Power	X		A1	5V	5V Power	х					
B2	GND	Ground	х		A2	GND	Ground	х					
B3	3.3V				A3	3.3V							
B4	ELE_PS_SENSE				A4	3.3V							
B5	GND	Ground	х		A5	GND	Ground	х					
B6	GND	Ground	X		A6	GND	Ground	х					
B7	SDHC_CLK / SPI1_CLK	uSD Clock	Х	Х	A7	SCLO		х					
B8	SDHC_D3 / SPI1_CS1_b				A8	SDA0		х					
B9	SDHC_D3 / SPI1_CS0_b	uSD Chip Select / Data3	X	Х	A9	GPIO9 / CTS1							
B10	SDHC_CMD / SPI1_MOSI	uSD MOSI / Command	х	X	A10	GPIO8 / SDHC_D2	uSD Data2	х	Х				
B11	SDHC_D0 / SPI1_MISO	uSD MISO / Data0	Х	Х	A11	GPIO7 / SD_WP_DET							
			T	1			Γ		I				
B12	ETH_COL				A12	ETH_CRS							
B13	ETH_RXER				A13	ETH_MDC							
B14	ETH_TXCLK				A14	ETH_MDIO							
B15	ETH_TXEN				A15	ETH_RXCLK							
B16	ETH_TXER				A16	ETH_RXDV							
B17	ETH_TXD3		1		A17	ETH_RXD3							
B18	ETH_TXD2				A18	ETH_RXD2							
B19	ETH_TXD1				A19	ETH_RXD1							
B20	ETH_TXD0				A20	ETH_RXD0							
B21	GPIO1 / RTS1				A21	SSI_MCLK							
B22	GPIO2 / SDHC_D1	SD Data1	Х	Х	A22	SSI_BCLK							
B23	GPIO3				A23	SSI_FS							
B24	CLKINO				A24	SSI_RXD							
B25	CLKOUT1				A25	SSI_TXD							
B26	GND	Ground	X		A26	GND							
B27	AN7	Touch Panel YPLS	Х	Х	A27	AN3							

#### **Table 8 - TWR-LCD Primary Elevator Expansion Pinout**



TWR-LCD Primary Connector									
Pin	Name	Usage	Used	Jmp	Pin	Name	Usage	Used	Jmp
B28	AN6	Touch Panel XMNS	Х	Х	A28	AN2			
B29	AN5	Touch Panel YMNS	Х	Х	A29	AN1			
B30	AN4	Touch Panel XPLS	Х	Х	A30	AN0			
B31	GND	Ground	Х		A31	GND	Ground	Х	
B32	DAC1				A32	DAC0			
B33	TMR3				A33	TMR1			
B34	TMR2				A34	TMR0			
B35	GPIO4				A35	GPIO6			
B36	3.3V				A36	3.3V			
B37	PWM7				A37	PWM3			
B38	PWM6				A38	PWM2			
B39	PWM5				A39	PWM1			
B40	PWM4				A40	PWM0	Piezo Buzzer	х	Х
B41	CANRXO				A41	RXD0			
B42	CANTX0				A42	TXD0			
B43	1WIRE				A43	RXD1			
B44	SPI0_MISO	LCD SPI MISO	X	Х	A44	TXD1			
B45	SPI0_MOSI	LCD SPI MOSI	Х	Х	A45	Analog VDD			
B46	SPI0_CS0_b	LCD SPI Chip Select	Х	X	A46	Analog VSS			
B47	SPI0_CS1_b	LCD SPI Chip Select	X	Х	A47	Analog Vref			
B48	SPI0_CLK	LCD SPI Clock	Х	Х	A48	Analog Vref			
B49	GND	Ground	Х		A49	GND			
B50	SCL1				A50	GPIO14	_		
B51	SDA1				A51	GPIO15			
B52	GPIO5 / SD_CARD_DET				A52	GPIO16			
B53	USB0_DP_PDOWN				A53	GPIO17			
B54	USB0_DM_PDOWN				A54	USB0_DM			
B55	IRQ_H	SD Detect	Х	Х	A55	USB0_DP			
B56	IRQ_G				A56	USB0_ID			
B57	IRQ_F				A57	USB0_VBUS			
B58	IRQ_E				A58	TMR7			
B59	IRQ_D				A59	TMR6			
B60	IRQ_C				A60	TMR5			
B61	IRQ_B			-	A61	TMR4			
B62	IRQ_A				A62	RSTIN_b			
B63	EBI_ALE / EBI_CS1_b				A63	RSTOUT_b	Reset	Х	
B64	EBI_CS0_b	LCD EBI Chip Select	X	X	A64	CLKOUT0			
B65	GND	Ground	X		A65	GND	Ground	X	
B66	EBI_AD15	LCD EBI	Х		A66	EBI_AD14	LCD EBI	Х	
B67	EBI_AD16	LCD EBI	Х		A67	EBI_AD13	LCD EBI	Х	
B68	EBI_AD17				A68	EBI_AD12	LCD EBI	Х	
B69	EBI_AD18				A69	EBI_AD11	LCD EBI	Х	
B70	EBI_AD19				A70	EBI_AD10	LCD EBI	X	
B71	EBI_R/W_b	LCD EBI R/W_b	Х		A71	EBI_AD9	LCD EBI	X	
B72	EBI_OE_b				A72	EBI_AD8	LCD EBI	Х	



	TWR-LCD Primary Connector								
Pin	Name	Usage	Used	Jmp	Pin	Name	Usage	Used	Jmp
B73	EBI_D7				A73	EBI_AD7	LCD EBI	Х	
B74	EBI_D6				A74	EBI_AD6	LCD EBI	Х	
B75	EBI_D5				A75	EBI_AD5	LCD EBI	Х	
B76	EBI_D4				A76	EBI_AD4	LCD EBI	Х	
B77	EBI_D3				A77	EBI_AD3	LCD EBI	Х	
B78	EBI_D2				A78	EBI_AD2	LCD EBI	Х	
B79	EBI_D1				A79	EBI_AD1	LCD EBI	Х	
B80	EBI_D0				A80	EBI_AD0	LCD EBI	Х	

# **4 Jumper Table**

There are several configuration switches provided for isolation, configuration, and feature selection. Refer to the following table for details. The default installed dip switch settings are shown in **\*bold\***.

Configuration Settings		Option	Setting		Description		
	DIP 1 / DIP 2	PS2 / PS0	<b>DIP 1</b> (PS2)	<b>DIP 2</b> (PSO)			
			OFF	OFF	Not a valid setting		
			*OFF*	*ON*	Enables SPI communication mode to the LCD Display; can be driven by SPIO on the Primary Elevator or by the on-board MCF51JM, selectable by JM/ELE (SW1-DIP3)		
			ON	OFF	Enables EBI (16b mode) communication to the LCD Display This interface is only accessible from the Tower Elevator MCU		
			ON ON		Enables EBI (8b mode) communication to the LCD Display This interface is only accessible from the Tower Elevator MCU		
	DIP 3	JM/ELE	ON		Enables SPI connection from SPI0 of Primary Elevator Connector		
			*OFF*		Enables SPI connection from on-board MCF51JM MCU		
W1	DIP 4	ELE uSD	ON		MicroSD is connected to the SPI1 of Primary Elevator Connector		
S			*OFF*		MicroSD is connected to the on-board MCF51JM MCU		
			ON *OFF*		Select SPI0 CS1 as the chip-select for LCD SPI interface		
	DIF 5	SFICS SEE			Select SPI0 CS0 as the chip-select for LCD SPI interface		
	DIP 6	TP SEL	ON		Disables MCF51JM connection to the LCD Touch Panel Use SW5 to enable ADC connection from Primary Elevator Connector		
			*OFF*		Enables MCF51JM connection to the LCD Touch Panel Ensure that SW5 DIP[4:1] are OFF		
		LCD BL	ON		Enables LCD Backlight		
	DIP 7		OFF		Disables LCD Backlight		
	DIP 8	ELE PWM0	ON		Piezo Buzzer is controlled by PWM0 of Primary Elevator Connector and on-board MCF51JM		
			*OFF*		Piezo Buzzer is controlled by on-board MCF51JM only		

#### Table 9 - TWR-LCD Configuration Table



Configuration Settings		Option	Setting	Description		
SW2	5-way Nav	5-way Navigation Switch	North (Up)	Indicates "North" signal to onboard MCU		
			East (Right)	Indicates "East" signal to onboard MCU		
			South (Down)	Indicates "South" signal to onboard MCU		
			West (Left)	Indicates "West" signal to onboard MCU		
			Center (Enter)	Indicates "Center" signal to onboard MCU		
	DIP 1	Touch Panel Isolation (XPLS)	ON	Connects AN4 of Primary Elevator Connector to XPLS Touch Panel Sig		
			*OFF*	Disconnects AN4 from Touch Panel		
	DIP 2	Touch Panel	ON	Connects AN5 of Primary Elevator Connector to XMNS Touch Panel Signal		
/5		Isolation (XMNS)	*OFF*	Disconnects AN5 from Touch Panel		
SV	DIP 3	Touch Panel	ON	Connects AN6 of Primary Elevator Connector to YMNS Touch Panel Signal		
		Isolation (YMNS)	*OFF*	Disconnects AN6 from Touch Panel		
	DIP 4	Touch Panel	ON	Connects AN7 of Primary Elevator Connector to YPLS Touch Panel Signal		
		Isolation (YPLS)	*OFF*	Disconnects AN7 from Touch Panel		

# **4.1 Mechanical Form Factor**

The TWR-LCD is designed for the Freescale Tower System as a side mounting peripheral and complies with the electrical and mechanical specification as described in *Freescale Tower Electromechanical Specification*.



Freescale ™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© Freescale Semiconductor, Inc. 2009. All rights reserved.

TWR-LCD User's Manual



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



#### Как с нами связаться

**Телефон:** 8 (812) 309 58 32 (многоканальный) **Факс:** 8 (812) 320-02-42 **Электронная почта:** <u>org@eplast1.ru</u> **Адрес:** 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.