

# **User Manual**

# **ARK-3400**

**Compact Embedded IPC** 

Trusted ePlatform Services



# Copyright

The documentation and the software included with this product are copyrighted 2009 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

# **Acknowledgements**

Award is a trademark of Award Software International, Inc.

VIA is a trademark of VIA Technologies, Inc.

IBM, PC/AT, PS/2 and VGA are trademarks of International Business Machines Corporation.

Intel® and Pentium® are trademarks of Intel Corporation.

Microsoft Windows® is a registered trademark of Microsoft Corp.

RTL is a trademark of Realtek Semi-Conductor Co., Ltd.

ESS is a trademark of ESS Technology, Inc.

UMC is a trademark of United Microelectronics Corporation.

SMI is a trademark of Silicon Motion, Inc.

Creative is a trademark of Creative Technology LTD.

CHRONTEL is a trademark of Chrontel Inc.

All other product names or trademarks are properties of their respective owners.

For more information about this and other Advantech products, please visit our website at:

http://www.advantech.com/

http://www.advantech.com/ePlatform/

For technical support and service, please visit our support website at: http://support.advantech.com.tw/support/

> Part No. 2006K34001 Printed in China

Edition 2 February 2011

# **Product Warranty (2 years)**

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For outof-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

- 1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
- 2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
- 3. If your product is diagnosed as defective, obtain an RMA (return merchandise authorization) number from your dealer. This allows us to process your return more quickly.
- 4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
- 5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

# **Declaration of Conformity**

### FCC Class A

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

# **Technical Support and Assistance**

- 1. Visit the Advantech web site at www.advantech.com/support where you can find the latest information about the product.
- 2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
  - Product name and serial number
  - Description of your peripheral attachments
  - Description of your software (operating system, version, application software, etc.)
  - A complete description of the problem
  - The exact wording of any error messages

# Warnings, Cautions and Notes

Warning! Warnings indicate conditions, which if not observed, can cause personal injury!



**Caution!** Cautions are included to help you avoid damaging hardware or losing data. e.g.

> There is a danger of a new battery exploding if it is incorrectly installed. Do not attempt to recharge, force open, or heat the battery. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.



Notes provide optional additional information.



# **Safety Instructions**

- 1. Read these safety instructions carefully.
- 2. Keep this User Manual for later reference.
- 3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
- 4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
- 5. Keep this equipment away from humidity.
- 6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
- 7. The openings on the enclosure are for air convection. Protect the equipment from overheating. DO NOT COVER THE OPENINGS.
- 8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
- 9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
- 10. All cautions and warnings on the equipment should be noted.
- 11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
- 12. Never pour any liquid into an opening. This may cause fire or electrical shock.
- 13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
  If one of the following situations arises, get the equipment checked by service personnel:
  The power cord or plug is damaged.
  - Liquid has penetrated into the equipment.
  - The equipment has been exposed to moisture.
  - The equipment does not work well, or you cannot get it to work according to the user's manual.
  - The equipment has been dropped and damaged.
  - The equipment has obvious signs of breakage.
- 14. Do not leave this equipment in an environment where the storage temperature may go below -20° C (-4° F) or above 60° C (140° F). This could damage the equipment. The equipment should be in a controlled environment.
- 15. CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer, discard used batteries according to the manufacturer's instructions.
- 16. The sound pressure level at the operator's position according to IEC 704-1:1982 is no more than 70 dB (A).
- 17. RESTRICTED ACCESS AREA: The equipment should only be installed in a Restricted Access Area.
- 18. DISCLAIMER: This set of instructions is given according to IEC 704-1. Advantech disclaims all responsibility for the accuracy of any statements contained herein.

# Wichtige Sicherheishinweise

- 1. Bitte lesen sie Sich diese Hinweise sorgfältig durch.
- 2. Heben Sie diese Anleitung für den späteren Gebrauch auf.
- 3. Vor jedem Reinigen ist das Gerät vom Stromnetz zu trennen. Verwenden Sie Keine Flüssig-oder Aerosolreiniger. Am besten dient ein angefeuchtetes Tuch zur Reinigung.
- 4. Die NetzanschluBsteckdose soll nahe dem Gerät angebracht und leicht zugänglich sein.
- 5. Das Gerät ist vor Feuchtigkeit zu schützen.
- 6. Bei der Aufstellung des Gerätes ist auf sicheren Stand zu achten. Ein Kippen oder Fallen könnte Verletzungen hervorrufen.
- 7. Die Belüftungsöffnungen dienen zur Luftzirkulation die das Gerät vor überhitzung schützt. Sorgen Sie dafür, daB diese Öffnungen nicht abgedeckt werden.
- 8. Beachten Sie beim. AnschluB an das Stromnetz die AnschluBwerte.
- 9. Verlegen Sie die NetzanschluBleitung so, daB niemand darüber fallen kann. Es sollte auch nichts auf der Leitung abgestellt werden.
- 10. Alle Hinweise und Warnungen die sich am Geräten befinden sind zu beachten.
- 11. Wird das Gerät über einen längeren Zeitraum nicht benutzt, sollten Sie es vom Stromnetz trennen. Somit wird im Falle einer Überspannung eine Beschädigung vermieden.
- 12. Durch die Lüftungsöffnungen dürfen niemals Gegenstände oder Flüssigkeiten in das Gerät gelangen. Dies könnte einen Brand bzw. elektrischen Schlag auslösen.
- Öffnen Sie niemals das Gerät. Das Gerät darf aus Gründen der elektrischen Sicherheit nur von authorisiertem Servicepersonal geöffnet werden.
   Wenn folgende Situationen auftreten ist das Gerät vom Stromnetz zu trennen und von einer qualifizierten Servicestelle zu überprüfen:
  - Netzkabel oder Netzstecker sind beschädigt.
  - Flüssigkeit ist in das Gerät eingedrungen.
  - Das Gerät war Feuchtigkeit ausgesetzt.
  - Wenn das Gerät nicht der Bedienungsanleitung entsprechend funktioniert oder Sie mit Hilfe dieser Anleitung keine Verbesserung erzielen.
  - Das Gerät ist gefallen und/oder das Gehäuse ist beschädigt.
  - Wenn das Gerät deutliche Anzeichen eines Defektes aufweist.
- 14. VOSICHT: Explisionsgefahr bei unsachgemaben Austausch der Batterie.Ersatz nur durch densellben order einem vom Hersteller empfohlene-mahnlichen Typ. Entsorgung gebrauchter Batterien navh Angaben des Herstellers.
- 15. ACHTUNG: Es besteht die Explosionsgefahr, falls die Batterie auf nicht fachmännische Weise gewechselt wird. Verfangen Sie die Batterie nur gleicher oder entsprechender Type, wie vom Hersteller empfohlen. Entsorgen Sie Batterien nach Anweisung des Herstellers.
- 16. Der arbeitsplatzbezogene Schalldruckpegel nach DIN 45 635 Teil 1000 beträgt 70dB(A) oder weiger.
- 17. Montageort: Das Gerät sollte nur in einem Bereich mit eingeschränktem Zugang montiert werden.
- 18. Haftungsausschluss: Die Bedienungsanleitungen wurden entsprechend der IEC-704-1 erstellt. Advantech lehnt jegliche Verantwortung für die Richtigkeit der in diesem Zusammenhang getätigten Aussagen ab.

# **Packing List**

Before installation, please ensure the following items have been shipped:

- 1 x ARK-3400 Unit
- 1 x DVI to CRT adapter connector
- 1 x Rubber foot kit
- 2 x Desk/Wall mount plate
- 1 x 4-pin Phoenix DC power connector
- 1 x Utility CD
- 1 x Registration and 2 years Warranty card

# **Ordering information**

Model Number Description

ARK-3400F-S5A1E	Intel® Celeron® M 370 1.5GHz Box IPC
ARK-3400F-S0A1E	Intel® Celeron® M 373 1.0GHz Box IPC

# **Optional accessories**

Part Number	Description
1757002161	AC-to-DC Adapter, DC19 V/7.89A 150W, with Phoenix Power Plug, $0 \sim 40^{\circ}$ C for Home and Office Use
1702002600	Power cable 3-pin 180 cm, USA type
1702002605	Power Cable 2-pin 180 cm, Europe Type
1702031801	Power Cable 2-pin 180 cm, UK Type
1700004713	Cable DVI-I to DVI and CRT
1700009398	LVDS cable for ARK-3400
1700009396	LVDS power cable for ARK-3400
1700009407	Digital IO cable for ARK-3400 (Internal)
1700009405	LPT cable for ARK-3400

# Contents

Chapter	1	General Introduction1
	1.1	Introduction2
	1.2	Product Feature2
		1.2.1 General
		1.2.2 Display
		1.2.3 Power Consumption
	1.3	Hardware Specification
	1.4	Mechanical Specification4
		1.4.1 Dimensions
		Figure 1.1 ARK-3400 Mechanical Dimension Drawing
		1.4.2 Weight
	1.5	Power requirement4
		1.5.1 System power4
		1.5.2 RTC battery4
	1.6	Environmental Specifications5
		1.6.1 Operation temperature5
		1.6.2 Relative Humidity
		1.6.3 Storage temperature
		1.6.4 Vibration loading during operation
		1.6.5 Shock during operation
		1.6.6 Safety
		1.0.7 EMC
Chapter	2	Hardware installation7
	2.1	ARK-3400 I/O Indication8
		Figure 2.1 ARK-3400 Front View8
		Figure 2.2 ARK-3400 Rear View8
	2.2	ARK-3400 Front Side External I/O Connectors9
		2.2.1 Power ON/OFF Button
		Figure 2.3 Power ON/OFF Button9
		2.2.2 Reset Button
		Figure 2.4 Reset Button9
		2.2.3 LED Indicators
		Figure 2.5 LED Indicators9
		2.2.4 Audio Connector
		Figure 2.6 Audio jack connectors9
		2.2.5 COM Connector
		Figure 2.7 COM port connector 10
		Table 2.1: COM standard serial port pin assignments
		2.2.6 eSATA Connector
		Figure 2.8 eSATA connector
		2.2.7 USB Connector
		Figure 2.9 USB connector
		I able 2.2:     USB Connector
	0.0	2.2.0 Compact Flash Card
	2.3	ARR-3400 real side external I/O connectors
		2.3.1 Fower Input Connector
		Table 2.3: Dower connector nin assignments
		2.3.2 Digital Visual Interface Connector (DVLI)
		2.0.2 Digital visual internate confidence (DVI-I)
		Table 2.4. DVI-I Connector nin assignments 12
		2.3.3 Ethernet Connector (I AN)

			Figure 2.12Ethernet connector	13
			Table 2.5: RJ-45 Connector pin assignments	13
		2.3.4	LVDS Connector	13
			Figure 2.13LVDS Connector	13
			Table 2.6: LVDS Connector Pin Assignment	13
		2.3.5	LCD Backlight On/Off control Connector	14
			Figure 2.14LCD Backlight connector	14
			Table 2.7: LCD Backlight Connector Pin Assignment	14
		2.3.6	LPT Connector	14
			Figure 2.15LPT Connector	14
			Table 2.8:    LPT Connector Pin Assignment	14
		2.3.7	DIO Connector	15
			Figure 2.16DIO Connector	15
	<b>-</b> .		Table 2.9: DIO Connector Pin Assignment	15
	2.4	Memo	ry Installation	16
		•	Figure 2.17 Memory Installation	16
	2.5	Compa	act Flash installation	17
			Figure 2.18CF Card installation	17
	2.6	HDD ir		1/
		DOL	Figure 2.19HDD Installation	17
	2.7	PCI ca		18
			Figure 2.20PCI Card Installation	18
	2.8	Mini P		19
			Figure 2.21 Mini PCI Card Installation	19
	2.9	Antenr	a installation	20
			Figure 2.22 Remove the cover	20
	0.40	Ontion	Figure 2.23 Antenna Installation	20
	2.10	Option		
Chapter	3	BIO	S settings	. 23
Chapter	<b>3</b> 3.1	BIOS I	IS settings	<b>. 23</b>
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S	ntroduction	<b>. 23</b>
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1	ntroduction	<b>. 23</b> 24 24 24 25
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1	ntroduction Setup Main Menu Figure 3.1 Award BIOS CMOS Setup Utility	<b>. 23</b> 24 24 25 25
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2	Installation In	<b>. 23</b> 24 24 25 25 26
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2	Note the settings	<b>. 23</b> 24 24 25 25 26 26
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3	NS settings Note that the set of the	<b>. 23</b> 24 24 25 26 26 26 28
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3	Not an and the second s	<b>. 23</b> 24 24 25 26 26 26 28 28
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4	Advanced BIOS Features Figure 3.3 Award BIOS Advanced CMOS Features Advanced CMOS Features Figure 3.3 Award BIOS Advanced CMOS Features Figure 3.3 Award BIOS Advanced CMOS Features	<b>. 23</b> 24 24 25 25 26 26 26 28 28 30
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4	Instantion         Introduction         Setup         Main Menu         Figure 3.1 Award BIOS CMOS Setup Utility         Standard CMOS Features         Figure 3.2 Award BIOS Standard CMOS Features         Advanced BIOS Features         Figure 3.3 Award BIOS Advanced CMOS Features         Advanced Chipset Features         Figure 3.4 Award BIOS Advanced Chipset Features	<b>. 23</b> 24 24 25 26 26 26 26 28 30 30
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5	Instantion of the production of the product of	<b>. 23</b> 24 25 25 26 26 28 30 30 32
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5	Introduction	<b>. 23</b> 24 25 25 26 26 26 28 28 30 30 32 32
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6	Introduction Setup Main Menu Figure 3.1 Award BIOS CMOS Setup Utility Standard CMOS Features Figure 3.2 Award BIOS Standard CMOS Features Advanced BIOS Features Figure 3.3 Award BIOS Advanced CMOS Features Advanced Chipset Features Figure 3.4 Award BIOS Advanced Chipset Features Integrated Peripherals Figure 3.5 Award BIOS Integrated Peripherals Power Management Setup	<b>. 23</b> 24 24 25 26 26 26 28 28 30 32 32 32 34
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6	Instruction         Introduction         Setup         Main Menu         Figure 3.1 Award BIOS CMOS Setup Utility         Standard CMOS Features         Figure 3.2 Award BIOS Standard CMOS Features         Advanced BIOS Features         Figure 3.3 Award BIOS Advanced CMOS Features         Advanced Chipset Features         Figure 3.4 Award BIOS Advanced CMOS Features         Integrated Peripherals         Figure 3.5 Award BIOS Integrated Peripherals         Power Management Setup         Figure 3.6 Award BIOS Power Management Setup	<b>. 23</b> 24 24 25 25 26 26 26 26 28 30 30 32 32 34 34
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6 3.2.7	Instruction         Introduction         Setup         Main Menu         Figure 3.1 Award BIOS CMOS Setup Utility         Standard CMOS Features         Figure 3.2 Award BIOS Standard CMOS Features         Advanced BIOS Features         Figure 3.3 Award BIOS Advanced CMOS Features         Advanced Chipset Features         Figure 3.4 Award BIOS Advanced CMOS Features         Integrated Peripherals         Figure 3.5 Award BIOS Integrated Peripherals         Power Management Setup         Figure 3.6 Award BIOS Power Management Setup         PnP/PCI Configurations	<b>. 23</b> 24 24 25 25 26 26 26 26 26 26 26 26 26 26 26 26 26 26 30 30 30 32 32 34 34 34
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6 3.2.7	Ngure 2.2 Friendsvalue (NDD installation)         Setup         Main Menu         Figure 3.1 Award BIOS CMOS Setup Utility.         Standard CMOS Features         Figure 3.2 Award BIOS Standard CMOS Features         Advanced BIOS Features         Figure 3.3 Award BIOS Advanced CMOS Features         Advanced Chipset Features         Figure 3.4 Award BIOS Advanced CMOS Features         Integrated Peripherals         Figure 3.5 Award BIOS Integrated Peripherals         Power Management Setup         Figure 3.6 Award BIOS Power Management Setup         PnP/PCI Configurations         Figure 3.7 Award BIOS PnP/PCI Configurations	. 23 24 24 25 25 26 26 28 30 30 30 32 32 34 34 36 36
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6 3.2.7 3.2.8	Image: Settings         Introduction         Setup         Main Menu         Figure 3.1 Award BIOS CMOS Setup Utility         Standard CMOS Features         Figure 3.2 Award BIOS Standard CMOS Features         Advanced BIOS Features         Figure 3.3 Award BIOS Advanced CMOS Features         Advanced Chipset Features         Figure 3.4 Award BIOS Advanced CMOS Features         Integrated Peripherals         Figure 3.5 Award BIOS Integrated Peripherals         Power Management Setup         Figure 3.6 Award BIOS Power Management Setup         PnP/PCI Configurations         Figure 3.7 Award BIOS PnP/PCI Configurations         PC Health Status	<b>. 23</b> 24 24 25 26 26 26 26 26 26 26 26 26 26 26 26 26 26 26 26 30 30 32 32 34 34 34 34 34 32
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6 3.2.7 3.2.8	Image: Settings         Introduction         Setup         Main Menu         Figure 3.1 Award BIOS CMOS Setup Utility         Standard CMOS Features         Figure 3.2 Award BIOS Standard CMOS Features         Advanced BIOS Features         Figure 3.3 Award BIOS Advanced CMOS Features         Advanced Chipset Features         Figure 3.4 Award BIOS Advanced CMOS Features         Integrated Peripherals         Figure 3.5 Award BIOS Integrated Peripherals         Power Management Setup         Figure 3.6 Award BIOS Power Management Setup         PnP/PCI Configurations         Figure 3.7 Award BIOS PnP/PCI Configurations         PC Health Status         Figure 3.8 Award BIOS PC Health Status	<b>. 23</b> 24 24 25 26 26 26 26 28 26 26 26 28 26 26 26 26 26 26 26 26 30 32
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6 3.2.7 3.2.8 3.2.9	Instruction         Instruction         Setup         Main Menu         Figure 3.1 Award BIOS CMOS Setup Utility         Standard CMOS Features         Figure 3.2 Award BIOS Standard CMOS Features         Advanced BIOS Features         Figure 3.3 Award BIOS Advanced CMOS Features         Advanced Chipset Features         Figure 3.4 Award BIOS Advanced CMOS Features         Integrated Peripherals         Figure 3.5 Award BIOS Integrated Peripherals         Power Management Setup         Figure 3.6 Award BIOS Power Management Setup         PnP/PCI Configurations         Figure 3.7 Award BIOS PnP/PCI Configurations         PC Health Status         Figure 3.8 Award BIOS PC Health Status         Frequency/voltage Control	<b>. 23</b> 24 24 25 26 26 26 26 26 26 26 26 26 26 26 26 26 26 26 26 26 26 26 30 30 32 34 34 34 34 32 32 32 32 32 32 34 32 34 34 36 37
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6 3.2.7 3.2.8 3.2.9	Instruction         Setup         Main Menu         Figure 3.1 Award BIOS CMOS Setup Utility.         Standard CMOS Features         Figure 3.2 Award BIOS Standard CMOS Features         Advanced BIOS Features         Figure 3.3 Award BIOS Advanced CMOS Features         Advanced Chipset Features         Figure 3.4 Award BIOS Advanced CMOS Features         Advanced Chipset Features         Figure 3.5 Award BIOS Integrated Peripherals         Power Management Setup         Figure 3.6 Award BIOS Power Management Setup         PnP/PCI Configurations         Figure 3.7 Award BIOS PnP/PCI Configurations         PC Health Status         Figure 3.8 Award BIOS PC Health Status         Frequency/voltage Control         Figure 3.9 Award BIOS Frequency/Voltage Control	. 23 24 24 25 26 26 26 26 26 26 26 26 26 26 26 26 26 26 26 26 26 26 30 30 32 32 34 34 34 34 34 34 34 34 34 34 32 34 34 34 34 34 34 37 37 37 37 37 38 37
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6 3.2.7 3.2.8 3.2.9 3.2.10	Instantiation         Instensisting <td< td=""><td><b>. 23</b> 24 24 25 25 26 26 26 28 30 30 30 30 32 32 34 34 36 37 38 38 38 38 39</td></td<>	<b>. 23</b> 24 24 25 25 26 26 26 28 30 30 30 30 32 32 34 34 36 37 38 38 38 38 39
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6 3.2.7 3.2.8 3.2.9 3.2.10 2.2.10	Instantion of the production         Instantiation         Instantis <tr< td=""><td><b>. 23</b> 24 24 25 26 26 26 26 26 26 28 26 30 30 32 33 32 32 33 32 33</td></tr<>	<b>. 23</b> 24 24 25 26 26 26 26 26 26 28 26 30 30 32 33 32 32 33 32 33
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6 3.2.7 3.2.8 3.2.9 3.2.10 3.2.10	Introduction         Setup         Main Menu         Figure 3.1 Award BIOS CMOS Setup Utility         Standard CMOS Features         Figure 3.2 Award BIOS Standard CMOS Features         Advanced BIOS Features         Figure 3.3 Award BIOS Advanced CMOS Features         Advanced Chipset Features         Figure 3.4 Award BIOS Advanced CMOS Features         Integrated Peripherals         Figure 3.5 Award BIOS Integrated Peripherals         Power Management Setup         Figure 3.6 Award BIOS Power Management Setup         PnP/PCI Configurations         Figure 3.7 Award BIOS PC Health Status         Figure 3.8 Award BIOS PC Health Status         Figure 3.9 Award BIOS Frequency/Voltage Control         Load Optimized Defaults         Figure 3.10Award BIOS Load Setup Defaults         Set Password	<b>. 23</b> 24 24 25 26 26 26 26 28 26 26 26 28 26 26 26 26 28 30 30 32 32 34 34 34 36 37 37 37 38 39 39 39 39
Chapter	<b>3</b> 3.1 3.2	BIOS I BIOS I BIOS S 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.6 3.2.7 3.2.8 3.2.9 3.2.10 3.2.10 3.2.11	<b>Settings</b> Main Menu         Figure 3.1 Award BIOS CMOS Setup Utility.         Standard CMOS Features         Figure 3.2 Award BIOS Standard CMOS Features.         Advanced BIOS Features         Figure 3.3 Award BIOS Advanced CMOS Features.         Advanced Chipset Features         Figure 3.4 Award BIOS Advanced CMOS Features         Integrated Peripherals         Figure 3.5 Award BIOS Integrated Peripherals         Power Management Setup         Figure 3.6 Award BIOS Power Management Setup         PnP/PCI Configurations         Figure 3.7 Award BIOS PC Health Status         Frequency/voltage Control         Load Optimized Defaults         Figure 3.9 Award BIOS Frequency/Voltage Control         Load Optimized Defaults         Figure 3.11Award BIOS Load Setup Defaults         Set Password         Figure 3.11Award BIOS Set Password	<b>. 23</b> 24 24 25 26 26 26 26 26 28 26 26 28 26 26 26 28 26 26 26 26 26 26 26 26 26 26 28 30 32 33 32 33 

	Figure 3.13Award BIOS Quit without Saving	41
Chapter 4	Software Installation	43
4.1	<ul> <li>Driver Installation</li></ul>	
Appendix A	Function Settings	55
A.1	Function Setting Figure A.1 Internal board top view Figure A.2 Internal board bottom view Table A.1: Setting Table	56 56 56 57
Appendix B	Display Application	59
B.1 B.2 B.3 B.4	Introduction Figure B.1 BIOS VGA setting LVDS Dual Display B.3.1 Display modes Display Resolution Setting	60 60 60 60 60 60 61
Appendix C	Application Notes	63
C.1 C.2	RS-485 Auto Flow Control Figure C.1 BIOS COM port setting C.1.1 Flow control, introduction C.1.2 Software flow control C.1.3 Hardware flow control C.1.4 How to implement WOL Setting C.2.1 Introduction C.2.2 System requirements - PC Compatible C.2.3 How it works C.2.4 Magic Packet	64 64 64 65 66 66 66 66 67 67
Appendix D	Watchdog Timer	69
D.1	Watchdog Timer	70
Appendix E	Programming GPIO	71
E.1 E.2	Programming GPIO GPIO Programming	72 72

ARK-3400 User Manual



# **General Introduction**

This chapter gives background information on ARK-3400 series.

# 1.1 Introduction

ARK-3400 Box IPC is an ideal application ready system platform solution. All electronics are protected in a compact sealed aluminum case for easy embedding in customers own housing, or as a stand-alone application, where space is limited and the environment harsh.

A solid sealed aluminum case provides vibration and dust resistance while also providing a passive cooling solution. The ARK-3400 provides system integrators with a turn-key solution and versatile application development path without breaking the bank or missing time to market deadlines.

The ARK-3400 can be used as a standalone system, wall-mounted and desktop mounted. The system accepts a wide range of power supplies (DC power in) and comes in a footprint of only 220 mm x 102.5 mm x 200 mm (8.66" x 4.04" x 7.87"). The rugged cast aluminum case not only provides great protection from EMI, shock/ vibration, cold and heat, but also passive cooling for quiet fanless operation.

The ARK-3400 answers this demand by offering 1 x DVI-I interface for dual display, 6 x USB 2.0 ports, 2 x Giga LAN port, audio function, 4 x COM ports, 1 x Mini PCI socket and 2 PCI expansion slots; packed into a small rugged unit and powered by an Celeron M processor. It also supports a wide range of input voltages from 12 VDC to 24 VDC. The ARK-3400 IPC supports 1 x 2.5" SATA HDD and 1 x Compact Flash card for storage options and it can provide the diversified application field.

# **1.2 Product Feature**

### 1.2.1 General

- Intel® Mobile Celeron® at 1.5 GHz/1.0 GHz
- Dual display and support for wide screen with high resolution
- Support 2 GbE, eSATA, 6 USB 2.0 and 4 COMs
- Internal one 2.5-inch SATA HDD drive bay
- Various expansion interfaces for diverse applications
- Easy integration, easy maintenance, and wide input voltage range

### 1.2.2 Display

- CRT display: Using a DVI to CRT adapter connector
- Dual display: CRT + DVI-D extended by DVI-I Y-cable (Optional)
- LVDS support: Support 48-bit LVDS interface (Optional)

### **1.2.3 Power Consumption**

- **Typical:** 21 W (CPU is Intel® Mobile Celeron® at 1.5 GHz and w/o expansion)
- Max.: 26 W (CPU is Intel® Mobile Celeron® at 1.5 GHz and w/o expansion)

# **1.3 Hardware Specification**

- **CPU:** Intel® Celeron® M 370, 1.5 GHz/ Celeron® M 373, 1.0 GHz
- System Chipset: Intel® 910GMLE + ICH6M
- **BIOS:** AWARD<sup>TM</sup> 4 Mbit, FWH
- System Memory: 1 x 200-pin SODIMM socket, Support DDR2 333/400 MHz, up to 2 GB
- SSD: Supports 1 x CF Card TYPE I/II
- **HDD:** Supports 1 x industrial extend temperature grade 2.5" SATA HDD
- Watchdog Timer: Single chip Watchdog 255-level interval timer, setup by software
- I/O Interface: 2 x RS232, 2 x RS232/422/485 (w/ auto flow control)
- **USB:** 6 x USB 2.0 compliant Ports
- Audio: Supports Line-in, Line-out, Microphone-in
- Ethernet Chipset: 2 x Realtek 8111B (Gigabit LAN)
  - Speed: 10/100/1000 Mbps
  - Interface: 2 x RJ45 w/ LED
  - Standard: IEEE 802.3z/ab (1000 Mbps) or IEEE 802.3u 100 Mbps compliant
- Expansion:
  - PCI: 2 slots
  - Mini PCI: 1 socket
- Chipset: Integrated graphics built in Intel® 910GMLE, Mobile Intel® Graphics Media Accelerator 900
- Memory Size: Dynamic Video Memory Technology (DVMT 3.0; Support up to 128 MB)
- Resolution:
  - CRT: Up to 1920x1080 with 2 vertical taps
  - DVI: Support up to UXGA (1600X1200 @ 75 Hz)
- Dual Independent: CRT + DVI-D (Extended by DVI-I Y-cable)

# **1.4 Mechanical Specification**

### 1.4.1 Dimensions



Figure 1.1 ARK-3400 Mechanical Dimension Drawing

### 1.4.2 Weight

3.8 kg (8.36 lb)

# **1.5 Power requirement**

## 1.5.1 System power

Minimum power input: DC 14 V-24 V 4.8 A-2.8 A

### 1.5.2 RTC battery

3 V / 195 mAH BR2032

# **1.6 Environmental Specifications**

### **1.6.1 Operation temperature**

- With Industrial Grade CompactFlash disk: -20 ~ 55° C
- With 2.5-inch extended temperature hard disk -20 to 45° C, with air flow, speed=0.7 m/sec

### 1.6.2 Relative Humidity

95% @ 40° C (non-condensing)

### 1.6.3 Storage temperature

-40 ~ 85° C (-40 ~ 185° F)

### **1.6.4 Vibration loading during operation**

- With CompactFlash disk: 5 Grms, IEC 60068-2-64, random, 5 ~ 500 Hz, 1 Oct./ min, 1 hr/axis.
- With 2.5-inch hard disk: 1 Grms, IEC 60068-2-64, random, 5 ~ 500 Hz, 1 Oct./ min, 1 hr/axis.

### **1.6.5** Shock during operation

- With CompactFlash disk: 50 G, IEC 60068-2-27, half sine, 11 ms duration
- With hard disk: 20 G, IEC 60068-2-27, half sine, 11 ms duration

### 1.6.6 Safety

UL, CCC, BSMI

### 1.6.7 EMC

CE, FCC, CCC, BSMI

ARK-3400 User Manual



# Hardware installation

This chapter introduces external IO and the installation of ARK-3400 Hardware.

# 2.1 ARK-3400 I/O Indication



Figure 2.1 ARK-3400 Front View



Figure 2.2 ARK-3400 Rear View

# 2.2 ARK-3400 Front Side External I/O Connectors

### 2.2.1 Power ON/OFF Button

ARK-3400 comes with a Power On/Off button with LED indicators on the front side to show its On status (Green LED) and Off/Suspend status (Orange LED), that support dual function of Soft Power -On/Off (Instant off or Delay 4 Second), and Suspend.



### Figure 2.3 Power ON/OFF Button

### 2.2.2 Reset Button

ARK-3400 has a Reset button on front side. Press the button can to activates the reset function.



### Figure 2.4 Reset Button

### 2.2.3 LED Indicators

There are two LED on ARK-3400 front metal face plate for indicating system status: Thermal LED is for system thermal alarm status; and HDD LED is for HDD & compact flash disk status.



### Figure 2.5 LED Indicators

### 2.2.4 Audio Connector

ARK-3400 offers stereo audio ports by three phone jack connectors of Line\_Out, Line\_In, Mic\_In. The audio chip controller is ALC203, Which is compliant with Azalea standard.



Figure 2.6 Audio jack connectors

### 2.2.5 COM Connector

ARK-3400 provides four D-sub 9-pin connectors that are serial communication interface ports. The COM1/2 in the rear side support RS-232/422/485 by jumper setting, the COM3/4 in the front side support RS-232 only. Default setting of these four ports are RS-232.



Figure 2.7 COM port connector

Table	e 2.1: COM standar	d serial port pin assig	nments	
	RS-232	RS-422	RS-485	
Pin	Signal Name	Signal Name	Signal Name	
1	DCD	Tx-	DATA-	
2	RxD	Tx+	DATA+	
3	TxD	Rx+	NC	
4	DTR	Rx-	NC	
5	GND	GND	GND	
6	DSR	NC	NC	
7	RTS	NC	NC	
8	CTS	NC	NC	
9	RI	NC	NC	
Note:	NC represents "No Con	nection".		

### 2.2.6 eSATA Connector

ARK-3400 has a 7 pin external connector for eSATA device. That is fully compliant with SATA I/SATA II standards, its can be access with external SATA I/SATA II device then up to 300MB/sec.



Figure 2.8 eSATA connector

### 2.2.7 USB Connector

ARK-3400 provides six connectors of USB interface, which give complete Plug & Play and hot swapping for up to 127 external devices. The USB interface complies with USB UHCI, Rev. 2.0 compliant. The USB interface can be disabled in the system BIOS setup. Please refer to Table. 2.2 for its pin assignments

The USB connectors are used for connecting any device that conforms to the USB interface. Many recent digital devices conform to this standard. The USB interface supports Plug and Play, which enables you to connect or disconnect a device whenever you want, without turning off the computer.



### Figure 2.9 USB connector

Table 2.2: USB Connector				
Pin	Signal name	Pin	Signal name	
1	VCC	2	USB_data-	
3	USB_data+	4	GND	

### 2.2.8 Compact Flash Card

ARK-3400 is equipped with an external CF card. You can find the installation in Chapter 2.5.

# 2.3 ARK-3400 rear side external I/O connectors

### 2.3.1 Power Input Connector

ARK-3400 comes with a four pins header that carries +14  $\sim$  24 VDC external power input.



### Figure 2.10 Power Input Connector

Table 2.3: Power connector pin assignments			
Pin	Signal Name		
1	GND		
2	+14 ~ 24 VDC		
3	+14 ~ 24 VDC		
4	GND		

### 2.3.2 Digital Visual Interface Connector (DVI-I)

The ARK-3400 offers a integrate Digital Visual Interface connector by a D-sub 24-pin female DVI-I connector, it integrates analog and digital video signal. This supports high-speed, high-resolution digital display and traditional analog display.



Figure 2.11 DVI-I connector

Table 2.4	: DVI-I Connector pin assig	nments	
Pin	Signal Name	Pin	Signal Name
1	TMDS Data 2-	2	TMDS Data 2+
3	TMDS Data 2/4 shield	4	TMDS Data 4-
5	TMDS Data 4+	6	DDC clock
7	DDC data	8	Analog vertical sync
9	TMDS Data 1-	10	TMDS Data 1+
11	TMDS Data 1/3 shield	12	TMDS Data 3-
13	TMDS Data 3+	14	+5 V
15	Ground	16	Hot plug detect
17	TMDS data 0-	18	TMDS data 0+
19	TMDS data 0/5 shield	20	TMDS data 5-
21	TMDS data 5+	22	TMDS clock shield
23	TMDS clock+	24	TMDS clock-
C1	Analog red	C2	Analog green
C3	Analog blue	C4	Analog horizontal sync
C5	Analog ground		

### 2.3.3 Ethernet Connector (LAN)

ARK-3400 provides two RJ45 connectors of Gb LAN interface, they are equipped with two Realtek 8111B Ethernet controllers that are fully compliant with IEEE 802.3u 10/100/1000 Mbps CSMA/CD standards. The Ethernet port provides a standard RJ-45 jack connector with LED indicators on the front side to show its Active/Link status (Green LED) and Speed status (Yellow LED).



Figure 2.12 Ethernet connector

Table 2.5: RJ-45 Connector pin assignments			
Pin	10/100/1000BaseT Signal Name		
1	TX+		
2	TX-		
3	RX+		
4	MDI2+		
5	MDI2-		
6	RX-		
7	MDI3+		
8	MDI3-		

### 2.3.4 LVDS Connector

The ARK-3400 comes with a D-Sub 26-pin connector that carries LVDS signal output, and can direct connect to LVDS LCD Display via external cable.

The system also provide a jumper of JP3 on internal motherboard for selecting the LCD signal power of 5V or 3.3V, please refer to the jumper table of JP3, and  $^{\circ}$ ×Full Disassembly Procedure $^{\circ}$ ± to adjust it. Up. The default setting of JP3 is 5 V.



Figure 2.13 LVDS Connector

Table	e 2.6: LVDS Connector	<sup>r</sup> Pin Assignme	nt	
Pin	Signal Name	Pin	Signal name	
1	LVDS_CLKBP	14	LVDS_CLKBM	
2	GND	15	LVDS_YAM0	
3	LVDS_YAP0	16	LVDS_YAM1	
4	LVDS_YAP1	17	LVDS_YAM2	
5	LVDS_YAP2	18	LVDS_CLKAM	
6	LVDS_CLKAP	19	GND	
7	+3.3 or +5 V	20	+3.3 or +5 V	

Table	2.6: LVDS Cor	nnector Pin Assignment		
8	GND	21	LVDS_YAM3	
9	LVDS_YAP3	22	LVDS_YBM0	
10	LVDS_YBP0	23	LVDS_YBM1	
11	LVDS_YBP1	24	LVDS_YBM2	
12	LVDS_YBP2	25	LVDS_YBM3	
13	LVDS_YBP3	26	GND	

### 2.3.5 LCD Backlight On/Off control Connector

The ARK-3400 comes with a D-Sub 9-pin connector which provides BKLTEN signal as well as +12 V, +5 V and Ground Pin signals that allow the user to connect these signals to LCD Inverter to implement the LCD On/Off control.

Provides BKLTEN signal that inverter Module requires for inverter on/off control.



### Figure 2.14 LCD Backlight connector

Table 2.7: LCD Backlight Connector Pin Assignment		
Pin	Signal name	
1	+12 V	
2	GND	
3	BKLTEN	
4	VBR	
5	+5 V	
6	Reserved	
7	Reserved	
8	Reserved	
9	Reserved	

### 2.3.6 LPT Connector

The ARK-3400 provides one D-sub 25-pin female connector, which offers printers or other communication interface port. If you want to use LPT port, you can find the Pin assignment as following.



Figure 2.15 LPT Connector

Table 2.8: LPT Connector Pin Assignment			
Pin	Signal Name	Pin	Signal name

Table	2.8: LPT Conne	ector Pin Assignment		
1	STROBE	14	ALF	
2	PD0	15	ERROR	
3	PD1	16	INIT	
4	PD2	17	SLCTIN	
5	PD3	18	GND	
6	PD4	19	GND	
7	PD5	20	GND	
8	PD6	21	GND	
9	PD7	22	GND	
10	ACK	23	GND	
11	BUSY	24	GND	
12	PE	25	GND	
13	SLCT			

### 2.3.7 DIO Connector

The ARK-3400 provides one D-sub 25-pin male connector, which offers Digital I/O communication interface port. If you want to use DIO port, you can find the Pin assignment as following.



### Figure 2.16 DIO Connector

Table	2.9: DIO Connector Pin	Assignment	
Pin	Signal Name	Pin	Signal name
1	DIO0-0	14	DIO1-0
2	DIO0-1	15	DIO1-1
3	DIO0-2	16	DIO1-2
4	DIO0-3	17	DIO1-3
5	DIO0-4	18	DIO1-4
6	DIO0-5	19	DIO1-5
7	DIO0-6	20	DIO1-6
8	DIO0-7	21	DIO1-7
9	GND	22	GND
10	GND	23	GND
11	GND	24	GND
12	+5 V	25	+5 V
13	+5 V		

# 2.4 Memory Installation

- 1. Flip the system upside down, and open the bottom cover by unscrewing the 4 screws.
- 2. Insert the memory module into the SODIMM socket.
- 3. Replace cover with screws.



Figure 2.17 Memory Installation

# Chapter 2 Hardware installation

# 2.5 Compact Flash installation

- 1. Open the front CF/HDD door by loosening the door screw.
- 2. Insert the CF card into the CF socket.
- 3. Reassemble.



Figure 2.18 CF Card installation

# 2.6 HDD installation

- 1. Remove the bottom cover by unscrewing the 4 screws. (Refer to Chapter 2.4)
- 2. Install the 2.5-inch SATA HDD with 4 HDD screws.
- 3. Connect the SATA signal cable and power cable to the connectors.



Figure 2.19 HDD Installation

# 2.7 PCI card installation

- 1. Remove the bottom cover by unscrewing the 4 screws. (Refer to Chapter 2.4)
- 2. Remove the Riser card module.
- 3. Insert the PCI extension card into the PCI slot of the riser card module.
- 4. Reassemble the Riser card module.
- 5. Reattach the bottom cover.



Figure 2.20 PCI Card Installation

# 2.8 Mini PCI installation

- 1. Open the bottom cover and remove the Riser card module. (Refer Chapter 2.4)
- 2. Insert the Mini PCI card into the Mini PCI socket and latch it into place.



Figure 2.21 Mini PCI Card Installation

# 2.9 Antenna installation

- 1. Remove the heatsink by loosening the fixing screws.
- 2. Pass the internal antenna cable jack through the antenna hole on the rear panel and fix it by tightening the matched nut.
- 3. Put on the external antenna cable.



Figure 2.22 Remove the cover



Figure 2.23 Antenna installation

# 2.10 Optional Cable Installation

(3

(2 (1

Open the bottom cover and follow the illustration and table below for optional cable installation and connection.



Bottom view (Opened)

Figure 2.24 Removable HDD Installation

	Outer connector fixing(connection)	Inner connector fixing(connection)
DIO cable (P/N: 1700009407)	1	Α
LPT cable (P/N: 1700009405)	2	В
LVDS cable (P/N: 1700009398)	3	С
LVDS power cable (P/N: 1700009396)*	4	D

### Note!

When the LVDS panel power source is provided from the system, the LVDS voltage jumper needs to be selected.

ARK-3400 User Manual



# **BIOS** settings

This chapter introduces how to set BIOS configuration data.

# 3.1 **BIOS Introduction**

Advantech provides full-featured Award BIOS that delivers the superior performance, compatibility and functionality that system integrators demand.

The modular, adaptable AwardBIOS supports the broadest range of third-party peripherals and all popular chipsets, plus Intel, AMD, nVidia, VIA, and compatible CPUs from 386 through Pentium and AMD Geode, K7 and K8 (including multiple processor platforms), and VIA Eden C3 and C7 CPU.

You can use Advantech's utilities to select and install features as needed.

# 3.2 BIOS Setup

The ARK-3400 series system has build-in AwardBIOS with a CMOS SETUP utility which allows the user to configure required settings or to activate certain system features.

The CMOS SETUP saves the configuration in the CMOS RAM of the motherboard. When the power is turned off, the battery on the board supplies the necessary power to the CMOS RAM.

When the power is turned on, press the <Del> button during the BIOS POST (Power-On Self Test) will take you to the CMOS SETUP screen.

CONTROL KEYS		
$< \uparrow >< \downarrow >< \leftarrow >< \rightarrow >$	Move to highlight item	
<enter></enter>	Select Item	
	Main Menu - Quit and not save changes into CMOS	
	Sub Menu - Exit current page and return to Main Menu	
<page +="" up=""></page>	Increase the numeric value or make changes	
<page -="" down=""></page>	Decrease the numeric value or make changes	
<f1></f1>	General help, for Setup Sub Menu	
<f2></f2>	Item Help	
<f5></f5>	Load Previous Values	
<f7></f7>	Load Optimized Default	
<f10></f10>	Save all CMOS changes	
## 3.2.1 Main Menu

Press <Del> to enter AwardBIOS CMOS Setup Utility, the Main Menu will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.



Figure 3.1 Award BIOS CMOS Setup Utility

#### Standard CMOS Features

This setup page includes all the items in standard compatible BIOS.

#### Advanced BIOS Features

This setup page includes all the items of Award BIOS enhanced features.

#### Advanced Chipset Features

This setup page includes all the items of Chipset configuration features.

#### Integrated Peripherals

This setup page includes all onboard peripheral devices.

Power Management Setup

This setup page includes all the items of Power Management features.

#### PnP/PCI Configurations

This setup page includes PnP OS and PCI device configuration.

#### PC Health Status

This setup page includes the system auto detect CPU and system temperature, voltage, fan speed.

- Frequency/Voltage Control This setup page includes CPU host clock control, frequency ratio and voltage.
- Load Optimized Defaults This setup page includes Load system optimized value, and the system would be in best performance configuration.

#### Set Password

Establish, change or disable password.

Save & Exit Setup Save CMOS value settings to CMOS and exit BIOS setup.

### Exit Without Saving Abandon all CMOS value changes and exit BIOS setup.

## 3.2.2 Standard CMOS Features

Phoen	ix - AwardBIOS CMD Standard CMDS F	IS Setup Ut 'eatures	ility
Date (mm:dd:yy) Time (bb:mm:cs)	Fri, Jul 17	2009	Item Help
<ul> <li>IDE Channel 0 Master</li> <li>IDE Channel 0 Slave</li> <li>IDE Channel 1 Master</li> </ul>	19 - 3 - 30		Menu Level ► Press [Enter] to enter next page for detail
Video Halt On	[EGA/UGA] [All Errors]		nara arive settings
Base Memory Extended Memory Total Memory	1X 15360K 16384K		
†↓→←:Move Enter:Select F5:Previous V	+/-/PU/PD:Value Values	F10:Save F7: Optim	ESC:Exit F1:General Help ized Defaults

Figure 3.2 Award BIOS Standard CMOS Features

#### Date

The date format is <weekday>, <month>, <day>, <year>.

Weekday From Sun to Sat, determined and display by BIOS only Month From Jan to Dec.

Month From Jan to Dec

Day From 1 to 31

Year From 1999 through 2098

#### Time

The time format in <hour> <minute> <second>, is based on 24-hour time.

#### IDE Channel 0 Master

CF Card Auto-Detection Press "Enter" for automatic device detection.

#### IDE Channel 2 Master

eSATA HDD Auto-Detection Press "Enter" for automatic device detection.

#### IDE Channel 2 Slave

SATA HDD Auto-Detection Press "Enter" for automatic device detection.

#### Video

The item determines that VGA display support type.

EGA/VGA Support VGA color mode.

- CGA 40 Support VGA color mode.
- CGA 80 Support VGA color mode.
- MONO Support VGA mono mode.

#### Halt on

The item determines whether the computer will stop if an error is detected during power up.

No Errors	The system boot but will not stop for any error		
All Errors	Whenever the BIOS detects a non-fatal error the system		
	will be stopped.		
All, But Keyboard	The system boot will not stop for a keyboard error, but it will stop for all other errors.		
	Base Memory		

The POST of the BIOS will determine the amount of base (or conventional) memory installed in the system.

#### Extended Memory

The POST of the BIOS will detect the amount of extended memory (above 1 MB in CPU's memory address map) installed in the system.

#### Total Memory

This item displays the total system memory size.

## 3.2.3 Advanced BIOS Features

Phoenix – AwardBIOS CMOS Setup Utility Advanced BIOS Features				
▶ CPU Feature	[Press Enter	1 🔺	I	tem Help
Hard Disk Boot Priority	IPress Enter	1		
Virus Warning	[Disabled]		Menu Leve	el 🕨 🔰
CPU L1 & L2 Cache	[Enabled]			
CPU L3 Cache	[Enabled]			
Hyper-Threading Technolog	y[Enabled] 👘			
Quick Power On Self Test	[Enabled]			
USB Flash Disk Type	[Auto]			
First Boot Device	EUSB-FDD 1			
Second Boot Device	ECDROM1			
Third Boot Device	[Hard Disk]			
Boot Other Device	[Enabled]			
Boot Up NumLock Status	[On]			
Gate A20 Option	[Fast]			
Typematic Rate Setting	[Disabled]			
× Typematic Rate (Chars/Sec				
× Typematic Delay (Msec)	250			
Security Option	[Setup]			
APIC Mode	[Enabled]			
†↓→+:Move Enter:Select +/- F5:Previous Value	∕PU∕PD∶Value s	F10:Save F7: Optim	ESC:Exit ized Defau	F1:General Help lts

Figure 3.3 Award BIOS Advanced CMOS Features

#### CPU Feature

This item allows user to adjust CPU features, CPU ratio, VID and Thermal and special features like XD flag.

#### Hard Disk Boot Priority

This item allows user to select boot sequence for system device HDD, SCSI, RAID.

#### Virus Warning [Disabled]

This item allows user to choose the VIRUS Warning feature for IDE Hard Disk boot sector protection.

#### CPU L1 & L2 Cache [Enabled]

This item allows user to enable CPU L2 cache and ECC checking function.

#### Quick Power On Self Test [Enabled]

This field speeds up the Power-On Self Test (POST) routine by skipping retesting a second, third and forth time. Setup setting default is enabled.

#### USB Flash Disk Type [Auto]

This item allows user to changed flash disk format. Setup setting default is auto.

#### First / Second / Third / Other Boot Drive

Hard Disk	Assign this boot device priority to Hard Disk.
CDROM	Assign this boot device priority to CDROM.
USB-FDD	Assign this boot device priority to USB-FDD.
USB-ZIP	Assign this boot device priority to USB-ZIP.
USB-CDROM	Assign this boot device priority to USB-CDROM.
LAN1	Assign this boot device priority to LAN.
LAN2	Assign this boot device priority to LAN.
Disabled	Disable this boot function.

## Boot Up NumLock Status [On]

This item enables users to activate the Number Lock function at system boot.

- Gate A20 Option [Fast]
  - This item enables users to switch A20 control by port 92 or not.
- Typematic Rate Setting [Disabled]

This item enables users to set the two typematic control items.

- Typematic Rate (Chars/Sec)
   The speed at which the system registers repeated keystrokes.
   Eight settings are 6, 8, 10, 12, 15, 20, 24 and 30.
- Typematic Delay (Msec)
   This item sets the keypress delay before typematic repetition kicks in.
   Four delay options are 250, 500, 750 and 1000.

#### Security Option [Setup]

- System Correct password must be supplied for both System boot, and for Setup page access.
- Setup Correct password must be supplied for access to Setup page. (Default value)

#### APIC Mode [Enabled]

This item allows user to enable or disable "Advanced Programmable Interrupt Controller". APIC is implemented in the motherboard and must be supported by the operating system, and it extends the number of IRQs available.

 MPS Version Control for OS [1.4] This item sets the operating system multiprocessor support version.

#### OS Select For DRAM > 64 MB [Non-OS2]

Select OS2 only if the system is running the OS/2 operating system with greater than 64 MB of RAM on the system.

## 3.2.4 Advanced Chipset Features

Phoenix - Adv	AwardBIOS CMOS Setup Ut anced Chipset Features	ility
DRAM Timing Selectable	[By SPD]	Item Help
CAS Latency Time DRAM RAS# to CAS# Delay	LAuto] [Auto]	Menu Level 🕨
DRAM RAS# Precharge	[Auto]	
System Memory Frequency	[Auto]	
SLP_S4# Assertion Width Sustem BIOS Cacheable	[4 to 5 Sec.] [Enabled]	
Video BIOS Cacheable	[Disabled]	
Memory Hole At 15M-16M ▶ PCI Express Root Port Fun	LDisabled] c[Press Enter]	
** VGA Setting **		
PEG/Onchip UGA Control	[Auto]	
On-Chip Frame Buffer Size	[ 8MB]	
DUMT Mode		
Panel Type	[1024×768 LVDS]	
↑↓→+:Move Enter:Select +/- F5:Previous Value	/PU/PD:Value F10:Save s F7: Optim	ESC:Exit F1:General Help nized Defaults

Figure 3.4 Award BIOS Advanced Chipset Features

**Note!** This "Advanced Chipset Features" screen controls the configuration of the board's chipset for fine-tuning system performance. Screen options depend on the specific chipset. It is strongly recommended that only technical users make changes to the default settings.

#### DRAM Timing Selectable [By SPD]

This item allows the user to set optimal timings for items 2 through 5. The system default setting of "By SPD" follows the SPD information on the ROM chip and ensures the system runs stably, with optimal performance.

#### CAS Latency Time [Auto]

This item allows the user to set the timing delay in clock cycles before SDRAM starts a read command after receiving it.

#### DRAM RAS# to CAS# Delay [Auto]

This item allows the user to set the timing of the transition from RAS (row address strobe) to CAS (column address strobe) as both rows and columns are separately addressed shortly after the DRAM is refreshed.

#### DRAM RAS# Precharge [Auto]

This item allows the user to set the DRAM RAS# precharge timing. The system default is set to "Auto" to reference the data from the SPD ROM.

#### Precharge delay (tRAS) [Auto]

This item allows the user to adjust memory precharge time.

### System Memory Frequency [Auto]

This item allows the user to adjust memory frequency to improve performance.

#### SLP\_S4# Assertion Width [4 to 5 sec.]

This item allows user to adjust SLP\_S4# signal. This field indicates the minimum assertion width of the SLP\_S4# signal to ensure that the DRAMs have been safely power-cycled.

#### System BIOS Cacheable [Enabled] This item allows the system BIOS to be cached to allow faster execution and better performance.

Video BIOS Cacheable [Disabled]

This item allows the video BIOS to be cached to allow faster execution and better performance.

#### Memory Hole At 15 M-16 M [Disabled]

This item reserves 15MB-16MB memory address space to ISA expansion cards that specifically require the setting. Memory from 15MB-16MB will be unavailable to the system because only the expansion cards can access memory in this area.

PCI Express Root port Func [Press Enter] This item allows the user to adjust PCIE port on, off, or auto.

## PEG/Onboard VGA Control [Auto]

This item allows the user to select whether onboard graphics processor or the PCI card.

#### ■ On-Chip Frame Buffer Size [8 MB]

This item allows the user to adjust on-chip graphics of memory buffer.

#### DVMT Mode [DVMT]

Intel's Dynamic Video Memory Technology (DVMT) takes that concept further by allowing the system to dynamically allocate memory resources according to the demands of the system at any point in time. The key idea in DVMT is to improve the efficiency of the memory allocated to either system or graphics processor.

The BIOS feature that controls all this is the DVMT Mode BIOS feature. It allows you to select the DVMT operating mode.

- Fixed The graphics driver will reserve a fixed portion of the system memory as graphics memory. This ensures that the graphics processor has a guaranteed amount of graphics memory but the downside is once allocated, this memory cannot be used by the operating system even when it is not in use.
- DVMT The graphics chip will dynamically allocate system memory as graphics memory, according to system and graphics require ments. The system memory is allocated as graphics memory when graphics-intensive applications are running but when the need for graphics memory drops, the allocated graphics memory can be released to the operating system for other uses.
- BOTH The graphics driver will allocate a fixed amount of memory as dedicated graphics memory, as well as allow more system memory to be dynamically allocated between the graphics processor and the operating system.

#### DVMT/FIXED Memory Size [128 MB]

This item allows the user to adjust DVMT/FIXED graphics memory size.

#### Panel Type [1024 x 768 LVDS]

These fields allow you to select the LCD Panel type. The default values for these ports are:

- 640 x 480 LVDS
- 800 x 600 LVDS
- 1024 x 768 LVDS
- 1280 x 1024 LVDS
- 1400 x 1050 RB LVDS(LFP1)
- 1400 x 1050 Non-RB (LFP1)

- 1600 x 1200 LVDS (LFP1)
- Boot Display [CRT+EFP]

This item allows the user to adjust panel resolution.

## 3.2.5 Integrated Peripherals

	Phoenix – AwardBIOS CMOS Setup Utility Integrated Peripherals						
▶ OnChip	IDE Device	[Press Enter]	1		Item Help		
► Onboard ► Super IO	Device	IFress Enter IPress Enter	1	Menu Lev	vel	•	
t↓→←∶Move	Enter:Select F5:Previous Va	+/-/PU/PD:Value lues	F10:Save F7: Optim	ESC:Exit	F1:Ge ults	meral	Help

Figure 3.5 Award BIOS Integrated Peripherals



This "Integrated Peripherals" option controls the configuration of the board's chipset, includes IDE, ATA, SATA, USB, AC97, MC97 and Super IO and Sensor devices; this page depends on the particular chipset installed.

#### OnChip IDE Device

This item enables users to set the OnChip IDE device status, includes enable IDE devices and setting PIO and DMA access mode, and some of new chipset also support for SATA device (Serial-ATA).

#### Onboard Device

This item enables users to set the USB, Azalia/AC97, LAN status enable or disable.

#### Super IO Device

This item enables users to set the Super IO device status, includes enable Floppy, COM, LPT, IR and control GPIO and Power fail status.

Onboard Serial port 1 [3F8]

This item allows user to adjust serial port 1 address.

Serial port 1 Use IRQ [IRQ3]

This item allows user to adjust serial port 1 IRQ.

#### SP 1 AutoFlow Control [Disabled]

Auto flow control is used in RS-485, is used to tri-state the transmitter when no other data is available, so that other nodes can use the shared lines.

When auto flow control is enable, the device monitors the local output buffer for not empty and empty conditions. If enable, the flow control will force signal to the desired polarity under the empty or not empty condition.

#### Onboard Serial port 2 [3E8]

This item allows user to adjust serial port 2 address.

#### Serial port 2 Use IRQ [IRQ4]

This item allows user to adjust serial port 2 IRQ.

- SP 2 AutoFlow Control [Disabled] Auto flow control is used in RS-485, is used to tri-state the transmitter when no other data is available, so that other nodes can use the shared lines. When auto flow control is enable, the device monitors the local output buffer for not empty and empty conditions. If enable, the flow control will force signal to the desired polarity under the empty or not empty condition. Onboard Serial port 3 [2F8] This item allows user to adjust serial port 3 address. Serial port 3 Use IRQ [IRQ5] This item allows user to adjust serial port 3 IRQ. Onboard Serial port 4 [2E8] This item allows user to adjust serial port 4 address. Serial port 4 Use IRQ [IRQ10] This item allows user to adjust serial port 4 IRQ. **Onboard Parallel Port [378/IRQ7]** This item allows user to adjust Parallel port address and IRQ.
- Parallel Port Mode [Standard] This item allows user to adjust parallel port mode of standard/SPP/EPP and ECP.
- ECP Mode Use DMA [3]

This item allows user to adjust ECP DMA resource.

## 3.2.6 Power Management Setup

Phoenix - Pa	AwardBIOS CMOS S wer Management Se	etup Ut: tup	ility
PCI Express PM Function OCPL Express PM Function	[Press Enter]	4	Item Help
ACPI Suspend Type	ES1(POS)]		Menu Level 🕨
× Run UGABIUS if S3 Resume Power Management	Auto [Min Saving]		
Video Off Method Video Off In Suspend	[DPMS] [Yes]		
Suspend Type	[Stop Grant]		
Suspend Mode	Disabled		
Soft-Off by PWR-BTTN	[Instant-Off]		
Wake-Up by PCI card Power On by Ring	[Enabled] [Enabled]		
× USB KB Wake-Up From S3 Resume bu Alarm	Disabled [Disabled]		
× Date(of Month) Alarm	0		
X IIme(III.mm.SS) Hidrm	0.0.0		
†↓→←:Move Enter:Select +/- F5:Previous Value	-/PU/PD:Value F10 s F7	:Save I : Optim:	ESC:Exit F1:General Help ized Defaults

Figure 3.6 Award BIOS Power Management Setup

**Note!** This "Power Management Setup" screen configures the system to most effectively save energy while operating in a manner consistent with your computer use.

#### PCI Express PM Function [Press Enter]

#### PCI Express PME [Enabled]

This item allows user to select boot sequence for Enabled(default)/Disable .

#### ACPI Function [Enabled]

This item defines the ACPI (Advanced Configuration and Power Management) feature that makes hardware status information available to the operating system, and communicate PC and system devices for improving the power management.

#### ACPI Suspend Type [S1 (POS)]

This item allows user to select sleep state when suspend.

- S1(POS) The suspend mode is equivalent to a software power down;
- S3(STR) The system shuts down with the exception of a refresh current to the system memory.

#### Run VGA BIOS if S3 Resume [Auto]

This item allows system to reinitialize VGA BIOS after system resume from ACPI S3 mode.

#### Power Management [User Define]

This item allows user to select system power saving mode.

Min Saving Minimum power management. Suspend Mode=1 hr.

Max Saving Maximum power management. Suspend Mode=1 min.

User Define Allows user to set each mode individually.

Suspend Mode= Disabled or 1 min ~1 hr.

#### Video Off Method [DPMS]

This item allows user to determine the manner is which the monitor is blanked.

V/H SYNC+Blank This option will cause system to turn off vertical and horizontal synchronization ports and write blanks to the

video buffer.

Blank ScreenThis option only writes blanks to the video buffer.DPMSInitial display power management signaling.

#### Video Off In Suspend [Yes]

This item allows user to turn off Video during system enter suspend mode.

#### Suspend Type [Stop Grant]

This item allows user to determine the suspend type.

#### Modem use IRQ [3]

This item allows user to determine the IRQ which the MODEM can use.

#### Suspend Mode [Disabled]

This item allows user to determine the time of system inactivity, all devices except the CPU will be shut off.

#### HDD Power Down Mode [Disabled]

This item allows user to determine the time of system inactivity, the hard disk drive will be powered down.

#### Soft-Off by PWR-BTTN [Instant-Off]

This item allows user to define function of power button.

Instant-Off Press power button then Power off instantly.

Delay 4 Sec Press power button 4 sec. to Power off.

#### Wake-Up by PCI card [Enabled]

This item allows user to defines PCI cards to wake up the system from the suspend mode.

#### Power On by Ring [Enabled]

This item allows the user to enable and define how the system will resume by activation of the modem ring.

#### Resume by Alarm [Disabled]

This item allows user to enable and key in Date/time to power on system

Disabled Disable this function.

Enabled Enable alarm function to power on system

Data (of month) Alarm1-31

Time (HH:MM:SS) Alarm(0-23) : (0-59) : 0-59)

#### Reload Global Timer Events

Primary IDE 0	[Disabled]
Primary IDE 1	[Disabled]
Secondary IDE 0	[Disabled]
Secondary IDE 1	[Disabled]
FDD,COM,FPT Port	[Disabled]
PCI PIRQ[A-D]#	[Disabled]
Power Fail Function	[Always Off]

## 3.2.7 PnP/PCI Configurations

Phoemix – P	AwardBIOS CM nP∕PCI Config	OS Setup Ut urations	ility		
Init Display First Reset Configuration Data	[PCI Slot]			Item Help	
Resources Controlled By × IRQ Resources PCI/VGA Palette Snoop ** PCI Express relative i Maximum Payload Size	IAuto(ESCD)] Press Enter [Disabled] tems ** [4096]		Menu Le	uel ►	
†↓→+:Move Enter:Select +/- F5:Previous Value	∕PU∕PD∶Value s	F10:Save F7: Optim	ESC:Exit ized Defa	F1:General ults	Help

Figure 3.7 Award BIOS PnP/PCI Configurations

Note!			

Use this "PnP/PCI Configurations" option for setting up the IRQ and DMA (both PnP and PCI) bus assignments.

#### Init Display First [PCI Slot]

This item is setting for start up Video output from PCI or Onboard device.

#### Reset Configuration Data [Disabled]

This item allow user to clear any PnP configuration data stored in the BIOS.

#### Resources Controlled By [Auto (ESCD)]

IRQ Resources

This item allows you respectively assign an interruptive type for IRQ-3, 4, 5, 7, 9, 10, 11, 12, 14, and 15.

#### PCI VGA Palette Snoop [Disabled]

The item is designed to solve problems caused by some non-standard VGA cards. A built-in VGA system does not need this function.

#### Maximum payload Size [4096]

The item allows user to adjust maximum TLP (Transaction Layer Packet) payload size.

## 3.2.8 PC Health Status

	Phoenix	- AwardBIOS CM PC Health S	OS Setup Ut: tatus	ility		
Shutdown Temperature	[Disabled]		Item Help			
Current Current CPU Vol 3.3 V 2.5 V 5 V 12 V CPU Fan System	System Temp tage Speed Fan Speed			Menu Level	•	
t∔⇒∈∶Move	Enter:Select +/ F5:Previous Value	- <b>/PU/PD : Va lue</b> es	F10:Save I F7: Optim	ESC:Exit F1:0 ized Defaults	General H	lelp

Figure 3.8 Award BIOS PC Health Status

No	te!

This "PC Health Status" screen reports the thermal, fan and voltage status of the board. This page depends on the particular chipset installed.

- Shutdown Temperature [Disabled] This item control when to notify ACPI OS to shut down the system.
- Current CPU Temperature [Show Only]
   This item displays current CPU temperature.
- Current System Temperature [Show Only]
   This item displays current System temperature.
- VCC Core /+3.3V /+2.5V /+5V/ +12V [Show Only] This item displays current CPU and system voltage.
- CPU/System Fan Speed [Show Only]
   This item displays CPU/System fan speed.

## 3.2.9 Frequency/voltage Control

Phoenix – AwardBIOS CMOS Setup Utility Frequency/Voltage Control						
Spread	Spectrum	[Disabled]			Item Help	
				Menu Le	vel 🕨	
t↓⇒∈∶Move	Enter:Select F5:Previous V	+/-/PU/PD:Value alues	F10:Save F7: Optim	ESC:Exit mized Defa	F1:General ults	Help

Figure 3.9 Award BIOS Frequency/Voltage Control

**Note!** This "Frequency/Voltage Control" screen controls the CPU Host and PCI frequency, this page this page depends on the particular CPU and chipset installed; some items will only show up when you install a processor which supports those functions.

#### Spread Spectrum [Disabled]

This item enables users to set the spread spectrum modulation.

## 3.2.10 Load Optimized Defaults



Figure 3.10 Award BIOS Load Setup Defaults

# Note!

Load Optimized Defaults loads the default system values directly from ROM. If the stored record created by the Setup program should ever become corrupted (and therefore unusable), these defaults will load automatically when you turn the ARK-3400 Series system on.

## 3.2.11 Set Password



Figure 3.11 Award BIOS Set Password

# Note!

To enable this feature, you should first go to the Advanced BIOS Features menu, choose the Security Option, and select either Setup or System, depending on which aspect you want password protected. Setup requires a password only to enter Setup. System requires the password either to enter Setup or to boot the system. A password may be at most 8 characters long.

#### **To Establish Password**

- 1. Choose the Set Password option from the CMOS Setup Utility main menu and press <Enter>.
- 2. When you see "Enter Password", enter the desired password and press <Enter>.
- 3. At the "Confirm Password" prompt, retype the desired password, then press <Enter>.
- 4. Select Save to CMOS and EXIT, type <Y>, then <Enter>.

#### To Change Password

- 1. Choose the Set Password option from the CMOS Setup Utility main menu and press <Enter>.
- 2. When you see "Enter Password", enter the existing password and press <Enter>.
- 3. You will see "Confirm Password". Type it again, and press < Enter>.
- 4. Select Set Password again, and at the "Enter Password" prompt, enter the new password and press <Enter>.
- 5. At the "Confirm Password" prompt, retype the new password, and press <Enter>.
- 6. Select Save to CMOS and EXIT, type <Y>, then <Enter>.

#### **To Disable Password**

- 1. Choose the Set Password option from the CMOS Setup Utility main menu and press <Enter>.
- 2. When you see "Enter Password", enter the existing password and press <Enter>.
- 3. You will see "Confirm Password". Type it again, and press < Enter>.
- 4. Select Set Password again, and at the "Enter Password" prompt, please don't enter anything; just press <Enter>.
- 5. At the "Confirm Password" prompt, again, don't type in anything; just press <Enter>.
- 6. Select Save to CMOS and EXIT, type <Y>, then <Enter>.

## 3.2.12 Save & Exit Setup



Figure 3.12 Award BIOS SAVE to CMOS and EXIT



Typing "Y" will quit the BIOS Setup Utility and save user setup values to CMOS.

Typing "N" will return to BIOS Setup Utility.

## 3.2.13 Quit Without Saving



Figure 3.13 Award BIOS Quit without Saving

# Note!

*Typing "Y" will quit the BIOS Setup Utility and save user setup values to CMOS.* 

Typing "N" will return to BIOS Setup Utility.

ARK-3400 User Manual



Software Installation

## 4.1 Driver Installation

## 4.1.1 Chipset driver installation

1. Change folder address to \Drivers\Chipset, and double click to execute infinst\_autol.exe.



2. Click Next; go to the next step.



3. Click Yes to accept the License Agreement.



4. Click Next to exit Readme File Information window.

Intel® Ch Readme File	ipset Device Soft	ware	inte	P
Refer to the Read Press the Page Do ************ * Product: * Release: * Version: * Target (	me file below to view the system wn key to view the rest of the fi : Intel(R) Chipset D : Production Version : 8.3.1.1009 Chipset#: X38 & 3200 11v 26 2007	requirements and in e. ************** evice Softwa /3210 Chipse	stallation information. **************** re t	*
* Date: Ju				*
* Date: Ju	*****	********	*********	·

5. Click Next button to continue.

	cinpset Device Software	Inte	
Setup Pro	ogress		- Salar
Please wait w	hile the following setup operations are perfor	med:	
Copying File: Creating Key Installing Driv Version: 6.1.	<pre>CSVer.dll HKLM\SOFTWARE\Intel\Infinst\Language=E ver: Mobile Intel(R) 915GM/PM/GM5/910GML E 0.1008 continue.</pre>	ENU,sz Express Processor to DRAM Contro	oller -
Click Next to			
Click Next to			
Click Next to			

6. Select Yes, I want to restart this computer now, and then click the Finish button. The computer will restart automatically. The driver installation is completed.

1	Intel® Chipset Device Software		
	Intel® Chipset Device Software Setup Is Complete	intel	
	The setup program successfully installed the Intel® Chipset Device Softw. Click Finish to complete the setup process.	are onto this computer.	
		1	
	Intel0	Finish	

## 4.1.2 Graphic driver installation

1. Change folder address to \Drivers\Graphic. And double click to execute win2k\_xp142550.exe.



2. Click "Next" button to continue installation.



3. Click "Next" button to skip through welcome window.



4. Click "Yes" to accept License Agreement.

Intel(R) Graphics M	edia Accelerator Driver
	License Agreement
intel	Please read the following license agreement carefully. Press the Page Down key to view the rest of the agreement.
	INTEL SOFTWARE LICENSE AGREEMENT (OEM / IHV / ISV Distribution & Single User)
	IMPORTANT - READ BEFORE COPYING, INSTALLING OR USING. Do not use or load this software and any associated materials (collectively, the "Software") until you have carefully read the following terms and conditions. By loading or using the Software, you agree to the terms of this Agreement. If you do not wish to so agree, do not install or use the Software.
	Please Also Note: * If you are an Original Equipment Manufacturer (OEM), Independent
	You must accept all of the terms of the license agreement in order to continue the setup program. Do you accept the terms?
	< Back Yes No
	Intel(R) Installation Framework

Chapter 4 Software Installation

5. Click "Next" to exit Readme File Information window.

Intel(R) Graphics M	ledia Accelerator Driver 🗧 🗖 🔀
(intel)	<b>Readme File Information</b> Refer to the Readme file below to view the system requirements and installation information. Press the Page Down key to view the rest of the file.
	<ul> <li>************************************</li></ul>
	< Back Next > Cancel

6. Click "Next"button to continue.

Intel(R) Graphics M	Aedia Accelerator Driver	-
(intel)	Setup Progress Please wait while the following components are installed:	
	Copying file: igxpun.exe Copying file: difxapi.dll Copying file: IScrNB.bmp Copying file: IScrNBR.bmp Copying file: HDMIENU.dll Creating key: HKLM\System\CurrentControlSet\Services\ialm\Dev Creating key: HKLM\System\CurrentControlSet\Services\ialm\Dev Creating key: HKLM\System\CurrentControlSet\Services\ialm\Dev Creating key: HKLM\System\CurrentControlSet\Services\ialm\Dev Creating key: HKLM\System\CurrentControlSet\Services\ialm\Dev Creating key: HKLM\System\CurrentControlSet\Services\ialm\Dev Creating key: HKLM\SOFTWARE\Microsoft\Windows\CurrentVer Installing Driver: Mobile Intel(R) 915GM/GMS,910GML Express Ch Version: 6.14.10.4764	SystemDirecto vice0\SystemE vice1\SystemE sion\Uninstall\ sion\Uninstall\ ipset Family
	Installation has completed. Click Next to continue.	1
		>
		Next
	Intel(R) Installat	ion Framework

7. Select "Yes, I want to restart this computer now" and click "Finish" button. The computer will restart automatically. Then the driver installation is completed.



## 4.1.3 LAN driver installation

1. Change folder address to \Drivers\LAN. And double click to execute setup.exe.

😂 LAN				
File Edit View Favorites To	ols Help			<b>R</b>
🔇 Back 🔹 🕥 - 🏂 🎉	Search 🧭 Folders	<del>.</del>		
Address 🛅 D:\ARK-3400 CD\Driver	s\LAN		Solution	Go
	📩 Name 🔺	Size	Туре	Dat
File and Folder Tasks 🙁	🔁 WIN2000		File Folder	5/29
	🔁 WINXP		File Folder	5/2
Make a new rolder	💽 _setup.dll	365 KB	Application Extension	5/1
Publish this folder to	🛃 data 1	3,250 KB	Cabinet File	9/2
Cherre this folder	🗖 🖬 data1.hdr	36 KB	HDR File	9/2
	🚽 🛃 data2	136 KB	Cabinet File	9/2
	🚺 🔊 ISSetup.dll	481 KB	Application Extension	9/1
Other Places	🖬 🖬 layout	1 KB	BIN File	9/2
	setup	450 KB	Application	8/3
🛅 Drivers	📑 🤒 setup	1 KB	Configuration Settings	6/3
A My Documents	🖬 🖬 setup	226 KB	INX File	9/2
Shared Documents	🔜 🛅 setup.isn	63 KB	ISN File	5/1
My Computer	👼 setup.iss	1 KB	ISS File	12/
Sector My Network Places	~ <			>

2. Click "Next" button to the next step.



3. Click "Install" button to start installation.



4. The network driver installation is completed. Click "Finish".



### 4.1.4 Audio driver installation

1. Change folder address to \Drivers\Audio. And double click to execute.



Chapter 4 Software Installation

2. Click "Next" button to skip welcome message.



3. Click "Continue Anyway" button to install.



4. Select "Yes, I want to restart this computer now" and click "Finish" button. The computer will restart automatically. Then the driver installation is completed.





**Function Settings** 

# A.1 Function Setting



Figure A.1 Internal board top view



Figure A.2 Internal board bottom view

## Table A.1: Setting Table

## For PCM-9583 Setting

JP1	CLEAR CMOS
Part Number	1653003101
Footprint	JH3X1V-2M
Description	PIN HEADER 3*1P 180D(M) 2.0mm DIP SQUARE W/ O Pb
Setting	Function
(1-2)	NORMAL (Default)
(2-3)	CLEAR CMOS

JP3	Internal LVDS PANEL POWER Select
Part Number	1653003101
Footprint	JH3X1V-2M
Description	PIN HEADER 3*1P 180D(M) 2.0mm DIP SQUARE W/ O Pb
Setting	Function
(1-2)	5 V for +VLVDS2_PANEL POWER Select (Default)
(2-3)	3.3 V for +VLVDS2_PANEL POWER Select

JP4	ATX / AT Mode switch
Part Number	1653002101
Footprint	JH2X1V-2M
Description	PIN HEADER 2*1P 180D(M)SQUARE 2.0mm DIP W/ O Pb
Setting	Function
NL	ATX Mode(default)
ON	AT Mode

JSETCOM1	COM1 RS232/422/485 Select
Part Number	1653009260
Footprint	HD_9x2P_79_JVE
Description	PIN HEADER SMD 9*2P 180D(M) 2.0mm
Setting	Function
(5-6),(7-9),(8-10),(13- 15),(14-16)	RS232
(3-4),(9-11),(10-12),(15- 17),(16-18)	RS422
(1-2),(9-11),(10-12),(15- 17),(16-18)	RS485

JSETCOM2	COM2 RS232/422/485 Select
Part Number	1653009260
Footprint	HD_9x2P_79_JVE
Description	PIN HEADER SMD 9*2P 180D(M) 2.0mm
Setting	Function
(5-6),(7-9),(8-10),(13- 15),(14-16)	RS232
(3-4),(9-11),(10-12),(15- 17),(16-18)	RS422
(1-2),(9-11),(10-12),(15- 17),(16-18)	RS485

RS232	RS422	RS485
~ 0 0 ~	~ 0 0 ~	~ 0 0 ~
∾ O O 4	ε <mark>Ο Ο</mark> 4	∾ O O 4
e O O 2	e 0 0 2	و 0 0 ء
× 0 0 ∞	⊳ 0 0 8	∞ 0 0
° <b>00</b> €	° 0 0 2	9009
<b>400</b>	<b>₽00</b> 7	₽ <b>00</b> 7
7003	<b>2</b> 00	<b>₽</b> 00
\$ <b>00</b> \$	÷00 ÷	\$ <b>0 0</b> \$
\$ 9	°, <b>00</b> ,	°, 00

#### For AMO-I000 Setting

JP1	CF MASTER / SLAVE Select
Part Number	1653002101
Footprint	JH2X1V-2M
Description	PIN HEADER 2*1P 180D(M)SQUARE 2.0mm DIP W/O Pb
Setting	Function
NL	SLAVE
ON	MASTER (default)



**Display Application** 

# **B.1 Introduction**

The ARK-3400 has an onboard Intel 910GMLE chipset for its PCIE controller. It supports LVDS & DVI displays and conventional analog CRT monitors with 128 MB frame buffer shared with system memory. The VGA controller can drive CRT displays with resolutions up to 1600 x 1200 @ 85 Hz and 2048 x 1536 @ 75 Hz and support 24/48 bits LVDS display mode up to UXGA panel resolution with frequency range from 25 MHz to 112 MHz.

Phoenix – AwardBIOS CMOS Setup Utility Advanced Chipset Features		
CAS Latency Time	[Auto] 🔺 Item Help	
DRAM RAS# Precharg Precharge dealu (1	le [Auto] Menu Level ► RASI [Auto]	
System Memory Fre SLP_S4# Assertion	Boot Display	
System BIOS Cache Video BIOS Cache	CRT [ ]	
Memory Hole At 15 ▶ PCI Express Root	DUI [ ] CRT+DUI [ ]	
** UGA Setting **	CRT+LFP L J	
PEG Force X1		
DUMT Mode DUMT_FIXED_Memory	tl:Move FNTFR:Accent FSC:About	
Panel Type Boot Display		
↑↓→+:Move Enter:Select +/-/PD:Value F10:Save ESC:Exit F1:General Help F5:Previous Values F7: Optimized Defaults		

Figure B.1 BIOS VGA setting

# B.2 LVDS

Low-voltage differential signaling, or LVDS, is an electrical signaling system that can run at very high speeds over inexpensive twisted-pair copper cables. It was introduced in 1994, and has since become very popular in computers, where it forms part of very high-speed networks and computer buses.

The ARK-3400 support 24/48 bits LVDS display mode up to UXGA panel resolution with frequency range from 25-MHz to 112-MHz. Refer to Chapter 3 "BIOS Operation" to find out how to change this setting. The default setting of "Boot Display" is "CRT".

# **B.3 Dual Display**

A multiple monitor setup increases the net display area of a system and can be an inexpensive way of improving computer usage. Resulting display area after upgrading to a multi-monitor configuration is limited by the size, resolution and number of monitors. The monitors used for multi-monitor can be different types (CRT+LFP or CRT+DVI) and sizes. The operating system manages the monitors' resolutions independently.

## **B.3.1 Display modes**

#### Clone mode

Initially on PCs, the multiple output interface was designed to display the same image on all output interfaces (sometimes referred to as mirroring or cloning). This reflected the fact that these video cards were originally used in presentations where the user typically had his or her face to the audience with a duplicate of the projected image available to the presenter.
#### Extended mode

In "extended" mode, additional desktop area is created on additional monitors. Each monitor can use different settings (resolution, color, refresh rate). Macintosh computers have supported the "extended desktop" concept since the late 1980s, increasing the platform's utility for professional media and software developers such as graphic designers, video editors, and game developers.

The concept was further developed by PC manufacturers and led to the "extended" or "independent displays" mode and the "spanning" or "stretched" display mode. In both of these modes, display devices are positioned next to each other in order to create the illusion that the two displays are logically contiguous.

# **B.4 Display Resolution Setting**

The ARK-3400 can drive CRT displays with resolutions up to 1600 x 1200 @ 85 Hz and 2048 x 1536 @ 75 Hz and support 24/48 bits LVDS display mode up to UXGA panel resolution with frequency range from 25 MHz to 112 MHz.

ARK-3400 User Manual



**Application Notes** 

## C.1 RS-485 Auto Flow Control

The COM1 & COM2 port connector located on the rear face plate of ARK-3400 unit can be configured to operate in RS-232, RS-422 or RS-485 mode by jumpers.

Phoenix – AwardBIOS CMOS Setup Utility SuperIO Device					
Onboard Serial Port 1	[3F8]		Item Help		
Serial Port 1 Use IAU SP 1 AutoFlow Control Omboard Serial Port 2 Serial Port 2 Use IRQ SP 2 AutoFlow Control Onboard Serial Port 3 Serial Port 3 Use IRQ Onboard Serial Port 4 Serial Port 4 Use IRQ Onboard Parallel Port Parallel Port Mode ECP Mode Use DMA	[Disabled] [3E8] [1RQ4] [Disabled] [2F8] [1RQ5] [2E8] [1RQ5] [378/1RQ7] [Standard] [3]		Menu Level	**	
↑↓→+:Move Enter:Select +/-/PU/PD:Value F10 F5:Previous Values F7			):Save ESC:Exit F1:General Help 7: Optimized Defaults		

Figure C.1 BIOS COM port setting

#### C.1.1 Flow control, introduction

Consider the situation where someone is helping you harvest apples from a tree. Your helper climbs up the tree and throws all the apples down to you. You have to put them in buckets. In the normal situation, you can easily catch all the apples, but when one bucket is full and it has to be replaced by an empty one, this action takes more time than is available between two apples thrown by your helper.

Two different things can occur. Your helper stops until the new bucket is in position, or some apples are damaged because they fall on the (rock hard, as it happens) ground in the small period you are not able to catch them.

You would probably prefer the first method where your helper stops for a small period. To achieve this, there will be some communication, eye-contact, a yell, or something like that to stop him/her from throwing new apples. How simple, but is it always this simple? Consider the situation where one computer device sends information to another using a serial connection. Now and then, the receiver needs to do some other actions, to write the contents of its buffers to disk for example. In this period of time no new information can be received. Some communication back to the sender is needed to stop the flow of bytes on the line. A method must be present to tell the sender to pause. To do this, both software and hardware protocols have been defined.

#### C.1.2 Software flow control

Both software and hardware flow control need software to perform the handshaking task. This makes the term software flow control somewhat misleading. What is meant is that with hardware flow control, additional lines are present in the communication cable which signal handshaking conditions. With software flow control, which is also known under the name XON-XOFF flow control, bytes are sent to the sender using the standard communication lines.

Using hardware flow control implies, that more lines must be present between the sender and the receiver, leading to a thicker and more expensive cable. Therefore, software flow control is a good alternative if it is not needed to gain maximum performance in communications. Software flow control makes use of the data channel

between the two devices which reduces the bandwidth. The reduction of bandwidth is in most cases however not so astonishing that it is a reason to not use it.

Two bytes have been predefined in the ASCII character set to be used with software flow control. These bytes are named XOFF and XON, because they can stop and restart transmitting. The byte value of XOFF is 19, it can be simulated by pressing Ctrl-S on the keyboard. XON has the value 17 assigned which is equivalent to Ctrl-Q.

Using software flow control is easy. If sending of characters must be postponed, the character XOFF is sent on the line, to restart the communication again XON is used. Sending the XOFF character only stops the communication in the direction of the device which issued the XOFF.

This method has a few disadvantages. One is already discussed: using bytes on the communication channel takes up some bandwidth. One other reason is more severe. Handshaking is mostly used to prevent an overrun of the receiver buffer, the buffer in memory used to store the recently received bytes. If an overrun occurs, this affects the way new incoming characters on the communication channel are handled. In the worst case where software has been designed badly, these characters are thrown away without checking them. If such a character is XOFF or XON, the flow of communication can be severely damaged. The sender will continuously supply new information if the XOFF is lost, or never send new information if no XON was received.

This also holds for communication lines where signal quality is bad. What happens if the XOFF or XON message is not received clearly because of noise on the line? Special precaution is also necessary that the information sent does not contain the XON or XOFF characters as information bytes.

Therefore, serial communication using software flow control is only acceptable when communication speeds are not too high, and the probability that buffer overruns or data damage occur are minimal.

#### C.1.3 Hardware flow control

Hardware flow control is superior compared to software flow control using the XON and XOFF characters. The main problem is, that an extra investment is needed. Extra lines are necessary in the communication cable to carry the handshaking information.

Hardware flow control is sometimes referred to as RTS / CTS flow control. This term mentions the extra input and outputs used on the serial device to perform this type of handshaking. RTS / CTS in its original outlook is used for handshaking between a computer and a device connected to it such as a modem.

First, the computer sets its RTS line to signal the device that some information is present. The device checks if there is room to receive the information and if so, it sets the CTS line to start the transfer. When using a null modem connection, this is somewhat different. There are two ways to handle this type of handshaking in that sitiuation.

One is, where the RTS of each side is connected with the CTS side of the other. In that way, the communication protocol differs somewhat from the original one. The RTS output of computer A signals computer B that A is capable of receiving information, rather than a request for sending information as in the original configuration. This type of communication can be performed with a null modem cable for full hand-shaking. Although using this cable is not completely compatible with the original way hardware flow control was designed, if software is properly designed for it, it can achieve the highest possible speed because no overhead is present for requesting on the RTS line and answering on the CTS line.

In the second situation of null modem communication with hardware flow control, the software side looks quite similar to the original use of the handshaking lines. The CTS and RTS lines of one device are connected directly to each other. This means,

that the request to send query answers itself. As soon as the RTS output is set, the CTS input will detect a high logical value indicating that sending of information is allowed. This implies, that information will always be sent as soon as sending is requested by a device if no further checking is present. To prevent this from happening, two other pins on the connector are used, the data set ready DSR and the data terminal ready DTR. These two lines indicate if the device attached is working properly and willing to accept data. When these lines are cross-connected (as in most null modem cables) flow control can be performed using these lines. A DTR output is set, if that computer accepts incomming characters.

#### C.1.4 How to implement

Implementing proper flow control can give some headaches. The main problems are the numerous ways it can be done and especially for null modem connections, the lack of a standard way of doing. The best way to implement rigid flow control in your software is to use preprogrammed routines from a reliable source. The problems involved in the own development of communication routines is often not worth the effort compared to the relative low prices of professional communication libraries. A good library is the COMM-DRV/Lib from Willies Computer Software Co. This library supports all versions of Windows and MS-DOS. XModem, YModem and ZModem file transfer routines are provided and all source code is included. Includes also Modem handling and string handling routines.

### C.2 WOL Setting

#### C.2.1 Introduction

Wake on LAN (WOL, sometimes WoL) is an Ethernet computer networking standard that allows a computer to be turned on or woken up remotely by a network message.

#### C.2.2 System requirements - PC Compatible

Wake on LAN (WoL) support is implemented on the motherboard of a computer. Most modern motherboards with an embedded Ethernet controller support WoL without the need for an external cable. Older motherboards must have a WAKEUP-LINK header onboard and connected to the network card via a special 3-pin cable; however, systems supporting the PCI 2.2 standard coupled with a PCI 2.2 compliant network adapter typically do not require a WoL cable as the required standby power is relayed through the PCI bus.

PCI version 2.2 has PME (Power Management Events). What this means is that PCI cards can send and receive PME via the PCI socket directly, without the need for a WOL cable.

Laptops powered by the Intel 3945 chipset or newer (with explicit BIOS support) allow waking up the machine using wireless (802.11 protocol). This is called Wake on Wireless LAN (WoWLAN).

Wake on LAN must be enabled in the Power Management section of the motherboard's BIOS. It may also be necessary to configure the computer to reserve power for the network card when the system is shutdown.

In addition, in order to get WoL to work it is sometimes required to enable this feature on the card. This can be done in Microsoft Windows from the properties of the network card in the device manager, on the "Power Management" tab. Check "Allow this device to bring the computer out of standby" and then "Only allow management stations to bring the computer out of standby" to make sure it does not wake up on all network activity.

### C.2.3 How it works

Wake-on-LAN is not restricted to LAN (Local area network) traffic.

The general process of waking a computer up remotely over a network connection can be explained thusly:

The target computer is shut down (Sleeping, Hibernating or Soft Off, i.e. ACPI state G1 or G2), with power reserved for the network card. The network card listens for a specific packet, called the "Magic Packet." The Magic Packet is broadcast on the broadcast address for that particular subnet (or an entire LAN, though this requires special hardware and/or configuration). When the listening computer receives this packet, the network card checks the packet for the correct information. If the Magic Packet is valid, the network card turns on the computer to full power and boots the operating system.

The magic packet is sent on the data link or OSI-2 layer and broadcast to all NICs (within the network of the broadcast address). Therefore, it does not matter whether the remote host has a fixed or dynamic IP-address (OSI-3 layer).

In order for Wake on LAN to work, parts of the network interface need to stay on. This increases the standby power used by the computer. If Wake on LAN is not needed, turning it off may reduce power consumption while the computer is off but still plugged in.

#### C.2.4 Magic Packet

The Magic Packet is a broadcast frame containing anywhere within its payload 6 bytes of ones (resulting in hexadecimal FF FF FF FF FF FF) followed by sixteen repetitions of the target computer's MAC address.

Since the Magic Packet is only scanned for the string above, and not actually parsed by a full protocol stack, it may be sent as a broadcast packet of any network- and transport-layer protocol. It is typically sent as a UDP datagram to port 0, 7 or 9, or, in former times, as an IPX packet.

ARK-3400 User Manual



Watchdog Timer

## **D.1 Watchdog Timer**

The SCH3114 Runtime base I/O address is 800h Setting WatchDog time value location at offset 66h If set value "0", it is mean disable WatchDog function. Superio\_GPIO\_Port = 800h mov dx,Superio\_GPIO\_Port + 66h mov al,00h out dx.al .model small .486p .stack 256 .data SCH3114\_IO EQU 800h .code org 100h .STARTup ;47H ;enable WDT function bit [3:2]=11 mov dx,SCH3114\_IO + 47h mov al,0ch out dx.al :65H ;bit [1:0]=Reserved ;bit [6:2]Reserve=00000 ;bit [7] WDT time-out Value Units Select ;Minutes=0 (default) Seconds=1 mov dx,SCH3114\_IO + 65h ; mov al,080h out dx,al :66H :WDT timer time-out value ;bit[7:0]=0~255 mov dx,SCH3114\_IO + 66h mov al.01h



Programming GPIO

## E.1 Programming GPIO

Advantech provides SUSI (Secure & Unified Smart Interface) API for customers. It is a set of user-friendly, intelligent and integrated application programming interfaces, which shortens development time, enhances security and offers add-on value for Advantech platform users. SUSI makes applications easier and simpler to build and operate. For the detailed GPIO register, please refer to below contents.

## E.2 GPIO Programming

```
For DOS GPIO control is through INT 15 Hook
In windows XP system please use SUSI
Below is an example of how to call sub routine °×Get Number of GPIO group°±
_____
mov ax,5e87h
mov bh,00h
int 15h
Detail information of INT 15 sub routine £1/2
; Get Number of GPIO group
; one group mean 8 gpio pins (one GPIO Chip)
; Input:
; ax=5E87h
; bh=00h
: output:
; ax=5E78 ; function success, other value means function fail
; cl= n group of gpio
; Get GPIO Config
; Input:
; ax=5E87h
: bh=01h
; cl= n ; n means which group of GPIO you want to get
: output:
; ax=5E78 ; function success, other value means function fail
; bl= the n group of gpio config
; bit 0 = \text{gpio } 0, 0 \Rightarrow \text{output pin}; 1 \Rightarrow \text{input pin}
; bit 1 = gpio 1, 0 \Rightarrow output pin; 1 \Rightarrow input pin
; .....
; bit 7 = gpio 7, 0 => output pin; 1 => input pin
; Set GPIO Config
; Input:
; ax=5E87h
```

```
; bh=02h
; cl= n ; n means which group of GPIO you want to set
; bl= the n group of gpio config
; bit 0 = \text{gpio } 0, 0 \Rightarrow \text{output pin}; 1 \Rightarrow \text{input pin}
; bit 1 = \text{gpio } 1, 0 => \text{output pin}; 1 => \text{input pin}
; .....
; bit 7 = gpio 7, 0 => output pin; 1 => input pin
: output:
; ax=5E78 ; function success, other value means function fail
; Get GPIO status
; Input:
; ax=5E87h
: bh=03h
; cl= n ; n means which group of GPIO you want to get
; output:
; ax=5E78 ; function success, other value means function fail
; bl= the n group of gpio status
; bit 0 =  gpio 0, 0 => Low; 1 => High
; bit 1 = gpio 1 , 0 => Low; 1 => High
; .....
; bit 7 = gpio 7 , 0 => Low; 1 => High
; Set GPIO status
: Input:
; ax=5E87h
; bh=04h
; cl= n ; n means which group of GPIO you want to set
; bl= the n group of gpio status
; bit 0 = gpio 0 , 0 => Low; 1 => High
; bit 1 = gpio 1 , 0 => Low; 1 => High
; .....
; bit 7 = gpio 7 , 0 => Low; 1 => High
: output:
; ax=5E78 ; function success, other value means function fail
```





### www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, electronic, photocopying, recording or otherwise, without prior written permission of the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2009



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



#### Как с нами связаться

**Телефон:** 8 (812) 309 58 32 (многоканальный) **Факс:** 8 (812) 320-02-42 **Электронная почта:** <u>org@eplast1.ru</u> **Адрес:** 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.