

S1C33 Family In-Circuit Debugger S5U1C33001H1400 MANUAL

SEIKO EPSON CORPORATION

Evaluation board/kit and Development tool important notice

- 1. This evaluation board/kit or development tool is designed for use for engineering evaluation, demonstration, or development purposes only. Do not use it for other purpose. It is not intended to meet the requirement of design for finished product.
- 2. This evaluation board/kit or development tool is intended for use by an electronics engineer, and it is not the product for consumer. The user should use this goods properly and safely. Seiko Epson dose not assume any responsibility and liability of any kind of damage and/or fire coursed by usage of it. User should cease to use it when any abnormal issue occurs even during proper and safe use.
- 3. The part used for this evaluation board/kit or development tool is changed without any notice.

NOTICE

No part of this material may be reproduced or duplicated in any form or by any means without the written permission of Seiko Epson. Seiko Epson reserves the right to make changes to this material without notice. Seiko Epson does not assume any liability of any kind arising out of any inaccuracies contained in this material or due to its application or use in any product or circuit and, further, there is no representation that this material is applicable to products requiring high level reliability, such as, medical products. Moreover, no license to any intellectual property rights is granted by implication or otherwise, and there is no representation or warranty that anything made in accordance with this material will be free from any patent or copyright infringement of a third party. When exporting the products or technology described in this material, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You are requested not to use, to resell, to export and/or to otherwise dispose of the products (and any technical information furnished, if any) for the development and/or manufacture of weapon of mass destruction or for other military purposes.

All brands or product names mentioned herein are trademarks and/or registered trademarks of their respective companies.

©SEIKO EPSON CORPORATION 2012, All rights reserved.

Table of Contents

1. GLOS	SSARY1
2. OVEF	RVIEW
2.1 F	Features
2.2 (Operating environment
3. COMI	PONENTS INCLUDED WITH PACKAGE
4. NAME	E AND FUNCTION OF EACH PART
4.1 L	_eft-side panel
4.1.1	1 10-pin connector for connecting to target systems
4.1.2	2 30-pin connector (<i>not provided</i>) for connecting to target systems
4.1.3	3 4-pin connector for flash programmer power supply
4.1.4	4 Regarding the monitor pins 10
4.2 F	Right-side panel
4.2.1	1 DIP switch
4.2.2	2 RESET/START switch 14
4.2.3	3 USB connector
4.3	Top panel
5. CON	NECTION
5.1 (Connecting the S5U1C33001H1400 and the host computer
5.1.1	1 Connecting the USB Cable
5.1.2	2 USB Driver Installation Procedure
5.2 (Connecting the target system
5.3 (Connector for flash programmer power supply22
5.3.1	1 Target system reset signal output (TARGET RST OUT) 22
5.3.2	2 Target voltage input (TARGET VCC IN) 22
5.3.3	3 Flash programming voltage output (FLASH VCC OUT) 23
6. STAR	RT-UP METHOD (POWER-ON SEQUENCE)
7. ICD N	10DE
7.1 I	CD mode setting

7.2	Invok	ing ICD mode	26
7.3	Debu	gger start-up	27
7.4	Conn	ection test	27
8. FL	ASH PI	ROGRAMMER MODE	. 28
8.1	Prepa	aring for flash programming	28
8.2	Flash	programmer mode operating method	29
9. FIF	RMWAF	RE UPDATE PROCEDURE	. 31
10. P	RECAL	JTIONS	32
10.1	1 Restr	ictions on debugging	32
1	0.1.1	Operation of the internal peripheral circuits	32
1	0.1.2	Interrupts when the target program is not running	32
1	0.1.3	Interrupts when the target program is executed in a single step	32
1	0.1.4	Break functions	32
1	0.1.5	Trace function	33
1	0.1.6	Counts of the execution counter	.33
10	0.1.7	Reserved areas in the internal peripheral circuits (C33 STD/Mini core)	34
10	0.1.8	Operating clock of the S5U1C33001H (C33 STD/Mini core)	.34
10	0.1.9	Area 2 of S1C33xxx (C33 STD/Mini/ADV core)	.34
1(0.1.10	Concurrent use of the S5U1C330M2S debug monitor	.34
10	0.1.11	Reset sequence	35
1(0.1.12	Break functions when a reset request is accepted	35
10	0.1.13	I/O memory dump by the S5U1C33001H	35
1(0.1.14	Parameter file	35
10	0.1.15	Models with cache memory embedded	36
1(0.1.16	Models with MMU embedded	.36
10.2	2 Differ	ences from the actual IC	37
10	0.2.1	Register initialization	.37
10.3	3 Usag	e precautions	38
10	0.3.1	Connecting and disconnecting equipment	38
10	0.3.2	Powering on/off	. 38
1	0.3.3	Connecting the target system	. 38

10.3.4	Operation of the S5U1C33001H system	38
10.3.5	Wiring between the S1C33xxx chip and target connector	39
10.3.6	Reset request	39
10.3.7	Notes on target system power supply	39
10.3.8	Notes on S5U1C33001H power supply	40
10.3.9	Core Sync Simple Logic Analyzer Function	40
10.4 Imple	ementation of the PC trace function	41
10.5 Imple	ementation of the bus trace function	41
11. TROUBL	ESHOOTING	42
12. SPECIFI	CATIONS	43

1. GLOSSARY

S5U1C33001H1400 (ICD33V6.0)

ICD mode	Flash programmer mode
This mode is used to debug the target system. Debugging requires both a PC and the debugger (gdb. exe included in the S5U1C33001C: C Compiler Package for S1C33 Family).	This mode is used to write programs to the target system without a PC. Before writing a program to the target system, you must load the program to the S5U1C33001H1400 (ICD33V6.0) in ICD mode.

Debugger, gdb.exe (included in the S5U1C33001C: C Compiler Package for S1C33 Family)

Simulator (SIM) mode	ICD6 mode
This mode simulates the execution of the target program on	This mode performs debugging using the
a PC memory. This mode does not require any other tool.	S5U1C33001H1400 (ICD33V6.0) or ICD board. The
However, this mode cannot execute ICD-dependent	program is executed on the target board. To debug
functions	these products, use this debugger in ICD6 mode

Target (S1C33xxx)

Normal mode	Debug mode
Ordinary mode in which the target system executes a user	In this mode, the target system accepts control by the
program.	debugger (gdb.exe).
The mode changes to debug mode under the following	This mode permits various debugging operations,
conditions:	including display and rewriting of data in registers and
• When the break condition set by the debugger (gdb.exe)	memory.
is met	This mode is activated when the S5U1C33001H1400
When the user presses the Break button on the gdb	(ICD33V6.0) is connected and the power-on sequence
screen while the debugger (gdb.exe) is connected	is executed.
• When a Low level is input to the target system DSIO pin	
 When the CPU executes a brk command 	

2. OVERVIEW

The S5U1C33001H1400 (In-Circuit Debugger for the S1C33 Family) is a hardware tool (emulator) that allows software to be efficiently developed for the S1C33 Family of 32-bit Single-Chip Microcomputers. It provides a software development environment by communicating with the S1C33xxx chip.

This manual primarily explains how to use the S5U1C33001H1400. For details on the debugger (gdb.exe) functions and commands, refer to the "Debugger" section in the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)". The figure below shows an external view of the S5U1C33001H.



Fig. 1 S5U1C33001H1400 external view

Note: Do not open the case as it may cause a malfunction.



2.1 Features

•	C33 cores supported	C33 STD core C33 Mini core C33 PE core C33 ADV core
•	Interface with the host PC	USB 1.1
•	Maximum data download speed	About 65KB/s (Approx. 50 KB/s at 20 MHz)*1
•	Mode supported by debugger	ICD6 mode
•	Program break function	PC break function Data break function Forced break function External forced break function (BRK IN) Area break function Bus break function (logical or physical address is selectable) Elapsed-time break function
•	Trace function	 Normal PC trace function / normal bus trace function → (1 Mclk after a go command or 1 Mclk before a break command can be traced) → (Allows selection of logical or physical address for bus trace) Area PC trace function / area bus trace function → Trace of area between trace trigger 1 and trace trigger 2 only → 1 Mclk can be traced → Allows selection of logical or physical address for bus trace Bus break trigger trace function TRC IN pin input signal trace function
•	Measurement of the target program execution	on time Measurement range of 3 us to 6515 hours
•	Single-unit flash programmer function	Provided
•	Firmware update function	Provided
•	Clock frequency for communications with ta	arget system

4 kHz to 120 MHz

2. OVERVIEW

٠

- Power supply for flash programmer Provided (fixed at 7.0 V)
- Reset signal output to target system
 Provided
 - Supported system I/O voltage 3.3 V, 1.8 V, input voltage (1.0 to 5.0 V) from target system
- Connector for target system connection 4-pin, 10-pin, 30-pin *2
- Connector for flash programmer power supply 4-pin
- *1 Frequency when I/O voltage = 3.3 V. The upper-limit frequency may be lower than the specification value in certain cases, depending on ambient noise, temperature conditions, product variations, etc.
- *2 The product package does not include a 30-pin cable connector. Please contact us if you need this cable connector.

Model	S5U1C33000H	S5U1C33001H		
Function	330103300011	Ver. 3.0	Ver. 4.0 Ver. 4.1	Ver. 6.0
C33 cores supported	C33 STD core C33 Mini core	C33 STD core C33 Mini core C33 PE core *5	C33 STD core C33 Mini core C33 PE core C33 ADV core	C33 STD core C33 Mini core C33 PE core C33 ADV core
Interface with the host PC	Serial and parallel I/F	USB 1.1	USB 1.1	USB 1.1
Data download speed (maximum rate: DCLK = 40 MHz)	Serial I/F: Approx. 8KB/s Parallel I/F: Approx. 30KB/s	About 65KB/s (About 50KB/s at 20 MHz)	About 65KB/s (About 50KB/s at 20 MHz) *1	About 65KB/s (About 50KB/s at 20 MHz) *1
Clock frequency to communicate with the target	1 MHz to 40 MHz	1 MHz to 40 MHz	1 MHz to 40 MHz *3	4 MHz to 40 MHz
Core clock frequency for using the trace function	1 MHz to 60 MHz (3.3 V) *1 (10-pin cable)	1 MHz to 60 MHz (3.3 V) (10-pin cable)	1 MHz to 120 MHz (3.3 V) *2, *3 (10-pin cable, or 30-pin coaxial cable)	4 MHz to 120 MHz (3.3 V) *2, *3, *6 (10-pin cable, or 30-pin coaxial cable)
Maximum trace capacity	128K clock cycles	1M clock cycles	1M clock cycles	1M clock cycles
Single-unit flash programmer function	-	Available	Available	Available
Firmware update function	-	-	Available	Available
Mode supported by debugger	ICD2 mode	ICD3 mode	ICD3 mode	ICD6 mode
Bus trace function	-	-	Available	Available *6
Bus break trigger trace function	-	-	Available	Available *6
TRC IN pin input signal trace function	-	-	Available	Available
User logic signal trace function *4	-	-	Available	Available
Target reset signal output	-	-	Available	Available
Target system I/O interface voltage	3.3 V	3.3 V	3.3 V and 1.8 V	3.3 V and 1.8 V, or input voltage (1.0 to 5.0 V) from target system
RESET/START switch	-	Available	Available	Available
DIP switch	4 bits	8 bits	8 bits	10 bits
LEDs for flash programmer	-	Available	Available	Available
Target system interface connector	10 pins	10 pins	10 pins, 30 pins	10 pins, 30 pins *6
Target system interface method	4 pins, 10 pins	4 pins, 10 pins	4 pins, 10 pins, 30 pins	4 pins, 10 pins, 30 pins *6
Target power supply connector	-	-	6 pins	-
Connector for flash programmer power supply	-	-	-	4 pins

Table 1	ICD models and	differences
---------	----------------	-------------

*1 Indicates the frequency range for 3.3-V I/O. The upper-limit frequency may be lowered by environment noise, temperature condition, S1C33 model, unevenness in quality, etc. Note: In the model with the C33 STD or Mini core embedded, the maximum CPU core clock frequency is 60 MHz but the maximum BCU (bus) clock frequency is 40 MHz. When operating the CPU with a clock higher than 40 MHz, the BCU clock must be setup to 1/2 CPU core clock (#X2SPD = 0).

*2 The maximum frequency may be half or less of the described value when the I/O voltage is 1.8 V.

- *3 Supports 32 kHz by firmware update.
- *4 Available only when the S1C33 model that supports the user logic signal trace function is used.
- *5 Supports by firmware update.
- *6 The product does not include a 30-pin cable for connecting to target systems or a connector for this cable. Please contact us if you need a 30-pin cable.

Core	C33 STDMini	C33 PE	C33 ADV
DCLK while the program is halted	= Bus clock	= Core clock x set value	= Core clock x set value
DCLK while the program is being executed	= Core clock	= Core clock	= Core clock
PC trace method	Level 1	Level 1	Level 2
Switching the DCLK-core clock ratio (DCLK while the program is halted)	-	0	0
Address setup for the debug unit	-	0	-
Area break function	-	-	0
Bus break function	-	-	0
Bus break trigger trace function	-	-	0
TRC IN pin input signal trace function	-	-	0
User logic signal trace function *7	-	-	0
Use of MMU in debug mode	-	-	0

 Table 2
 Correspondence between C33 cores and debug functions

*7 Available only in S1C33 models that support the user logic signal trace function.

Except for the PC trace, Level 2 is upwardly compatible with Level 1 and realizes higher analytical accuracy than Level 1. Functions not listed in the above table can be used regardless of the core model.

2.2 Operating environment

As the host computer, the S5U1C33001H1400 uses a PC with a USB port (USB 1.1) available. Windows 2000 or Windows XP is recommended for the OS.

3. COMPONENTS INCLUDED WITH PACKAGE

The following shows the components included with the package:

(1)	S5U1C33001H1400 (main unit)	1
(2)	USB cable (mini B)	1
(3)	Target system interface cable (10-4 pin)	1
(4)	Target system interface cable (10-10 pin)	1
(5)	Target system power supply cable (4-4 pin)	1
(6)	Target system interface connectors (10-pin)	1
(7)	Target system interface connectors (4-pin)	1
(8)	Target system power supply connectors (4-pin)	1
(9)	User registration card	. English/Japanese, 1 each
(10)	Warranty card	. English/Japanese, 1 each
(11)	Usage precautions	. English/Japanese, 1 each
(12)	Manual download guide	. English/Japanese, 1 each
The	items specified below are not included with the package. These items must be pr	repared separately.

(13) S5U1C33001H1400 User Manual (ICD33V6.0)

(PDF is downloadable from this PDF document and the SEIKO EPSON HP)

(14) Debugger (gdb.exe) for the S1C33 Family (included in the S1C33 Family C Compiler Package)

(15) Debugger manual for the S1C33 Family (included in the S1C33 Family C Compiler Package)



Fig. 2 Package components

4. NAME AND FUNCTION OF EACH PART

The following shows an external view of the S5U1C33001H1400's operating section and the name of each part.

4.1 Left-side panel



Fig. 3 Left-side panel

4.1.1 10-pin connector for connecting to target systems

This connector is used to connect to the target system using a 10-pin cable or 10-pin-4-pin cable.

4.1.2 30-pin connector (*not provided*) for connecting to target systems

This connector is used to connect to the target system using a 30-pin cable.

- Note: This connector is not provided with the debugger unit. Please contact us if you need this cable.
- Note: Only one of the 10-pin connector for connecting to target systems and 30-pin connector for connecting to target systems may be used at any given time.

4.1.3 4-pin connector for flash programmer power supply

This connector is used to output a reset signal to the target system or to supply power (note) for flash programming. When the interface for debug signals requires a voltage level for the target system, this connector is used to input the operating voltage from the target system. For information on the connector pin configuration and connection method, refer to "Connector for flash programmer power supply."

Note: The S5U1C1700H incorporates a 7-V, 200-mA power supply for flash programming. However, use of this power supply may not be possible with certain S1C processors. If the technical manual for the target S1C processor does not specifically mention this power supply, damage may occur in the chip due to overvoltage. To prevent this problem, avoid using this voltage (do not set the DIP SW8 to ON) if this voltage is not supported by the target S1C processor. Keep this pin open when implementing a connection terminal on the target board.

4.1.4 Regarding the monitor pins

• GND pin (black (left side in the above diagram))

To monitor the signals output from the above pins, connect the GND of a measuring instrument such as an oscilloscope to this pin. If the ground level between the S5U1C33001H and the target system is unstable (particularly when the 4-pin cable is used), this pin can be used to stabilize the ground level.

• BRK IN pin (red)

If a low-level signal is input to this pin when the target program is being executed, the target program execution is suspended. After a low level is input to the BRK IN terminal, a break will occur after a few instructions have been executed.

• TRC IN pin (white)

This pin inputs an external trace signal. The input signal can also be traced when the bus trace is performed.

• TRG OUT pin (light blue)

The TRG OUT pin outputs trace trigger signals indicating the start and end of the trace. To perform an area trace with the S5U1C33001H, set two trigger points: the start address and end address of the trace area. When the execution address of the program corresponds to the set trace trigger point, the TRG OUT pin outputs a High-level signal. It also outputs a High-level signal when target program execution is suspended. For a discussion of how to set the trace function, see the "Debugger" section in the S5U1C33001C Manual (C Compiler Package for S1C33 Family). The output timing is shown below. To generate trace trigger signals, you must run the program for trace trigger point 1 and point 2, in that order. Shown below are states in which trace triggers are and are not generated.



Fig. 4 Examples of TRG OUT output timing

• EMUOUT pin (green)

This pin outputs a low level when the EMU/ERASE LED is lit (that is, when the program is being executed) and outputs the 5 V level when that LCD is off (during a break). This signal can be used as the protect signal for the S5U1C33xxxM emulation memory.

• TRCFULL pin (blue (right side in the above diagram))

This is the trace full state output pin. This pin outputs a high level when the trace memory becomes full.

4.2 Right-side panel





4.2.1 DIP switch

Note: After operating the DIP switches, press the RESET/START switch to apply the settings.

• Selecting target CPU core (SW1)

Table 3-1 DIP SW1 setting

SW1	Setting
OPEN	C33
ON	C17 (Not supported)

• Selecting ICD mode/flash programmer mode (SW2, SW3)

Table 3-2	DIP SW2 and SW3 settings
	Dir offe and offe settinge

SW2	SW3	Setting
OPEN	OPEN	ICD mode
ON	OPEN	Flash programmer mode Erase \rightarrow Write
OPEN	ON	Flash programmer mode Verify
ON	ON	Flash mode Erase \rightarrow Write \rightarrow Verify

ICD mode: Mode for executing the debug command from the debugger in a PC (see the relevant section) Flash programmer mode: Mode for operating the S5U1C33001H independently as a flash programmer (see relevant section)

• Selecting DSIO signal (SW4, SW5)

Table 3-3 DIP SW4 and SW5 settings

SW4	SW5	Setting
OPEN	OPEN	3.3 V (default)
OPEN	ON	1.8 V
ON	OPEN	Target system input voltage (1.0 to 5.0 V)
ON	ON	Target system input voltage (1.0 to 5.0 V)

Target system operating voltage applied to Pin No. 4 of the connector for flash programmer power supply.

• Selecting connection test (SW6)

Table 3-4 DIP SW6 setting

SW6	Setting
OPEN	Connection test disabled (default)
ON	Connection test enabled

Connection test: A communication check test is performed at the time of debugger invocation.

• Selecting firmware update mode (SW7)

Table 3-5 DIP SW7 setting

SW7	Setting
OPEN	Off (default)
ON	On

Turning this DIP switch ON enables connections between the S5U1C33001H and debugger without a target system. For a discussion of how to update the firmware, refer to "Firmware Update."

• Selecting flash programming voltage output (SW8)

Table 3-6 DIP SW8 setting

SW8	Setting
OPEN	Off
ON	On

Note: The S5U1C1700H incorporates a 7-V, 200-mA power supply for flash programming. However, use of this power supply may not be possible with certain S1C processors. If the technical manual for the target S1C processor does not specifically mention this power supply, damage may occur in the chip due to overvoltage. To prevent this problem, avoid using this voltage (do not set the DIP SW8 to ON) if this voltage is not supported by the target S1C processor.

• Selecting trace (SW9)

Table 3-7 DIP SW9 setting

SW9	Setting
OPEN	Trace disabled
ON	Trace enabled

• Option setting (SW10)

Table 3-8 DIP SW10 setting

SW10	Setting
OPEN	Unused
ON	Unused

4.2.2 RESET/START switch

< In ICD mode >

Pressing the RESET/START switch restarts the firmware and establishes an initial connection with the target S1C processor. If the target board is not connected, the firmware awaits the initial connection. If the TARGET RST OUTPUT signal from the S5U1C33001H reaches the target board, a reset signal is also output.

< In flash programmer mode >

Pressing the RESET/START switch invokes the selected flash operation function (erase, write, verify). If the LED indicates OK/ERR, the state immediately before the execution of the function will be restored.

Note: After operating the DIP switches, press the RESET/START switch to apply the settings (in ICD mode or flash programmer mode).

4.2.3 USB connector

This connector is used to connect a PC using the USB cable.

Note: A USB hub that runs solely on bus power may not provide adequate power in all cases. To supply voltage for flash programming to the target system in flash programmer mode, connect directly to the USB port of the PC or use an AC adaptor (USB 5-V output) to supply power to the USB cable.

4.3 Top panel



Fig. 6 Top panel

LED1 through LED4

The four LEDs on the top panel show the debugging or flash programming status of LED1 through LED4 on the front panel. The information provided by these LEDs in ICD mode and flash programmer mode differs.

< In ICD mode >

LED1 (CPU)

This LED indicates the target CPU selected by the DIP SW1.

- Green) C33: Product incorporating S1C33xxx or S1C33 core
- (Blue) C17: Product incorporating S1C17xxx or S1C17 core (not supported at this time)

LED2 (ICD MODE)

This LED emits a constant red light if the target system is not connected and flashes red if a proper connection cannot be achieved with the target system. The LED signals continuous blue if ICD mode is selected (DIP SW2 and SW3 set to OPEN).

(Blue) Operations in ICD mode

(In initial connection)

- (Yellow) USB is being recognized
- (Red, ON) Target system is not connected

(Red, flashing) Communication with target system cannot be achieved

LED3 (EMU)

If ICD mode is selected (DIP SW2 and SW3 set to OPEN), this LED emits a constant red light when the debugger issues a command to execute the target program, indicating that the target system is executing the target program. It also lights up when power for the target system is turned off or no target system is connected. In this case, turning on the power for the target system or properly Connecting the target system and pressing the RESET/START switch will turn off the LED. If the LED emits a constant green light, the target processor is in the debug mode.

(Red)	Power for the target system is turned off (except for initial connection)
	Target system is not connected (except for initial connection)
	Target system is running a user program
🔵 (Green)	Target S1C processor is in debug mode
• (OFF)	Other

LED4 (TRC)

This LED will emit a constant light blue light when ICD mode is selected (DIP SW2 and SW3 set to OPEN).

• (OFF)	Trace OFF
🔵 (Light blue)	Trace ON
(Yellow)	Trace ON (memory full)

Note: With firmware Ver 1.0, this LED will emit a constant light blue light even when the trace function is disabled. This issue is scheduled to be corrected in the next firmware update.

< In flash programmer mode >

LED1 (CPU)

This LED indicates the target CPU selected by the DIP SW1.

\bigcirc	(Green)	C33: Product incorporating S1C33xxx or S1C33 core
ightarrow	(Blue)	C17: Product incorporating S1C17xxx or S1C17 core (not supported at this time)

LED2 (ERASE)

This LED indicates the flash memory erase condition.

Ο	(White)	Flash memory erase is selected
Ο	(White, flashing)	Data in the flash memory is being erased
\bigcirc	(Green)	Flash memory erase has been successfully completed (OK)
	(Red)	Flash memory erase error (ERR)
(T	•••••	

(In initial connection)

- (Red, ON) Target system is not connected
- (Red, flashing) Communication with target system cannot be achieved

LED3 (WRITE)

This LED indicates the flash memory write condition.

\bigcirc	(Purple)	Flash memory write is selected
	(Purple, flashing)	Flash memory is being written
\bigcirc	(Green)	Flash memory write has been successfully completed (OK)
	(Red)	Flash memory write error (ERR)

LED3 (VERIFY)

This LED indicates the flash memory verify condition.

\bigcirc	(Yellow)	Flash memory verify is selected
\bigcirc	(Yellow, flashing)	Flash memory is being verified
\bigcirc	(Green)	Flash memory verify has been successfully completed (OK)
	(Red)	Flash memory verify error (ERR)

5. CONNECTION

5. CONNECTION

5.1 Connecting the S5U1C33001H1400 and the host computer

5.1.1 Connecting the USB Cable

The connectors at each end of the USB cable are type A (for the host computer) and Mini B type (for the S5U1C33001H). Turn on the S5U1C33001H power and connect the USB cable to the host computer. The host computer will request that the USB driver be installed. Use the procedure described in the next section to install the USB driver.

Note: The USB driver is located in the directory in which the S5U1C33001C (S1C33 Family C Compiler Package) is installed:

 $C:\ EPSON\ gnu 33\ utility\ drv_usb\ Icd 33v60.$



Fig. 7 Connecting the USB cable

5.1.2 USB Driver Installation Procedure

- (1) When the USB cable is first connected to the host computer, the hardware wizard will be displayed.
- (2) Install the USB driver by following the directions displayed by the wizard. Specify "C:\EPSON\gnu33\utility\drv_usb\Icd33v60" as the USB driver directory. The device manager will be displayed as shown below when the USB driver has been installed correctly.
- Note: When using the S5U1C33001H1400 (ICD33V6.0), use the following C compiler package: GNU33V3.1.1 (Product No. not assigned), GNU33V3.2.0 (S5U1C33001C1300) or a later C Compiler Package.





The device manager will be displayed as shown below when the USB driver has been installed correctly.



Note: If the window above is not displayed correctly, reinstall the USB driver.

5.2 Connecting the target system

Connect the target system, using the 10-pin or 4-pin cable provided with the S5U1C33001H or a 30-pin cable.(*1) Use the 10-pin-type/4-pin-type connector provided with the S5U1C33001H, a 30-pin connector[*1], or equivalent on the target system side. See the tables below for pin configurations for connectors on the target side. For each signal pin number of the S1C33xxx chip, refer to the "S1C33xxx Technical Manual" of the specific model.

*1: The product package does not include a 30-pin cable or the corresponding connector. Please contact us if you need this cable or the corresponding connector.



Fig. 8 Connecting the target system

10-pin connector		or	$\begin{array}{c} 9 \\ 10 \\ \hline \end{array} \begin{array}{c} 1 \\ 2 \\ \end{array}$	
No.	Pin name	I/O	Pin function	
1	DCLK	Ι	Clock for debugging	
2	GND	-	Power supply (GND)	
3	DSIO	I/O	Serial I/O signal for debugging	
4	GND	-	Power supply (GND)	
5	DST2	Ι	Debug status 2 signal	
6	GND	-	Power supply (GND)	
7	DST1	Ι	Debug status 1 signal	
8	GND	-	Power supply (GND)	
9	DST0	Ι	Debug status 0 signal	
10	DPCO	Ι	PC signal	

Table 4	Pin assignment of target connectors
	i in addigiment of target connectors

4-pin connector 4				
No.	Pin name	I/O	Pin function	
1	DCLK	Ι	Clock for debugging	
2	GND	-	Power supply (GND)	
3	DSIO	I/O	Serial I/O signal for debugging	
4	DST2	Ι	Debug status 2 signal	

Г

30-р	30-pin connector						30 1▼ [] {8889999999999999999999999999999999999
No.	Pin name	I/O	Pin function	No.	Pin name	I/O	Pin function
1	GND	-	Power supply (GND)	16	DST2	Ι	Bus trace status 2 signal
2	DCLK	Ι	Clock for debugging	17	DTS1	Ι	Bus trace status 1 signal
3	GND	-	Power supply (GND)	18	DTS0	Ι	Bus trace status 0 signal
4	DSIO	I/O	Serial I/O signal for debugging	19	GND	-	Power supply (GND)
5	GND	-	Power supply (GND)	20	DTD7	Ι	Bus trace data 7 signal
6	DST2	Ι	Debug status 2 signal	21	DTD6	Ι	Bus trace data 6 signal
7	GND	-	Power supply (GND)	22	DTD5	Ι	Bus trace data 5 signal
8	DST1	Ι	Debug status 1 signal	23	DTD4	Ι	Bus trace data 4 signal
9	GND	-	Power supply (GND)	24	GND	-	Power supply (GND)
10	DST0	Ι	Debug status 0 signal	25	DTD3	Ι	Bus trace data 3 signal
11	GND	-	Power supply (GND)	26	DTD2	Ι	Bus trace data 2 signal
12	DPCO	Ι	PC signal	27	DTD1	Ι	Bus trace data 1 signal
13	GND	-	Power supply (GND)	28	DTD0	Ι	Bus trace data 0 signal
14	DTS4	Ι	Bus trace status 4 signal	29	GND	-	Power supply (GND)
15	DTS3	I	Bus trace status 3 signal	30	DBT	I	Bus break trigger signal

Notes:

- The signals connected to the S5U1C33001H are very high-speed signals, so the target connector must be mounted within 5 cm from the S1C33xxx. If there is more distance between the connector and the S1C33xxx chip, the S5U1C33001H may not work properly.
- A 33 Ω resistor must be connected in series to the DSIO signal line between the connector and the S1C33xxx chip. The resistor should be placed as close to the S1C33xxx as possible.
- Be sure to use the supplied 10-pin or 4-pin, or 30-pin cable for Connecting the target system to the S5U1C33001H. Using another cable may cause a malfunction. Furthermore, do not use the 30-pin cable and 10-pin or 4-pin cable simultaneously.
- Disable the trace function of the S5U1C33001H using DIP switch 4 in the following cases:
 - when using the 4-pin cable and connector.
 - when the signals (DST0, DST1, DPCO) necessary for tracing are not connected even if the 30-pin or 10-pin cable and connector is used.
 - when the trace function is not used due to some reason even if the 30-pin or 10-pin cable and connector is used and all the signals are connected.
- The 4-pin connector does not have a projection for preventing reverse insertion. Check the cable marker of pin 1 to be sure the insertion of connector is proper when connecting it to the target system.
- The product package does not include a 30-pin cable or the corresponding connector. Please contact us if you need this cable or the corresponding connector.



Fig. 9 Connecting with 4-pin connectors

5.3 Connector for flash programmer power supply

This connector is used to output reset signals to the target system, to output voltage for flash programming, and to input target interface voltage. Debugging is possible without connecting these signals. If necessary, use the cable for flash programmer power supply provided with the S5U1C33001H to connect the target system. The pin assignment of the 4-pin connector (white) of the S5U1C33001H is shown in the table below.

Table 5 Pin assignment of the flash programmer power supply connector (white)

	No.	Pin name	I/O	Pin function
	1	FLASH VCC OUT	0	Flash programming voltage output
1234	2	GND	-	Power supply (GND)
	3	TARGET RST OUT	0	Target system reset signal output
	4 TARGET VCC IN	I	Target system voltage input	

* Note the sequence of Pin Nos. (This sequence is reversed in the connector for connecting to target systems.)

5.3.1 Target system reset signal output (TARGET RST OUT)

Pressing the RESET/START switch outputs a reset signal from the TARGET RST OUT pin to the target system.

The following circuit structure is recommended to use this reset output.



Fig. 10 Example of reset circuit

Note: High (voltage level set by DIP SW4, SW5) or Low (GND level) is output as a target reset signal.

5.3.2 Target voltage input (TARGET VCC IN)

In addition to 3.3 V and 1.8 V, the voltage (1.0 to 5.0 V) input from the target system can be used as an interface for the target system. To use this function, set the DIP SW4 to ON and apply a voltage from the target system to the TARGET VCC IN pin.

5.3.3 Flash programming voltage output (FLASH VCC OUT)

Some target S1C processors have internal flash memory that can supply the voltage (7 V) necessary for flash programming from the S5U1C33001H. The maximum current that can be provided in this way is 200 mA.

To use this output, set the DIP SW8 to ON and connect the power supply from the target system to the FLASH VCC OUT pin. Note that setting the DIPS SW8 to ON results in a constant output of 7 V from the FLASH VCC OUT pin regardless of the operation of the RESET/START switch.

Note: Refer to the relevant technical manual to determine if the target S1C processor can use this output. (To prevent overvoltage-induced damage to the S1C processor, avoid using this output if no applicable instructions are provided in the technical manual.)

6. START-UP METHOD (POWER-ON SEQUENCE)

To start up the S5U1C33001H system, follow the sequence described below:

(1) Connect the S5U1C33001H to the host computer using the USB cable.

The LED1, LED2, and LED3 operate as follows:

- LED1 (Green, ON) * In the case of C33
- LED2 (Red, ON)
- LED3 (OFF)
- (2) Turn the target system on.

The LED1, LED2, and LED3 operate as follows:

- LED1 (Green, ON) * In the case of C33
- LED2 (Blue, ON)
- LED3 (Green, ON)
- (3) Start up the debugger (gdb.exe) on the host computer in ICD mode.

To terminate the S5U1C33001H system, follow the sequence described below:

- (1') Terminate the debugger (gdb.exe) on the host computer.
- (2') Turn the target system off.
- (3') Turn the S5U1C33001H off.

Notes:

- Normally the S5U1C33001H system can work properly when the target system is turned on first and then the S5U1C33001H. However, the power-on sequence described above is recommended since the system may not work properly if the target system is in indeterminate operation or in runaway status.
- If the debugger (gdb.exe) is terminated after the S5U1C33001H is turned off, the debugger may not work properly with "Cannot open ICD33 usb driver." displayed on the screen when it is re-invoked. In this case, turn on or reset the S5U1C33001H after terminating the debugger (gdb.exe) once, and then re-invoke the debugger.

For details on how to invoke/terminate the debugger, refer to the "Debugger" section in the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)". Furthermore the debugger (gdb.exe) must be invoked after turning all the power of the system on.

Check the following if the debugger reports a target down error, which means that communication between the S5U1C33001H and the target system is not functioning.

 If the target system power is turned on after the S5U1C33001H is turned on: After the S5U1C33001H power is turned on, a forced break will be applied continuously to the target system. After the target system is turned on, the S1C33xxx chip is reset. The S1C33xxx chip enters debug mode and starts communication with the S5U1C33001H.
 If multiple power on/reset cycles occur caused by switch bounce when the target is turned on, the communication between the S5U1C33001H and the target system may be disconnected after the second reset.

Design the target system so that switch bounce does not occur and the system starts up only once. Furthermore, if the reset is applied with either the power or the oscillator in an unstable state (for example, if the reset is applied within the first few ms after the power is turned on), the S1C33xxx chip operation will also be unstable. In this case the system will not enter debug mode and communication between the S5U1C33001H and the target system will not be possible. Apply the reset only after an adequate stabilization time has elapsed.

Refer to the "S1C33xxx Technical Manual" for more information on the reset operation.

- If the S5U1C33001H is turned on after the target system power is turned on: When the S5U1C33001H is turned on, it issues a forcible break to the free-running target system. The S1C33xxx chip enters debug mode and starts communication with the S5U1C33001H. If a boot program was not loaded into ROM, the S1C33xxx chip cannot respond to the forced break since the S1C33xxx chip is in the runaway state, so communication is impossible. Load a boot program that operates correctly into boot ROM so that the target system will not be in the runaway state.
- If the initial connection operation fails

In this case, add a reset switch to the target system and start the system in the following sequence:

- (1) Turn the target system on
- (2) Hold down the reset switch on the target system and turn the S5U1C33001H on
- (3) Release the reset switch to clear the reset state.

This will allow the system to operate reliably. This is because this sequence reliably reproduces the conditions in the "If the S5U1C33001H is turned on after the target system power is turned on" item above. If it is not possible to connect, install a reset switch on the target system. We recommend adding the reset switch at the system design stage.

• RESET/WRITE switch on the S5U1C33001H

Besides turning power on and off, the S5U1C33001H can be reset using the on-board RESET/WRITE switch.

Also the RESET/WRITE switch changes the signal output from the TARGET_RESET pin in the target system power supply connector (see next section).

7. ICD MODE

ICD mode is used to debug the target system by connecting the debugger (dbg.exe) on the PC to the target system. Described below are the settings for launching the S5U1C33001H in ICD mode and corresponding procedures.

7.1 ICD mode setting

```
To launch the S5U1C33001H in ICD mode, set the DIP switches as follows:
SW2 = OPEN
SW3 = OPEN
```

7.2 Invoking ICD mode

After Connecting the target system to the host computer, start the S5U1C33001H as described below. Starting the S5U1C33001H by a different procedure may not result in a successful connection.

< When TARGET RST_OUT signal is not connected >

If the TARGET RST OUT signal is not connected to reset the target system, follow the start-up procedure described below.

- (1) Press the S5U1C33001H RESET/START switch.
 - LED1 (Green, ON) * In the case of C33
 - LED2 (Red, flashing)
 - LED3 (OFF)
 - LED4 (OFF)
- (2) Press the target system RESET switch.
 - LED1 (Green, ON) * In the case of C33
 - LED2 (Blue, ON)
 - LED3 (Green, ON)
 - LED4 (OFF) *1

If the LEDs do not light as described above, there may be a problem with the connection. Repeat the procedure from step (1).

*1: With firmware Ver 1.0, LED4 will emit a constant light blue light in step (2), even when the trace function is disabled. This issue is scheduled to be corrected in the next firmware update.

< When TARGET RST_OUT signal is connected >

If the TARGET RST OUT signal is connected to reset the target system, the S5U1C33001H automatically generates signals according to the connection procedure. You need only to press the S5U1C33001H RESET/START switch to start the S5U1C33001H.

- (1) Press the S5U1C33001H RESET/START switch.
 - LED1 (Green, ON) * In the case of C33
 - LED2 (Blue, ON)
 - LED3 (Green, ON)
 - LED4 (OFF) *1

With the LEDs in the status described above, repeat the procedure from step (1).

*1: With firmware Ver 1.0, LED4 will emit a constant light blue light in step (2), even when the trace function is disabled. This issue is scheduled to be corrected in the next firmware update.

7.3 Debugger start-up

After the aforementioned operation results in a proper connection between the S5U1C33001H and the target S1C processor, run the debugger (gdb.exe) on the PC.

To connect to the S5U1C33001H and start debugging, you must specify ICD mode using the target command.

(gdb) target icd6 usb

For a discussion of the debug command and how to use the debugger, refer to the S5U1C33001C Manual (C Compiler Package for S1C33 Family).

Note: Close the debugger before disconnecting the S5U1C33001H from the host computer.

7.4 Connection test

The S5U1C33001H can run diagnostics to confirm proper communication with the target system at the time the debugger (gdb.exe) is launched. If proper start-up is not possible by this method, perform a connection test. Use the DIP SW6 to enable or disable this function.

Skipping the connection test (default)

If the DIP SW6 is set to OPEN, the S5U1C33001H skips connection diagnostics when connecting to the target system at the time the debugger is launched.

Execution of connection test

If the DIP SW6 is set to ON, the S5U1C33001H runs the connection diagnostics of the connection to the target system at the time the debugger is launched.

8. FLASH PROGRAMMER MODE

Flash programmer mode lets the S5U1C33001H function as a flash programmer. Described below are preparations for starting up the S5U1C33001H in flash programmer mode and associated procedures.

8.1 Preparing for flash programming

The S5U1C33001H can write data, such as a program downloaded to internal flash memory, directly to the flash memory of the target system.

As described below, start by downloading to the S5U1C33001H the data you want to write to the target system's flash memory.

(1) Convert the file to be written to the target system flash memory to a Motorola S3 file.

Use objcopy.exe (included in the C Compiler Package for S1C33 Family) to perform this file conversion.

Example:

1. Converting sample.elf to Motorola S3 file

>objcopy -O srec -R .gbss --srec-forceS3 sample.elf sample.sa

2. Fill the empty addresses in sample.sa with 0xff and produce sample.saf.

(When the fill start address is 0x600000 and the target block size is 0x1000)

>moto2ff 0x600000 1000 sample.sa

- (2) Launch the S5U1C33001H in ICD mode.
- (3) Launch the debugger.
 - 1. Launching GDB

>gdb

2. Connecting the target system

(gdb) target icd6 usb

- (4) Delete any unnecessary programs or data in the S5U1C33001H with the c33 fwe command.
- (5) Use the c33 fwlp command to download the flash erase/write program to the S5U1C33001H.
 Example: Downloading data erase/write program file, writer.sa
 (when the erase routine start address is 0x14c and the write routine start address is 0x180)
 (gdb) c33 fwlp writer.sa 0x14c 0x180

(6) Use the c33 fwld (or c33 fwdc) command to download the data to be written to the target system flash memory to the S5U1C33001H. At the same time, set the erase area in flash memory.

Example: Erasing all sectors and downloading sample.saf to flash memory

(when flash start address is 0x600000)

(gdb) c33 fwld sample.saf 0 0 0x600000

(7) End the debugger.

For an in depth discussion of the debugger (dbg.exe) and objcopy.exe, refer to the S5U1C33001C Manual (C Compiler Package for S1C33 Family).

8.2 Flash programmer mode operating method

Given below is the procedure for launching the S5U1C33001H in flash programmer mode and performing flash programming.

(1) Set the DIP SW2 and SW3 based on the work to be performed.

You can select flash erase and write only, verify only, or erase \rightarrow write \rightarrow verify.

SW2	SW3	Setting
OPEN (↑)	OPEN (↑)	ICD mode (default)
ON (↓)	OPEN (↑)	Flash programmer mode Erase \rightarrow Write
OPEN (↑)	ON (↓)	Flash programmer mode Verify
ON (↓)	ON (↓)	Flash programmer mode Erase \rightarrow Write \rightarrow Verify

Table 6 DIP switch settings in flash programmer mode

(2) If the DIP switch settings were changed while power was being supplied via USB, press the RESET/START switch to set the S5U1C33001H to flash programmer mode.

If the DIP switch settings are changed when power is off, supply power by connecting the USB cable for the S5U1C33001H to the USB port of the host computer or by connecting an AC adaptor with USB 5-V output. (Flash programmer mode will run on power supplied through the USB cable. No communication occurs with the PC.) If the S5U1C33001H starts up properly, the LEDs will light up according to the selected operating mode.



- (3) Connect the target system to the S5U1C33001H for flash programming.
- (4) Press the RESET/START switch. The S5U1C33001H executes the selected flash operation. The operation currently underway is indicated by the flashing LED.

		Erase	Write	Verify
•	ERASE	(White, flashing)	_	_
•	WRITE	_	(Purple, flashing)	_
•	VERIFY	_	_	(Yellow, flashing)

(5) After the flash operation is completed, the following LED lights up to indicate successful completion of the operation or the generation of an error.

Operation completed successfully



- (6) Disconnect the target system.
- (7) Return to step (3) to proceed with the same flash operation.Return to step (1) to change the flash operation.

To end flash programming, disconnect the USB cable and set the DIP switches to ICD mode settings.

9. FIRMWARE UPDATE PROCEDURE

The S5U1C33001H has a firmware update function using the debugger (gdb.exe). The following show the procedure to update the S5U1C33001H firmware.

Note: Before the firmware can be updated, the USB driver must be installed.

- (1) Connect the S5U1C33001H with the host computer using the USB cable.
- (2) Set the S5U1C33001H DIP switches as shown below and press the RESET/START switch.
 - SW2 = OPEN

SW3 = OPEN

SW7 = ON

- (3) Invoke the debugger (gdb.exe)
 - To invoke at the command prompt: >start /w gdb -nw --c33_no_ver
 - To invoke from gwb33 Just click the [GDB] button with nothing selected.
- (4) Enter the commands shown below after the debugger starts up.

(gdb) target icd6 usb (gdb) c33 firmupdate *icd33dmt.sa*

(5) The ukpdate operation has completed when LEDs light up as follows:



(6) Set the DIP SW7 to OPEN and press the RESET/START switch to restart the S5U1C33001H. Please contact us if a problem occurs during the firmware update that renders the S5U1C33001H inoperable.

10. PRECAUTIONS

10.1 Restrictions on debugging

The debugging using the S5U1C33001H is subject to the restrictions specified below.

10.1.1 Operation of the internal peripheral circuits

The peripheral circuits of the S1C33xxx stop operating when the debugger (gdb.exe) on the host computer is ready to accept commands, that is, unless the target program is running. For this reason, the peripheral circuits do not operate in real time when the target program is executed in the single-step mode. For details on single-step execution, refer to the "Debugger" section in the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)".

10.1.2 Interrupts when the target program is not running

If an interrupt request to the C33 core is generated by the target system when the target program is not running, interrupt processing is paused. The interrupt that has been paused is serviced immediately before the target program is executed or immediately after one instruction is executed after the debugger (gdb.exe) on the host computer has directed that the target program be executed.

10.1.3 Interrupts when the target program is executed in a single step

If an interrupt request to the C33 core is generated by the target system during single-step execution of the target program, including functions and subroutines (STEP), the interrupt request is paused. During single-step execution of the target program, not including functions and subroutines (NEXT), an interrupt request received within a function or subroutine is serviced without being paused and an interrupt received in other parts of the program is paused as with the STEP command. The interrupt that has been paused is serviced immediately before the target program is executed or immediately after one instruction is executed after the debugger (gdb.exe) on the host computer has directed that the target program be executed. For details on single-step execution (STEP and NEXT), refer to the "Debugger" section in the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)".

10.1.4 Break functions

The S5U1C33001H and the debugger support multiple break functions. The timing at which a break occurs is classified into the following two categories depending on the break function.

 Break functions that suspend the target program before the instruction in which the cause of the break occurred is executed Software PC break, hardware PC break (2) Break functions that suspend the target program after several instructions are executed from the instruction in which the cause of the break occurred Data break, area break, bus break

For details on break functions, refer to the "Debugger" section in the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)".

10.1.5 Trace function

Note that the trace function in the S5U1C33001H has the following restrictions. Furthermore, refer to the technical information of the trace function ("Implementation of the PC Trace Function" and "Implementation of the Bus Trace Function").

- (1) The S5U1C33001H PC trace function can trace only instruction execution cycle information. Note that data access (read/write) information cannot be traced. When the target system uses the S1C33 model in which a C33 core that supports the bus trace function is embedded, data read/write information can be traced.
- (2) Be aware that the trace function cannot be used when it is disabled using the DIP switch. For enabling/disabling the trace function using the DIP switch, refer to "Trace function setting" in the "DIP Switches" section.
- (3) There are certain functional limitations to the PC trace function that are due to the analysis procedure being implemented in software. Refer to "Implementation of the PC Trace Function" section and the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)" for more information.
- (4) Be aware that the trace function cannot be used when using the 4-pin cable to connect the target system to the S5U1C33001H.
- (5) Be aware that the bus trace function cannot be used when using the 10-pin cable to connect the target system to the S5U1C33001H.

10.1.6 Counts of the execution counter

The S5U1C33001H's execution counter is normally subject to the errors shown in the table below. These errors must be taken into account when calculating execution times. Note that execution and break overhead adds the prefetch cycles for two additional instructions, making the counters usable for only relatively long intervals. For short intervals, use the clock cycle counts from the trace function.

Execution counter	Count error
Cycle counter	±4 bus clock cycles
μs-unit time counter	±50 ns
Second-unit time counter	±1 μs

Table 7	Execution	counter	error
---------	-----------	---------	-------

10.1.7 Reserved areas in the internal peripheral circuits (C33 STD/Mini core)

When reserved areas in the internal peripheral circuits are displayed using the S5U1C33001H's data display function, note that, depending on the type of microcomputer, the last value read by the C33 core that is held in the bus latch circuit inside the chip may be displayed.

10.1.8 Operating clock of the S5U1C33001H (C33 STD/Mini core)

When execution of the target program is suspended, the operating clock of S1C33xxx chip on the target system is forcibly switched to the high-speed clock even if the C33 core may have been operated with the low-speed clock while the target program was executed. For this reason, if the high-speed clock is turned off by the target program when the target system is being operated with the low-speed clock, the S5U1C33001H will be unable to operate normally after execution of the target program is suspended.

10.1.9 Area 2 of S1C33xxx (C33 STD/Mini/ADV core)

Area 2 of the S1C33xxx (0x0060000 to 0x007FFFF) is reserved as a dedicated area for the programs that operate the S5U1C33001H. Therefore, no device can be mapped to this area using a parameter file, and data cannot be written to this area when the target program is suspended or being executed. If the contents of area 2 are rewritten, the S5U1C33001H will be unable to operate normally. For details on the parameter file, refer to the "Debugger" section in the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)".

10.1.10 Concurrent use of the S5U1C330M2S debug monitor

The S5U1C330M2S cannot be used with the S5U1C33001H simultaneously for debugging the target program.

The S5U1C33001H can be used for debugging the S5U1C330M2S. In this case, the S5U1C330M2S must be implemented using "mon33ice.lib" (library supplied with the S5U1C330M2S package). However, only the following parts in the S5U1C330M2S can be debugged:

- Part for initial connection to the debugger (gdb.exe)
- Confirming the command functions except for execution commands
- Part for communication to the debugger (gdb.exe)

10.1.11 Reset sequence

The sequence from when the S5U1C33001H is powered on until the execution of the target program is executed is entirely different from that of the actual S1C33xxx chip. However, a sequence for the reset requests input from the target system while the target program is being executed is the same as that for the actual S1C33xxx chip. Regarding the reset sequence in the actual S1C33xxx chip, refer to the "S1C33xxx Technical Manual".

10.1.12 Break functions when a reset request is accepted

If a cold reset request from the target system is accepted when the target system is being executed, the hardware PC break and data break functions are disabled until execution of the target program is suspended.

In the case of a hot reset request, there is no such restriction.

10.1.13 I/O memory dump by the S5U1C33001H

Note that some S1C33xxx peripheral circuits may change the control register status due to their specifications when the I/O memory is read using the memory dump function of the S5U1C33001H or when the target program execution is suspended.

For details on the memory dump function, refer to the "Debugger" section in the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)".

10.1.14 Parameter file

Make sure the parameter file for the S5U1C33001H is set correctly according to the specifications of the target system.

For details on the parameter file, refer to the "Debugger" section in the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)".

10.1.15 Models with cache memory embedded

The debugging operations performed while program execution is suspended rewrite the contents of the cache memory. Furthermore, the software PC break function cannot be used when the cache is used under conditions other than that listed in the table below. Use the hardware break function in such cases.

	Instruction cache	Data cache
1	OFF	OFF
2	ON	ON
3	OFF	ON (write through mode only)

Table 8 Cache usage conditions to use software PC break

10.1.16 Models with MMU embedded

The debugging operations performed while program execution is suspended access physical addresses in the default setting.

Although there are some restrictions, it can be changed so that logical addresses will be accessed. For more information, refer to the "Debugger" section in the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)".

10.2 Differences from the actual IC

The S5U1C33001H is different from the actual IC in the way specified below. If this difference is not taken into consideration in an application, the program may not operate normally in the actual IC.

10.2.1 Register initialization

When the actual IC is powered on, the contents of all registers except the PC (program counter) and PSR (processor status register) are indeterminate and retain the immediately preceding values after a reset, whereas in the S5U1C33001H all registers are initialized when the debugger on the host computer is invoked.

At this time, the registers are initialized with the following data:

(For all cores)	
PSR (processor status register):	0x00000000
AHR, ALR (arithmetic operation high/low registers):	0xAAAAAAAA
R0 through R15 (general-purpose registers):	0xAAAAAAAA
(For C33 STD, Mini and PE cores)	
PC (program counter):	0x00C00000 (Note)
SP (stack pointer):	0x0AAAAAA8
(For C33 ADV core)	
PC (program counter):	0x20000000 (Note)
LCO (loop count register):	0x00000000
LSA (loop start address register):	0x00000000
LEA (loop end address register):	0x00000000
SOR (shift out register):	0x00000000
TTBR (trap table base register):	0x20000000
DP (data pointer):	0x00000000
USP (user stack pointer):	0x00000000
SSP (supervisor stack pointer):	0x00000000

For this reason, never create a program that depends on the initialized value. However, for reset input from the target system when the target program is being executed, the S5U1C33001H retains the immediately preceding values, as with the actual IC. For details on each register, refer to the C33 Core Manual.

Note: The PC initial value is decided according to the setting value of the trap table base register (boot address). Refer to the "S1C33xxx Technical Manual" for details on the trap table base register (TTBR).

10.3 Usage precautions

10.3.1 Connecting and disconnecting equipment

Before attaching or removing the target system and cables, and setting the DIP switch and jumper, be sure to turn off the power to the host computer, S5U1C33001H, and target system. Failure to take this precaution may result in equipment malfunction.

10.3.2 Powering on/off

After turning off the power to the S5U1C33001H, wait at least 10 seconds before turning the power on again. If the power is turned on immediately after it is turned off, the S5U1C33001H may not be initialized correctly in a power-on reset, and may cause a malfunction.

10.3.3 Connecting the target system

The signals connected to the S5U1C33001H are very high-speed signals, so the target connector must be mounted within 5 cm from the S1C33xxx. If there is more distance between the connector and the S1C33xxx chip, the S5U1C33001H may not work properly. Furthermore, be sure to use one of the supplied 10-pin and 4-pin cables, or 30-pin cables for connecting the target system to the S5U1C33001H. Using two cables (30-pin and 10-pin or 4-pin cables) simultaneously or using another cable may cause a malfunction.

*1: The product package does not include a 30-pin cable or the corresponding connector. Please contact us if you need this cable or the corresponding connector.

10.3.4 Operation of the S5U1C33001H system

The S5U1C33001H can work by connecting a target system in which the actual S1C33xxx chip is mounted.

Since the S5U1C33001H package does not include any board equivalent to a target system, please prepare separately.

10.3.5 Wiring between the S1C33xxx chip and target connector

When wiring the S1C33xxx chip to the target connector for connecting the S5U1C33001H, insert a 33 Ω resistor in series between the S1C33xxx chip DSIO pin and the connector. This resistor must be placed as close to the S1C33xxx chip as possible. If the reset line is not connected, the system can be operated without this 33 Ω resistor. However, we recommend inserting this resistor to prevent malfunctions. The other pins are connected directly. The total length of the line must be under 5 cm.

Forcible breaks are applied by inputting a low-level to the DSIO pin. Although this signal is pulled up through an about 100 k Ω internally, when not debugging, we recommend either removing the 33 Ω resistor to reduce noise and other problems or pulling this line up to the VDD level (the core voltage).



Place a 33 Ω resistor in series at a location as close to the S1C33xxx as possible.

Fig. 11 Wiring between S1C33xxx and target connector

10.3.6 Reset request

Do not reset the target system while the target program execution is suspended as the S5U1C33001H will be unable to operate normally.

10.3.7 Notes on target system power supply

The allowable voltage range for the signals input from the target system is 0 to 3.6 V. The S5U1C33001H may fail if voltages that exceed this range are input. Therefore, target systems to be connected to the S5U1C33001H must be designed so that voltages outside this range are not applied. Take special care in designing the target system power supply, and design the target system so that overvoltages are not applied to the S5U1C33001H when the target system power supply is turned on or off.

10.3.8 Notes on S5U1C33001H power supply

When using the S5U1C33001H, install circuit breakers that automatically disconnect both conductors in the local power mains, and connect the S5U1C33001H power supply line to a power line protected in that manner.

10.3.9 Core Sync Simple Logic Analyzer Function

This function allows tracing of up to 14 arbitrary signals in the same cycles as the core clock. The traced information can be displayed with the core status. When using an evaluation board for development, any signals on the board may be traced. Before internal signals can be traced, when using an FPGA for development, they should be output from the unused pins.

A 30-pin cable(*1) is used for tracing. The signals to be traced must be output from DTD7 through DTD0, DTS4 through DTS0, or DBT of the provided 30-pin connector. (Use a connector conversion board, such as the CK-4 manufactured by Sunhayato Corp., to attach the 0.5 mm pitch 30-pin connector on the 2.54 mm pitch board.)

For operations of the debugger and the debug commands, refer to the "Debugger" section in the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)".

*1: The product package does not include a 30-pin cable or the corresponding connector. Please contact us if you need this cable or the corresponding connector.



Fig. 12 Connection example for tracing user logic signals

10.4 Implementation of the PC trace function

The PC trace function is implemented by a method that allows the debugger (gdb.exe) to analyze the target program flow using the information delivered on the DST0, DST1, DST2 and DPCO signals output from the S1C33xxx chip, and the target program information loaded into the debugger. The debugger obtains the absolute addresses information required for analyzing the target program flow from the following status.

- (1) The PC (program counter) value when the target program restarts executing from suspended status
- (2) Trace trigger set-up address when a trace trigger is generated
- (3) The PC (program counter) value that is output on the 27- or 31-cycle DPCO signal (PC signal for debugging)

Furthermore, target program execution information is output on the DST0–DST2 signals (status signals for debugging). The debugger analyzes execution and branches successively using this absolute address and execution information, and displays the trace information. Therefore, there are some restrictions in the PC trace function. For details on the PC trace function and operating procedures, see the "Debugger" section in the "S5U1C33001C Manual (C Compiler Package for S1C33 Family)".

10.5 Implementation of the bus trace function

The S1C33xxx bus trace function monitors the internal bus to obtain the bus address, data, bus master, read/write, access size and access type (instruction fetch cycle or data access cycle) information when a read or write access is generated. The sampled information is divided and output from the DST4-0 and DTD7-0 pins to the S5U1C33001H in maximum 8 cycles. If a new bus access is generated while the current bus information is being output from the target system, the S1C33xxx will suspend outputting the current trace information and will start outputting the new trace information. Therefore, frequent bus accesses reduce bus trace information to be obtained. In this case, select a bus trace option for compressing the trace data. The information compress circuit in the S1C33xxx compresses the bus trace data before outputting, thus the amount of bus trace information that can be obtained will be increased.

Furthermore, the items to be traced can be narrowed by specifying a command parameter so that the desired bus trace information to be obtained will be increased.

The bus trace function does not affect the real-time program execution.

11. TROUBLESHOOTING

The following shows the problems attributable to the hardware:

Symptom	Cause/remedy
After power is supplied to the S5U1C33001H via USB, the LED2 (EMU) does not change to ICD mode (blue).	 (1) Does the LED2 (EMU) remain lit in yellow? → See the "Connecting the S5U1C33001H and the host computer" section in this manual. Install the USB driver. (2) Does the LED2 (EMU) remain lit in red? → See the "Connecting the target system" section in this manual. Connect the S5U1C33001H to the target system, then press the RESET/START button. (3) Is the LED2 (EMU) flashing in red? → Recheck the connection procedure.
The following message appears when the debugger (gdb.exe) in the host computer is invoked: Cannot open ICD33 usb driver	 (1) Are the host computer and the S5U1C33001H connected correctly? → See the "Connecting the S5U1C33001H and the host computer" section in this manual and check the connection. (2) Was the debugger (gdb.exe) restarted after resetting the S5U1C33001H while the debugger is running? → See the "Method of invoking ICD mode" section in this manual and restart according to the procedure specified.
The following message will appear suddenly when the target program is executed using the debugger (gdb.exe) in the host computer: Break by external break. Program received signal SIGINT, Interrupt.	 This problem can be generated when low noise enters the DSIO signal of the target system or the BRK IN pin changes to GND level. (1) Is the target system connected with the provided cable? Is the provided cable connected without using an extension cable? → Use only the provided cable. If this cable cannot be used for some reason, connect the target system directly to the S5U1C33001H using the shortest cable possible. (2) Are there any electrically conductive items located near the BRK IN pin? → Keep electrically conductive items away from the BRK IN pin.
The bus trace function is enabled, but trace information cannot be obtained at all.	 (1) Is the 30-pin coaxial cable connected to the target system? → Use the 30-pin coaxial cable. The product package does not include a 30-pin cable. Please contact us if you need a 30-pin cable.
The operation is unstable.	 (1) Is the DSIO signal level (SW4 and 5) set correctly? → See the "Right-side panel" section in this manual and check the setting. (2) Is the target system connected with the provided cable? Is the provided cable connected without using an extension cable? → Use only the provided cable. If this cable cannot be used for some reason, connect the target system directly to the S5U1C33001H using the shortest cable possible.

Table 9 Troubleshooting

12. SPECIFICATIONS

Components	Items	Specifications	Remarks
S5U1C33001H	Dimensions	114 mm (W) x 120 mm (L) x 33 mm (H)	Rubber feet included
	Input voltage	5 V DC	
	Power consumption	2.5 W, max.	
USB cable	Length	1.6 m	
	Connectors	S5U1C33001H side: Mini-B type Host PC side: Standard-A type	
Target system interface cable (4-pin)	Length	Approx. 15 cm	
Target system interface cable (10-pin)	Length	Approx. 15 cm	
Flash programmer power supply cable (4-pin)	Length	Approx. 15 cm	

Table 10 Specifications

Table 11 Connectors recommended for target system

Components	Items	Specifications	Remarks
Target system interface cable (4-pin)	Connectors	4-pin (straight): HKP04M5S (manufactured by Honda Tsushin) 4-pin (low angle): HKP04M5LS (manufactured by Honda Tsushin)	
Target system interface cable (10-pin)	Connectors	10-pin (straight): J3654-6002SC (manufactured by 3M) 10-pin (low angle): J3654-5002SC (manufactured by 3M)	
Flash programmer power supply cable (4-pin)	Connectors	4-pin (straight): HKP04M5S (manufactured by Honda Tsushin) 4-pin (low angle): HKP04M5LS (manufactured by Honda Tsushin)	

EPSON

AMERICA

EPSON ELECTRONICS AMERICA, INC.

214 Devcon Drive, San Jose, CA 95112, USA Phone: +1-800-228-3964 FAX: +1-408-922-0238

EUROPE

EPSON EUROPE ELECTRONICS GmbH

Riesstrasse 15, 80992 Munich, GERMANY

Phone: +49-89-14005-0

FAX: +49-89-14005-110

International Sales Operations

ASIA

EPSON (CHINA) CO., LTD. 7F, Jinbao Bldg., No.89 Jinbao St., Dongcheng District, Beijing 100005, CHINA Phone: +86-10-8522-1199 FAX: +86-10-8522-1125

SHANGHAI BRANCH

7F, Block B, Hi-Tech Bldg., 900 Yishan Road, Shanghai 200233, CHINA Phone: +86-21-5423-5577 FAX: +86-21-5423-4677

SHENZHEN BRANCH

12F, Dawning Mansion, Keji South 12th Road, Hi-Tech Park, Shenzhen 518057, CHINA Phone: +86-755-2699-3828 FAX: +86-755-2699-3838

EPSON HONG KONG LTD.

Unit 715-723, 7/F Trade Square, 681 Cheung Sha Wan Road, Kowloon, Hong Kong. Phone: +852-2585-4600 FAX: +852-2827-4346

EPSON TAIWAN TECHNOLOGY & TRADING LTD.

14F, No. 7, Song Ren Road, Taipei 110, TAIWAN Phone: +886-2-8786-6688 FAX: +886-2-8786-6660

EPSON SINGAPORE PTE., LTD.

1 HarbourFront Place, #03-02 HarbourFront Tower One, Singapore 098633 Phone: +65-6586-5500 FAX: +65-6271-3182

SEIKO EPSON CORP.

KOREA OFFICE 5F, KLI 63 Bldg., 60 Yoido-dong, Youngdeungpo-Ku, Seoul 150-763, KOREA Phone: +82-2-784-6027 FAX: +82-2-767-3677

SEIKO EPSON CORP. MICRODEVICES OPERATIONS DIVISION

IC Sales & Marketing Department 421-8, Hino, Hino-shi, Tokyo 191-8501, JAPAN Phone: +81-42-587-5814 FAX: +81-42-587-5117

S5U1C33001H1400 MANUAL

SEIKO EPSON CORPORATION

Document code: 411437800a First Issue: May, 2008© Reviced: December, 2012 in JAPAN

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Epson: <u>
\$5U1C33001H1400</u>



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



Как с нами связаться

Телефон: 8 (812) 309 58 32 (многоканальный) **Факс:** 8 (812) 320-02-42 **Электронная почта:** <u>org@eplast1.ru</u> **Адрес:** 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.