LMX2470SLE Evaluation Board Operating Instructions



National Semiconductor Corporation Wireless Communications, RF Products Group

2900 Semiconductor Dr. M/S D3500 Santa Clara, CA, 95052-8090 LMX2470SLEFPEBI Rev 02.22.2004

Table of Contents

GENERAL DESCRIPTION	.3
SETUP AND MEASUREMENT PROCEDURES	.4
Recommended Test Equipment	.4
Connection and Setup	.4
Phase Noise Measurement Using A Spectrum Analyzer	.4
Reference Spur Measurement Using A Spectrum Analyzer	. 5
Lock Time Measurement Using A Modulation Domain Analyzer	. 5
RF PLL Phase Noise	.6
RF PLL IN-BAND FRACTIONAL SPURS	.7
RF PLL FRACTIONAL SPURS	.8
RF PLL LOCK TIME	.9
RF PLL LOCK TIME ATTRIBUTES1	0
IF PLL PHASE NOISE AND LOOP BANDWIDTH1	1
IF PLL Reference Spurs1	2
IF PLL LOCK TIME	3
IF PLL LOCK TIME ATTRIBUTES1	4
APPENDIX A – LMX2470 EVALUATION BOARD SCHEMATIC DIAGRAM1	5
APPENDIX B – LMX2470 EVALUATION BOARD LAYOUT1	6
Appendix C – LMX2470 Build Diagram1	7
APPENDIX D –BILL OF MATERIALS1	8
APPENDIX E – HOW TO SETUP CODELOADER SOFTWARE	9
APPENDIX F – TINKERING WITH THE CPUD AND FM MODES	20
APPENDIX G – ADDITIONAL FEATURES OF THE LMX2470 EVALUATION BOARD2	22
APPENDIX H – EVALUATION BOARD TEST LIMITS2	25

LMX2470 Evaluation Board Operating Instructions

General Description

The LMX2470 Evaluation Board simplifies evaluation of the LMX2470 2.6 GHz/0.8 GHz **PLLatinum**TM dual frequency synthesizer. The board enables all performance measurements with no additional support circuitry. The evaluation board consists of a LMX2470 device, a RF VCO module and IF VCO & RF/IF loop filters built by discrete components. The SMA flange mount connectors are provided for external reference input, RF and IF VCO outputs, and the power and grounding connection. A cable assembly is bundled with the evaluation board for connecting to a PC through the parallel printer port. By means of *MICROWIRE*TM serial port emulation, the *CodeLoader* software included can be run on a PC to facilitate the LMX2470 internal register programming for the evaluation and measurement.

RF LOOP FILTER							
Theoretical (NOT Meas	ured) Simulation (Done wit	h EasyPLL at wirele	ess.national.com)				
Phase Margin	39.1 deg	Pole Ratio T3 /T1	51.2 %				
Loop Bandwidth	11.6 KHz	Pole Ratio T4/T3	31.1 %				
Lock Time	2400 – 2480 MHz to 1 KHz tolerance in 249 uS w/o Fastlock	Spur Gain @ 200 KHz	-9.0 dB				
		Settings fo	r Operation				
	VCO	Кф	800 uA				
CPoRF	$1.5 \text{ k}\Omega = 2.7 \text{ k}\Omega$	Comparison Frequency	20 MHz				
150 nF		Output Frequency	2400 - 2480 MHz				
	₩ 820 pF ₩ 560 pF	PLL Supply	2.5 Volts				
		VCO Supply	3 Volts				
★ ★	★ ★	Other Inf	ormation				
		VCO Used	VARIL2450U				
		VCO Gain	55 MHz/Volt				
		VCO Input Capacitance	22 pF				
	IF LOOP FILTE	R					
Theoretical (NOT Meas	ured) Simulation (Done wit	h EasyPLL at wirele	ess.national.com)				
Phase Margin	47.1 deg	Lock Time	760 - 780 MHz MHz to 1 KHz tolerance in 453 uS				
Loop Bandwidth	5.1 KHz	Spur Gain @ 200 KHz	22.1 dB				
		Settings for Operation					
		Κφ	1 mA				
		Comparison Frequency	200 kHz				
CPoRF 10	·///\	Output Frequency	760 - 780 MHz				
		PLL Supply	2.5 Volts				
	T OpenOpen	VCO Supply	3 Volts				
		Other Information					
	▼ ▼	VCO Used	VARIL191-773U				
		VCO Gain	18 MHz/Volt				
		VCO Input Capacitance	100 pF				



Setup and Measurement Procedures

The LMX2470 Evaluation Board is fully assembled and factory tested. Follow the instructions below to set up the hardware platform for the measurement of interest.

Recommended Test Equipment

- Spectrum analyzer (operating frequency range > 2 GHz)
- Modulation domain analyzer
- DC power supply with adjustable voltage outputs
- 100 MHz signal source/generator or ultra-clean 10 MHz signal source. Actually, a 20 MHz (or 19.2, 19.68, or 19.8) MHz crystal can be used. If so, just disable the oscillator doubler bit OSC2X.

Connection and Setup

- 1. Verify that seven jumper blocks are placed in the power header that is located on the upper left hand corner of the board and assigned the designator "POWER".
- 2. Connect the VccPLL power source to a 2.5 volt power supply. .
- 3. Connect the VccVCO power source to a 3.0 volt power supply.
- 4. Connect the reference source to the SMA connector labeled OSCin. Plug the DB25 connector end of the cable assembly to the parallel port of the PC. Connect the other end of the cable to the on-board 5x2-pin header. Refer to the Data cable configuration section of the Applications Information, CodeLoader Operation for pin #1 position. Connect the RF_OUT/IF_OUT output port to the input of a spectrum analyzer for phase noise and reference spur measurement or the input of a modulation analyzer for lock time measurement.
- 5. Run the *CodeLoader* software on the PC for LMX2470 register programming. Refer to Appendices D and E for more details. Ensure proper port setup, and make sure that the frequency of the reference source on the CodeLoader matches that actually used for the board.
- Verify that the CodeLoader software is properly programming the PLL by monitor the current going into the VccPLL pin. Power the RF PLL down and then back up again using the *RF_PD* bit. There should be a several mA change in the current.

Phase Noise Measurement Using A Spectrum Analyzer

- 1. Use the *CodeLoader* software to set the desired frequency and to program the LMX2470 device. Refer to Appendix E for more details.
- 2. Set the spectrum analyzer to the desired center frequency, and adjust the span so the appropriate offset frequency can be viewed.
- 3. Turn on the video-averaging feature of the analyzer for better determination of the noise level.
- If using a spectrum analyzer, use the marker noise function. If the spectrum analyzer does not support this, then subtract 10●log(Resolution Bandwidth) from the measurement. Realize that this method does not account for the spectrum analyzer correction factor (typically ~ 2.5 db).
- 5. Note that these measurements are taken in the default setup.
- 6. For these measurements, the PLL not being used was powered down via microwire and the corresponding VCO power supply jumper was removed.



Reference Spur Measurement Using A Spectrum Analyzer

- 1. Use the *CodeLoader* software to set the desired frequency and to program the LMX2470 device. Refer to Appendix E for more details.
- 2. Set the spectrum analyzer to the desired center frequency, and set the span to allow the reference sidebands to be viewed. For example, the span can be set to 250 kHz during RF VCO measurement because its loop filter design is based on 100 kHz channel spacing.
- 3. The reference spur is the difference between the level of the VCO output frequency tone and the level of the reference spur (at the center frequency +/- the reference frequency).
- 4. Note that fractional spurs are dependent on voltage, fractional modulus, delta sigma modulator order, CPUD bit, and frequency. When measuring spurs, it is important to measure them at the lowest, middle, and highest frequency to get a realistic idea of the worst case. For these measurements, the PLL not being used was powered down via microwire and the corresponding VCO power supply jumper was removed.

Lock Time Measurement Using A Modulation Domain Analyzer

- Decide the maximum and minimum frequency to be switched alternately. Enter *Burst Mode* menu of *CodeLoader* software to create a macro to program the LMX2470 to the maximum and minimum frequency alternately over time. It is necessary to put a sufficient delay between PLL programming (i.e. 100,000). Refer to the *Burst Mode configuration and operation* section of the *Application Information*, *CodeLoader Operation* for more details.
- 2. Set the slope of the trigger appropriately. For a positive lock time, choose a positive slope. For a negative lock time, choose a negative slope.
- 3. Set the trigger frequency just past the starting frequency. For instance, when measuring the lock time from 2400 to 2480 MHz, set the trigger at 2401 MHz.
- 4. Set the center frequency to the desired frequency and the span to 10 KHz.
- 5. Press **[Start/Stop]** button to capture the switching curve. Repeat this many times to get an idea of how much this measurement may vary. The graphs shown in this report are considered representative of the average lock time seen.
- 6. The lock time is the time difference between the point the frequency starts to change and the point that the PLL frequency settles within +/- 1 kHz range.



- Note how the phase noise degrades at offsets less than 3 KHz. This may be partially due to the reference noise and measurement system. However, part of this is due to the part. If the comparison frequency is lowered, this effect is reduced.
- The loop bandwidth is about 10 KHz.
- The in-band phase noise can be improved by using a higher charge pump current setting, but the 800 uA setting was used so that higher current settings could be used for with fastlock/cycle slip reduction.
- The plot above was taken with an HP4352B phase noise system with the Agilent E4426B signal generator. The reference source was a Wetzel 10 MHz crystal with +12 dBm output.
- The phase noise system accounts for correction factors, which makes the measurement appear about 2.5 dB worse than not accounting for this factor.











- for fastlock.
 The plot above was taken with an HP4352B phase noise system with the Agilent E4426B signal generator. The reference source was a Wetzel 10 MHz crystal with +12 dBm output.
- The phase noise system accounts for correction factors, which makes the measurement appear about 2.5 dB worse than not accounting for this factor.









Appendix A – LMX2470 Evaluation Board Schematic Diagram

TOP LAYER and Silkscreen (Mid Layer 1 is Ground and is 10 mils below the top layer) **MID LAYER 2** BOTTOM LAYER and SILKSCREEN

Appendix B – LMX2470 Evaluation Board Layout (top view looking through the board)



Appendix C – LMX2470 Build Diagram (As seen top view through the board)

Appendix D – Bill of Materials

	A	Assembly	LMX2470SLDEB					
	I	Revision	2.1					
	La	st Updated	10/18/2002					
Item	Qty.	Manufacturer	Part#	Part Type	Part Fo	otprint N	laterial	Designator
0	n/a	OPEN	OPEN	 C18, C20, C21, C22, C2_RF, C3_IF, C4_IF, C5_RF R1, R2pRF, R14, R15, R16, R17, R32, R33, R34, R35, R36, R37, R39, R3pRF FoLD, VccIFVCO, VddRF, VtuneIF, VtuneRF, Any component with designator 100 or higher is open and on the bottom layer. 				
1	1	COMM CON CONNECTORS	HTSM3203-10G2	10 Pin Header	HEADER_2X5	PLASTIC		uWire
2	1	COMM CON CONNECTORS	HTSM3203-14G2	14 Pin Header	HEADER_2X7	PLASTIC		POWER
3	7	COMM CON CONNECTORS	CCIJ255G	SHUNT, Single, 0.1", Closed Top	N/A	PLASTIC	Place a	across the following pins of the POWER 2, 3-4, 5-6, 7-8, 9-10, 11-12, 13-14)
4	5	CDI	5762SF	SMA	SMA(30X125MIL)	METAL	IF_OU	JT, RF_OUT, OscIn, VccPLL, VccVCO
5	1	LUX MANUFACTURING	225325GTSP	LARGE FRAME	LARGE FRAME	METAL		MECHANICAL
6	12	ORLANDER, INC	OF12SHCA	FRAME SCREWS	SCREWS	METAL		MECHANICAL
7	10	ORLANDER, INC	2C18PPMZZ	SMA SCREWS	SCREWS	METAL		MECHANICAL
8	1	NATIONAL SEMICONDUCTOR	LMX2470	LMX2470	CSP24	SILICON	(M	U1 atch Dot on Part with Dot on Board)
9	1	NATIONAL SEMICONDUCTOR	LMX2470SLDEBPCB	PCB Board	PCB Board n/a			n/a
10	1	VARIL	VCO191-773U	VCO	VARIL U	CAN	(Ma	U3 atch Dot on VCO with Dot on Board)
11	1	VARIL	VCO191-2450U	VCO	VARIL U	CAN	(Ma	U2 atch Dot on VCO with Dot on Board)
12	2	STEWARD	LI0603D301R-00	Ferrite Bead	603	FERRITE		L1, L2
13	11	KEMET	C0603C101J5GAC	100pF	0603	NPO		C2, C4, C6, C8, C10, C12, C15, C17, C19, C24, C25
14	1	KEMET	C0603C561CJ3GAC	560pF	0603	NP0		C4_RF
15	1	KEMET	C0603C821CJ3GAC	820pF	0603	NP0		C3_RF
16	1	KEMET	C0805C182CJ3GAC	1.8nF	0805	NP0		C1_IF
17	1	PANASONIC	ECHU1C103JB5	10nF	0805	FILM		C2_IF
18	1	PANASONIC	ECHU1C153JB5	15nF	0805	FILM		C1_RF
19	9	KEMET	C0603C104K3RAC	100nF	0603	X7R	C3, 0	C5, C7, C9, C11, C13, C14, C16, C23
20	1	PANASONIC	ECHU1C154MA5	150nF	1210	FILM		C2pRF
21	2	KEMET	C1210C475K8RAC	4.7uF	1210	X7R		C1, C26
22	8	VISHAY	CRCW0603000ZRT1	0 Ω	0603	CERAMIC	R3, R3	IF, R4_IF, R5_RF, R27, R28, R38, R40
23	9	VISHAY	CRCW0603180JRT1	18 Ω	0603	CERAMIC	; R2,	R4, R6, R7, R8, R10, R12, R25, R30
24	1	VISHAY	CRCW0603221JRT1	220 Ω	0603	CERAMIC	;	R2_RF
25	6	VISHAY	CRCW0603331JRT1	330 Ω	0603	CERAMIC	;	R5, R9, R24, R26, R29, R31
26	1	VISHAY	CRCW0603152JRT1	1.5 KΩ	0603	CERAMIC	;	R3_RF
27	1	VISHAY	CRCW0603272JRT1	2.7 ΚΩ	0603	CERAMIC	;	R4_RF
28	1	VISHAY	CRCW0603822JRT1	8.2 KΩ	0603	CERAMIC	;	R2_IF, R2pIF
29	5	VISHAY	CRCW0603103JRT1	10 KΩ	0603	CERAMIC	;	R11, R13, R18, R20, R22
30	3	VISHAY	CRCW0603123JRT1	12 KΩ	0603	CERAMIC	;	R19, R21, R23

The loop filter components C1_RF, C2_RF, and C2_IF that were used to take the information had a FILM dielectric. However, X7R capacitors were substituted and no noticeable degradation in performance was observed, so it is acceptable to substitute X7R components for these components.

K LMX2470 _ 🗆 🗵 This shows the proper port setup. The port setup ols Select Device Options Mode Hel is: Port Setup Registers Bits/Pins BurstMode **BF PLL** IF PLL Clock: 32 Port Address C LPT1 C LPT3 C Other 378 Reload Every 10 sec Port Setup Diagram Clock Other Pins Data: 128 Clock Bit 🛯 Data Ground 16 • 32 • 64 • 128 • C1 • C2 C1 LE (Latch Enable) Address Conflict LE: Data Bi 10 Pin Connector (Top View) 2 64 @ 128 O C1 O C2 RFEn: Pin 1 - 0 0 0 0 0 IFEn: 4 64 C 128 C C1 C C2 Trigger: C2 32 0 64 0 128 0 01 0 02 For most desktop computers, the parallel port is 32 0 64 0 128 0 01 0 02 LPT1, but LPT3 is common for many laptop • • • • • • • • • • • • • • • • • computers. CodeLoader does not autodetect the DB 25 Connecto correct port. K LMX2470 _ 🗆 × Elle Keyboard Controls Select Device Options Mode Help This shows the proper bits/pins setup. At this BurstMode RF PLL IF PLL Port Setup | Registers | **Bits/Pins** time, not all the best known modes are shown. Power Down Controls Fractional Controls Fastlock Controls Friogra FDM RF_TOC The CE pin is normally enabled to power up the RF_FN2 700 -TRIGGER ATPU 0 📫 evaluation board, but this evaluation board has a RF_CPF • Disable RF_FD2 1600uA pull-up resistor, so this pin has no impact. 0÷ Misc Controls CSR FM 1/4 + I osc₂× 3rd Order Modulator MUX PDCP CPUD • X2 Fastlock Current Disabled -Maximum IF TOC DITH 500 -Dithering Disabled 1MX2470 - U × Select Device Options Mode He Note that although a 10 MHz reference source is BurstMode Port Setup Registers Bits/Pins **RF PLL** IF PLL used, this should be treated as 20 MHz on the RF Reference Oscillator R Counter PLL side because the oscillator doubler is used. \odot OSC Ð Ensure that the 16 prescaler is used for the best Loop Filter 20 MHz Phase Detector Fi performance. 800.44 Z(s) 20000 ÷ kH: 122.01 N Counter PLL VCO ~ 2440.2 MHz K LMX2470 <u>- 0 ×</u> Eile Keyboard Controls Select Device Options Mode Help The oscillator doubler only doubles the frequency IF PLU Port Setup Bits/Pins BurstMode RF PLL Registers for the RF PLL, so on the IF PLL, the reference Reference Oscillator R Counte source frequency is 10 MHz. 050 \bigcirc 50 ÷ Charg Pump Gain Loop Filter State Phase Detector MH₂ + Z(s) 200 ↓ kH₂ 3850 + N Counter PLL vco \bigcirc 770 MHz

Appendix E – How To Setup CodeLoader Software

Appendix F – Tinkering with the CPUD and FM Modes

The CPUD and FM bits have a large impact on fractional spurs. They do have some impact on phase noise, but this impact is on the order of 1 dB or less. For this evaluation board, there are three types of fractional spurs. The main fractional spur is at 200 KHz offset. Fractional spurs that occur at frequency offsets that are either one-half or one-fourth of the channel spacing will be referred to as sub-fractional spurs. There may be a sub-fractional spur at 100 KHz, and if the fourth order modulator is used, then there may also be a sub fractional spur at 50 KHz as well. There are trade-offs between the main fractional spur level and main fractional spur level. Also, the sub-fractional spurs are sensitive to the power level of the reference input. In order to best show the impact of these bits, the worst case spurs from 2400.2 MHz, 2440.2 MHz, and 2480.2 MHz were measured. Various bits were changed to make 17 different modes. When the comparison frequency was 10 MHz, the charge pump gain was increased to 1600 uA to maintain the same loop bandwidth.

				50 KHz Spur (dBc)		100 KHz Spur (dBc)		200 KHz Spur (dBc)	
Mode	OSC2X	FM	CPUD	Avg.	Stdev.	Avg.	Stdev.	Avg.	Stdev.
0	0	2nd	Minimum	-66.7	1.3	-71.4	4.2	-69.4	5.4
1	0	2nd	Maximum	-67.3	0.3	-72.6	3.5	-67.1	0.9
2	0	2nd	Nominal	-65.5	0.7	-74.3	5.0	-66.6	4.3
3	0	3rd	Minimum	-59.4	7.7	-68.0	3.6	-72.1	3.1
4	0	3rd	Maximum	-57.6	7.6	-66.4	3.8	-70.2	1.5
5	0	3rd	Nominal	-59.9	7.4	-68.6	3.8	-67.7	3.3
6	0	4th	Minimum	-53.1	5.4	-69.2	1.6	-73.2	1.9
7	0	4th	Maximum	-53.5	3.0	-70.8	2.0	-71.2	1.7
8	0	4th	Nominal	-55.7	7.0	-67.9	3.3	-68.6	2.2
9	1	2nd	Minimum	-66.0	3.6	-68.0	2.7	-78.6	0.9
10	1	2nd	Maximum	-65.3	2.2	-71.3	1.7	-78.6	1.1
11	1	2nd	Nominal	-65.9	0.3	-68.3	2.6	-76.7	2.2
12	1	3rd	Minimum	-66.3	0.4	-72.8	0.8	-79.0	2.8
13	1	3rd	Maximum	-66.1	1.8	-75.8	2.0	-76.9	1.9
14	1	3rd	Nominal	-66.3	2.1	-72.6	2.0	-76.8	5.1
15	1	4th	Minimum	-47.7	2.8	-66.8	3.3	-80.1	2.1
16	1	4th	Maximum	-59.9	3.8	-73.9	0.1	-77.7	1.5
17	1	4th	Nominal	-47.3	1.9	-68.0	4.5	-76.4	3.6

The reference source was the 10 MHz out of the back of a HP8563E spectrum analyzer. This source was about 0 dBm. There is also a 3 dB pad on the board. When the OSC2X bit was one, the comparison frequency was 20 MHz, otherwise it was 10 MHz. The following trends can be seen with these different modes:

- For all modes, the main fractional spur at 200 KHz looks lower with the 20 MHz comparison frequency than with a 10 MHz comparison frequency.
- The 1/4th sub fractional spur at 50 KHz offset is only present when the 4th order modulator was used
- The data in the front of this document was originally taken with mode 13, but the table suggests that using mode 12 reduces the 200 KHz spur at the expense of the 100 KHz spur. Using mode 15 creates large spurs at 50 KHz, but reduces the main fractional spur at 200 KHz. It is impossible to say that one mode is the best for every application and circumstance, but there are certainly modes that are better than others. Modes 12, 13, and 15 seem to be optimal, depending on how optimal spur performance is defined.



The chart above is just a visual representation of the table on the previous page. The turquoise, purple, and blue dotted lines on the graph indicate the noise floor of the spectrum analyzer at 50 KHz, 100 KHz, and 200 KHz, respectively.

Appendix G – Additional Features of the LMX2470 Evaluation Board

POWER MANAGEMENT

The power management strategy on this board allows one to run the board off any combination of power supplies. The resistor R1 connects VccVCO with VccPLL. The gray lines represent optional connections that can be made. One important thing to understand is that the jumpers may be placed horizontally as well as vertically, allowing more flexibility. The squares that are gray in color have an SMA connector routed to them.



Name	Function
VccVCO	Power Supplies for the TCXO, RF VCO, and IF VCO
VccTCXO	Power supply for the TCXO
VccRFVCO	Power supply for the RF VCO. Note that there is an option to send this through an LDO.
VpRF	Power supply for the VpRF pin of the PLL Note that for normal operation, VpRF = VpIF
VpIF	Power supply for the VpIF pin of the PLL. Note that for normal operation, VpRF = VpIF
VccIFVCO	Power supply for the IF VCO. Note that there is an option to send this through an LDO.
VccRF	Power supply for the VccRF pin of the PLL. Note that for normal operation, VccRF = VccIF
VccIF	Power supply for the VccIF pin of the PLL. Note that for normal operation, VccRF = VccIF

MICROWIRE

In the default setup, the 10K/39K voltage divider divides 5 volts to 4 volts. Now the reason it doesn't go to 3 volts is that if the PC has a 3 volt output as a few do, then it gets 2.4 volts. If the user is at 3.0 volts Vcc for the rest of the board, it is still within specifications. Note also the capacitors. On DC lines, the ESR of the 1uF capacitor is not critical because it is next to 10K Ω resistor. This should significantly reduce any noise coming the microwire on these traces. On CLOCK, DATA, and LE, there is only 10 pF, since these carry AC signals. The pull-up on the RF_EN and IF_EN is to VCCmain, so it does not disrupt current measurements into the VccPLL pin. So it should be clear that if the Pull-up resistor is in the board, and the PLL is powered down, then there will be a voltage across these pull-up resistors which will increase the current consumption of the board. The microwire can also turn off the RF and IF LDOs and be used for bandswitch functions on the VCOs.

PART NUMBERING SCHEME

The part designators are assigned such that all the components on the bottom layer have a designator of 100 or higher, and all the components on the top layer are less than 100. In the default configuration, no components on the bottom layer should be included. All components on the bottom layer are to support additional features.

HYBRID VCO FOOTPRINT

Although the evaluation board is created to support a particular VCO, the footprint is flexible and designed such that other VCOs are easy to put on the board. To mount a smaller VCO on the board, scratch off the soder mask with the flat edge of a screwdriver and then put solder on the pads such that it covers the exposed copper.

MULTI-FASTLOCK SUPPORT

In addition to supporting traditional fastlock, this board supports switching in two resistors. This is more there for testing purposes. For both the RF and IF loop filters, it is possible to switch in up to 3 possible combinations of resistors. For instance, on the RF loop filter, if one makes R40 0 ohm and R2_IF open, then one can switch in R2_RF, R41, or both. The way to use this is to make R2pRF = R2_RF and R41 = R2_RF/2. If the charge pump current or comparison frequency is increased, it is possible to keep the loop filter and phase margin optimized with these resistors. Although this example is for the RF loop filter, the same concept applies to the IF loop filter.

Charge Pump or Comparison Frequency Multiplier	R2pRF	R41	FloutR F	FLoutIF	Equivalent Fastlock Resistor	Loop Bandwidth Multiplier
1X	R2_RF	R2_RF/ 2	Tri- State	Tri- State	OPEN	1X
4X	R2_RF	R2_RF/ 2	Low	Tri- State	R2_RF	2X
9X	R2_RF	R2_RF/ 2	Tri- State	Low	R2_RF/2	3X
16X	R2_RF	R2_RF/ 2	Low	Low	R2_RF/3	4X

TUNING VOLTAGE ACCESS

The tuning voltage is brought out to an SMA. This is useful for charge pump sweeps and VCO characterization. Note to characterize the VCO on the board with a VCO tester, it is not necessary to remove the PLL. Simply power it down. When this feature is not used, resistors R30 and R36 should be removed. Note that if R30 is removed, so is support for switched filters.

ANALOG LOCK DETECT SUPPORT

R34, R35, and C21 are there so that lock detect filters can be constructed. Note that this is intended for open drain lock detect.

INPUT IMPEDANCE MEASUREMENTS

Because the RF traces are straight into the PLL, one can short C15, R38, and R7. Open R3, R5, and R9. Put 100 pF in C17. To calibrate the equipment, use 0 ohm, 50 ohm (2 100 ohms in parallel), and open in R9. This way the trace is calibrated out and it is not necessary to destroy the board in order to put a piece of semi-rigid cable on it. Measurements done in this way turn out to have less "squiggly" lines than by trying to calibrate out the board trace with the port extensions function.

BANDSWITCH VCO SUPPORT

The board is also configured so that CodeLoader can control a bandswitch VCO for either the RF or IF PLL. In order to do this, one can use the trigger pin. Don't forget to stuff the components on the bottom layer from this.

RF SWITCHED FILTER SUPPORT

Switched loop filters are useful in dual band applications where one standard has a hard lock time requirement and an easier spur requirement than the other. For this mode of operation, FloIF is tri-state and C42, C43, C4_RF ,and R53 add in parallel with R4_RF and reduce the thermal noise, but theoretically do not impact the PLL loop dynamics (they may impact it a little due to non-zero VCO input capacitance). In the other mode, the FloIF pin is pulled to ground and an extra pole is formed with R4_RF and C4_RF. Now C42 adds in parallel with C1_RF and C43 >> C2_RF such that we can neglect C2_RF and R2_RF and replace that with R53 and C43 for theoretical analysis. On the bottom of the board are components that can be switched in addition to the RF loop filter. The intention of this feature is that R3_RF is 0ohm and C3_RF is open. Now R40 and R2pIF need to be open and R41 should be 0 ohms.



SENSITIVITY MEASUREMENTS

In order to measure sensitivity, short C15 and R38, open R3, put 330 ohms in R5 and R9, put 18 ohms in R7, and put 100 pF in C17. Then from the signal generator, but a cable and between the cable and the board, put a 3 dB pad connector. Now reflected waves in the cable should be minimized by this. Also the 3 db pad constructed on the board with R4, R7, and R9 minimizes standing waves on the board trace. To record the sensitivity level, take the signal generator power level, and subtract 7 db. (1 for the cable, 3 dB for the pad connector, and 3 db for the pad on the board).

CRYSTAL/TCXO SUPPORT

To add a TCXO, short R37 and R39. C114 and C115 form the load capacitors. Now the footprint is 4 pins, not two. put the crystal across pins 4 and 3, but be careful to avoid pin 2, which is ground.

LDO SUPPORT

On the bottom of the board, both of the VCOs and the PLL may be run of a power regulator. The board in mind was the LP2985. Note that the LDOs can be controlled via CodeLoader. In order to do this, one can use the Trigger pin. Don't forget to stuff the appropriate components on the bottom layer.

Appendix H – Evaluation Board Test Limits

The test limits used to test the LMX2470 evaluation board are shown below. Note that test limits are always worse than typical conditions because they account for board to board variation. In addition to this, they also may be worse in order to simplify and speed up the measurement process. This evaluation board is typically tested with an automated test program.

PLL	Parameter	Offset	Test Limit	Comments
RF	Phase Noise	3 KHz	-83	CPUD=2. Marker Noise Function ON.
RF	Phase Noise	5 KHz	-80	CPUD=2. Marker Noise Function ON.
RF	Lock Time	1 KHz	550	TOC=700
RF	Fractional Spur	200 KHz	-68	CPUD=3
IF	Phase Noise	5 KHz	-82	Marker Noise Function ON.
IF	Spur	200 KHz	-69	Note that the spur is typically far below this, but this measurement can be limited by the noise floor of the spectrum analyzer.

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Products		Applications	
Audio	www.ti.com/audio	Automotive and Transportation	www.ti.com/automotive
Amplifiers	amplifier.ti.com	Communications and Telecom	www.ti.com/communications
Data Converters	dataconverter.ti.com	Computers and Peripherals	www.ti.com/computers
DLP® Products	www.dlp.com	Consumer Electronics	www.ti.com/consumer-apps
DSP	dsp.ti.com	Energy and Lighting	www.ti.com/energy
Clocks and Timers	www.ti.com/clocks	Industrial	www.ti.com/industrial
Interface	interface.ti.com	Medical	www.ti.com/medical
Logic	logic.ti.com	Security	www.ti.com/security
Power Mgmt	power.ti.com	Space, Avionics and Defense	www.ti.com/space-avionics-defense
Microcontrollers	microcontroller.ti.com	Video and Imaging	www.ti.com/video
RFID	www.ti-rfid.com		
OMAP Mobile Processors	www.ti.com/omap		
Wireless Connectivity	www.ti.com/wirelessconnectivity		

TI E2E Community Home Page

e2e.ti.com

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2012, Texas Instruments Incorporated



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



Как с нами связаться

Телефон: 8 (812) 309 58 32 (многоканальный) **Факс:** 8 (812) 320-02-42 **Электронная почта:** <u>org@eplast1.ru</u> **Адрес:** 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.