

FTDI Chip VA800A PROG Datasheet Programmer for VM800P Embedded Video Engine Plus module



1 Introduction

The VA800A PROG is a programmer for the VM800P module. This provides a USB to SPI bridge that will enable access to the ATMEGA328P on the VM800P module.

The module provides a suitable alternative to the inbuilt USB to UART programmer of the VM800P and may also be used to recover a damaged/corrupted MCU.

1.1 Features

- Connects to the VM800P Plus module using the SPI interface
- Micro-B USB connector
- 6-way IDC connector
- Powered from the PC USB port (5V)
- Power switch to control supply to the target
- Ribbon cable to connect to the VM800P "Tag_Connect" socket.

Neither the whole nor any part of the information contained in, or the product described in this manual, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. This product and its documentation are supplied on an as-is basis and no warranty as to their suitability for any particular purpose is either made or implied. Future Technology Devices International Ltd will not accept any claim for damages howsoever arising as a result of use or failure of this product. Your statutory rights are not affected. This product or any variant of it is not intended for use in any medical appliance, device or system in which the failure of the product might reasonably be expected to result in personal injury. This document provides preliminary information that may be subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. Future Technology Devices International Ltd, Unit 1, 2 Seaward Place, Centurion Business Park, Glasgow G41 1HH United Kingdom. Scotland Registered Company Number: SC136640



2 Ordering Information

Part No.	Description
VA800A_PROG	VA800A PROG module, programmer for VM800P Plus module

Table 2-1 – Ordering information



Table of Contents

1	Int	roduction	1
1.	.1	Features	1
2	Ord	dering Information	2
3	Ha	rdware Description	4
3.	.1	· VA800A PROG module	4
3.	.2	Physical Descriptions	4
	3.2.1	L Dimensions	4
	3.2.2	2 VA800A PROG Connectors	6
	3.2.3	3 VA800A PROG Components	7
4	Boa	ard Schematics	8
5	Ha	rdware Setup Guide	9
5.	.1	Power Configuration	9
5.	.2	SPI Interface connection	9
5.	.3	Programing the VM800P bootloader	9
6	Со	ntact Information1	3
Ap	pen	dix A – References 1	4
Ap	pen	dix B - List of Figures and Tables1	5
Li	ist o	f Figures1	5
Li	ist o	f Tables1	5
Ap	pen	dix C – Revision History1	6





3 Hardware Description

Please refer to section 3.2.2 for connector settings.

3.1 VA800A PROG module



Figure 3-1 - VA800A PROG module

The VA800A PROG module is designed as an ISP programmer to the VM800P Plus module. The main functions of the VA800A PROG are as follows:

- programmer for the VM800P Plus module.
- Interface to the VM800P Plus module using SPI interface.
- Micro-B USB connector
- 6-way IDC connector
- Powered from the PC USB port (5V)
- Power switch to control supply to the target
- Ribbon cable to connect to the VM800P "Tag_Connect" socket included.

3.2 Physical Descriptions

3.2.1 Dimensions

The VA800A PROG module dimensions is illustrated in Figure 3-2 and Figure 3-3.





Figure 3-3 - VA800A PROG module Bottom view

All dimensions are in mm



3.2.2 VA800A PROG Connectors

Connectors are described in the following sections.

CN1- USB Connector

This is the interface where the USB signals are routed. This interface is used to connect the VA800A PROG board to the PC.

Pin No.	Name	Туре	Description	
1	VBUS	Р	VBUS, 5V Power Supply	
2	D-	IO	D Minus	
3	D+	IO	D Plus	
4	ID	NA	IA Not Connected	
5	GND	Р	Ground	

Table 3-1 – CN1 Pinout

• CN2- SPI Connector

This is the interface where the SPI signals are connected. There are also power and ground pins on this interface. The ISP cable is connected between this interface and the VM800P module ISP connector to program the VM800P board.

Pin No.	Name	Туре	Description
1	MISO	I	Master In Slave Out
2	5V	P 5V power supply	
3	SCK	0	SPI Clock
4	MOSI	0	Master Out Slave In
5	SS	0	Slave Select
6	GND	Р	Ground

Table 3-2 – CN2 Pinout

• CN3- ISP Connector

This is the interface where the SPI signals are connected. There are also power and ground pins on this interface. The ISP cable is connected to this interface to program the ATMEGA in this board.

Pin No.	Name	Туре	Description
1	MISO	I	Master In Slave Out
2	5V	Р	5V power supply
3	SCK	0	SPI Clock
4	MOSI	0	Master Out Slave In
5	RST#	0	Reset
6	GND	Р	Ground

Table 3-3 – CN3 Pinout



Note: CN2 and CN3 should not be used at the same time. Note: CN3 should not be used by customers. Using CN3 will make the module non-functional.

• SW1- Power switch

The power switch should be in ON position to supply external power to VM800P module.

3.2.3 VA800A PROG Components

• U1 – FT232RQ

This converts the USB signals from the PC to UART TTL signals.

• U2 – ATMEGA328P

This converts the UART signals to SPI signals.

• LED1 – Green

Indicates the status of UART RX. Illuminate when the GPIO line is logic 0.

• LED2 –Red

Indicates the status of UART TX. Illuminate when the GPIO line is logic 0.

• LED3 –Yellow

Indicates the status of power. Illuminate when the 5V power is ON.





4 Board Schematics



Figure 4-1 - VA800A PROG Schematics



5 Hardware Setup Guide

5.1 Power Configuration

The board is powered from the PC. The CN1 USB micro-B connector on the VA800A PROG board should be connected to the PC.

5.2 SPI Interface connection

The SPI interface is used to program the VM800P Plus module. The ISP cable shown in <u>Figure 5-1</u> is connected between the SPI interface on the VA800A-PROG module to the ISP connector on the VM800P module. The black colour connector on the ISP cable is connected to connector CN2 on the VA800A-PROG module and the blue colour connector on the ISP cable is connected to connector CN3 on the VM800P module.

The SCK signal on CN2 is connected to the SCK signal on the VM800P board.

The MOSI signal on CN2 is connected to the MOSI signal on the VM800P board.

The MISO signal on CN2 is connected to the MISO signal on the VM800P board.

The SS signal on CN2 is connected to the RST signal on the VM800P board.

The 5V signal on CN2 is connected to the 5V signal on the VM800P board.

The GND signal on CN2 is connected to the GND signal on the VM800P board.



Figure 5-1 – ISP Cable

5.3 Programing the VM800P bootloader

The bootloader is programmed to the VM800P in the factory using the VM800P ISP connector. This module is used to program the bootloader to the VM800P module.

Steps to program the bootloader to VM800P using Arduino IDE.

Open the Arduino IDE

Select the Tools->Serial Port->COMxx corresponding to the VA800A_PROG.

VA800A_PROG Datasheet Version 1.1



Document Reference No.: BRT_000006 Clearance No.: BRT#010



Figure 5-2 – Select the Serial Port

Select the Tools->Board->Arduino Pro or Pro Mini(5V, 16MHz) w/ATmega328



Figure 5-3 – Select the Board

Select the Tools->Programmer->Arduino as ISP







Figure 5-4 – Select the Programmer

Click on Tools->Burn Bootloader.

Sound Arduino	1.0.5-r2			
File Edit Sketch	ools Help			
Sound FTImp.	Auto Format Archive Sketch Fix Encoding & Reload Serial Monitor	Ctrl+T Ctrl+Shift+M	to the screen	
/* Be. if(Pl:	Board Serial Port) }	udio engine api to play sound */ :Pitch<<8) Sound));	
/* bootup the	Programmer	•	reen */	1
/* Set Serial. if (Boot {	the Display Enable pi println("Start Appl upConfigure()) W	n*/ ication").	,	
165			Arduino Pro or Pro Mini (SV, 16 MHz) w ATr	nega328 on COM54

Figure 5-5 - Burn Bootloader

The status bar will display "Burning bootloader to IO board (This may take a minute)...".



VA800A_PROG Datasheet Version 1.1

Document Reference No.: BRT_000006 Clearance No.: BRT#010

	- Aldenio 10.3-12	
File Edit	Sketch Tools Help	
00) 🗈 🛃 🛃	-Q-
Sound		
	FTImpl.Finish();//render the display list to the screen	
	/* Below code demonstrates the usage of audio engine api to play sound */ ${\tt if}({\tt PlaySound})$	
	<pre>FTImpl.PlaySound(Vol,(uintl6_t)((Pitch<<8) Sound));</pre>	
/* boot /* boot void se	up the module and display primitives on screen $^{\ast /}$ tup ()	
(/* Initialize serial print related functionality */ <pre>Serial.begin(9600);</pre>	
	/* Set the Display Enable pin*/ Serial_println("Start Application");	
	<pre>if(BootupConfigure()) {</pre>	
	III	F.
Burning	m bootloader to VO Board (this may take a minute)	4
Burning	m bootloader to VO Board (this may take a minute)	4
Burning	m bootloader to VO Board (this may take a minute)	,
e Burning.	m bootloader to VO Board (this may take a minute)	• •
Burning	m bootloader to VO Board (this may take a minute)	,
Burning	m bootloader to VO Board (this may take a minute)	•
Burning	m bootloader to VO Board (this may take a minute)	ł
<	m bootloader to VO Board (this may take a minute)	ŀ
< Luming	m bootloader to VO Board (this may take a minute)	ŀ
 Euming 	m bootloader to VO Board (this may take a minute)	ŀ
< Burning	m bootloader to UO Board (this may take a minute)	ŀ

Figure 5-6 – Burning Bootloader

When the bootloader has burned successfully the status message will change to "Done burning bootloader.".

Sound Arduino 1.0.5-r2	- • • ×
File Edit Sketch Tools Help	
	P
Sound	
FTImpl.Finish();//render the display list to the screen	^
/* Below code demonstrates the usage of audio engine api to play sound */ if(PlaySound)	
FTTmpl.PlaySound(Vol,(uintl6_t)((Pitch<<8) Sound));	
<pre>//* bootup the module and display primitives on screen */ void setup()</pre>	
<pre>/* Initialize serial print related functionality */ Serial.begin(9600);</pre>	
<pre>/* Set the Display Enable pin*/ Setial_println("Start_Appl ication"); if(BootupConfugre(1))</pre>	E
{	-
<	۱.
Done burning bootloader.	
185 Arduino Pro or Pro Mini (SV, 16 MHz) w/ A	(Tmega328 on COM54

Figure 5-7 – Done Burning bootloader





6 Contact Information

Head Quarters – Singapore

Bridgetek Pte Ltd 178 Paya Lebar Road, #07-03 Singapore 409030 Tel: +65 6547 4827 Fax: +65 6841 6071

E-mail (Sales) E-mail (Support) <u>sales.apac@brtchip.com</u> support.apac@brtchip.com

Branch Office - Taipei, Taiwan

Bridgetek Pte Ltd, Taiwan Branch 2 Floor, No. 516, Sec. 1, Nei Hu Road, Nei Hu District Taipei 114 Taiwan, R.O.C. Tel: +886 (2) 8797 5691 Fax: +886 (2) 8751 9737

E-mail (Sales) E-mail (Support) sales.apac@brtchip.com support.apac@brtchip.com

Branch Office - Glasgow, United Kingdom

Bridgetek Pte. Ltd. Unit 1, 2 Seaward Place, Centurion Business Park Glasgow G41 1HH United Kingdom Tel: +44 (0) 141 429 2777 Fax: +44 (0) 141 429 2758

E-mail (Sales) E-mail (Support) sales.emea@brtichip.com support.emea@brtchip.com Branch Office – Vietnam

Bridgetek VietNam Company Limited Lutaco Tower Building, 5th Floor, 173A Nguyen Van Troi, Ward 11, Phu Nhuan District, Ho Chi Minh City, Vietnam Tel : 08 38453222 Fax : 08 38455222

E-mail (Sales) E-mail (Support) sales.apac@brtchip.com support.apac@brtchip.com

Web Site

http://brtchip.com/

Distributor and Sales Representatives

Please visit the Sales Network page of the <u>Bridgetek Web site</u> for the contact details of our distributor(s) and sales representative(s) in your country.

System and equipment manufacturers and designers are responsible to ensure that their systems, and any Future Technology Devices International Ltd (FTDI) devices incorporated in their systems, meet all applicable safety, regulatory and system-level performance requirements. All application-related information in this document (including application descriptions, suggested FTDI devices and other materials) is provided for reference only. While FTDI has taken care to assure it is accurate, this information is subject to customer confirmation, and FTDI disclaims all liability for system designs and for any applications assistance provided by FTDI. Use of FTDI devices in life support and/or safety applications is entirely at the user's risk, and the user agrees to defend, indemnify and hold harmless FTDI from any and all damages, claims, suits or expense resulting from such use. This document is subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. Neither the whole nor any part of the information contained in, or the product described in this document, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. Future Technology Devices International Ltd, Unit 1, 2 Seaward Place, Centurion Business Park, Glasgow G41 1HH, United Kingdom. Scotland Registered Company Number: SC136640



Appendix A – References

VM800P Datasheet: VM800P Plus board

FT800 datasheet: FT800 Embedded Video Engine

FT800 software programming guide: FT800 Programmer Guide

FT800 sample application notes: <u>AN 246 VM800CB SampleAPP Arduino Introduction</u> <u>http://www.ftdichip.com/Support/Documents/AppNotes/AN 275 FT800 Example with Arduino.pdf</u>



Appendix B - List of Figures and Tables

List of Figures

Figure 3-1 – VA800A PROG module	4
Figure 3-2 - VA800A PROG module Top view	5
Figure 3-3 - VA800A PROG module Bottom view	5
Figure 4-1 - VA800A PROG Schematics	8
Figure 5-1 – ISP Cable	9
Figure 5-2 – Select the Serial Port	10
Figure 5-3 – Select the Board	10
Figure 5-4 – Select the Programmer	11
Figure 5-5 – Burn Bootloader	11
Figure 5-6 – Burning Bootloader	12
Figure 5-7 – Done Burning bootloader	12

List of Tables

Table 2-1 - Ordering information	2
Table 3-1 – CN1 Pinout	6
Table 3-2 – CN2 Pinout	6
Table 3-3 – CN3 Pinout	6





Appendix C – Revision History

Document Title:	VA800A_PROG Module Datasheet
Document Reference No.:	BRT_000006
Clearance No.:	BRT#010
Product Page:	http://brtchip.com/product
Document Feedback:	Send Feedback

Revision	Changes	Date
Version 1.0	Initial Release	2014-05-14
Version 1.1	Dual branding to reflect the migration of the product to the Bridgetek name – logo changed, copyright changed, contact information changed	2016-09-13



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



Как с нами связаться

Телефон: 8 (812) 309 58 32 (многоканальный) **Факс:** 8 (812) 320-02-42 **Электронная почта:** <u>org@eplast1.ru</u> **Адрес:** 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.