



Grove - Relay

Release date: 9/20/2015

Version: 1.0

Wiki: [http://www.seeedstudio.com/wiki/Grove - Relay](http://www.seeedstudio.com/wiki/Grove_-_Relay)

Bazaar: <http://www.seeedstudio.com/depot/Grove-Relay-p-769.html>

Document Revision History

Revision	Date	Author	Description
1.0	Sep 21, 2015	Victor.He	Create file

Contents

Document Revision History.....	2
1. Introduction	2
2. Specifications	3
3. Usage.....	4
3.1 With TI LaunchPad	4
3.2 With Arduino.....	5
3.3 With Raspberry Pi	6
3.3.1 Run the program	7
4. Resources	8

Disclaimer

For physical injuries and possessions loss caused by those reasons which are not related to product quality, such as operating without following manual guide, natural disasters or force majeure, we take no responsibility for that.

Under the supervision of Seeed Technology Inc., this manual has been compiled and published which covered the latest product description and specification. The content of this manual is subject to change without notice.

Copyright

The design of this product (including software) and its accessories is under tutelage of laws. Any action to violate relevant right of our product will be penalized through law. Please consciously observe relevant local laws in the use of this product.

1. Introduction

The Grove-Relay module is a digital normally-open switch. Through it, you can control circuit of high voltage with low voltage, say 5V on the controller. There is an indicator LED on the board, which will light up when the controlled terminals get closed.



2. Specifications


Parameter	v1.1	v1.2
Product Release Date	27th Jan 2013	9th June 2014
Operating Voltage	5V	3.3V~5V
Operating Current	60mA	100mA
Relay Life	100,000 Cycle	100,000 Cycle
Max Switching Voltage	250VAC/30VDC	250VAC/30VDC
Max Switching Current	5A	5A

3. Usage

3.1 With TI LaunchPad

Controlling other electronics (Relay)

This example showcases how to use the Grove-relay module to control larger load, i.e. a desk lamp light. A 3V voltage signal can cause the relay to switch on, allowing current to flow through the connected appliance.



```

/*
Relay
The basic Energia example.
This example code is in the public domain.
*/


#define RELAY_PIN 39

// the setup routine runs once when you press reset:
void setup() {
  pinMode(RELAY_PIN, OUTPUT); // initialize the digital pin as an output.
}

// the loop routine runs over and over again forever:
void loop() {
  digitalWrite(RELAY_PIN, HIGH); // turn the relay on (HIGH is the voltage level)
  delay(1000); // wait for a second
  digitalWrite(RELAY_PIN, LOW); // turn the relay o by making the voltage LOW
  }
  
```

```
delay(1000); // wait for a second
}
```

3.2 With Arduino



Below is a demo that shows you how to control a Grove - Relay with a Grove - Button. When the button gets pressed, the relay will close.

```
// Project Five - Relay Control
//

void setup()
{
  pinMode(1, INPUT);
  pinMode(2, INPUT);
  pinMode(6, OUTPUT);
}

void loop()
{
  if (digitalRead(1)==HIGH)
  {
    digitalWrite(6, HIGH);
    delay(100);
  }
  if (digitalRead(2)==HIGH)
  {


```



```
digitalWrite(6, LOW);  
  
}  
}
```

3.3 With Raspberry Pi

This sample is show you how to use Grove - Relay by Raspberry Pi . The demo below will show that the relay be control by Grove -Button.



```
# Raspberry Pi + Grove Switch + Grove Relay  
  
import time  
import grovepi  
# Connect the Grove Switch to digital port D3  
# SIG,NC,VCC,GND  
  
switch = 3  
# Connect the Grove Relay to digital port D4  
# SIG,NC,VCC,GND  
  
relay = 4  
grovepi.pinMode(switch,"INPUT")  
grovepi.pinMode(relay,"OUTPUT")  
while True:  
try:  
if grovepi.digitalRead(switch):  
grovepi.digitalWrite(relay,1)  
else:
```

```
grovepi.digitalWrite(relay,0)
time.sleep(.05)
except KeyboardInterrupt:
    grovepi.digitalWrite(relay,0)
    break
except IOError:
    print "Error"
```

3.3.1 Run the program

1. Find the path to the file(According to your own path)

```
cd GrovePi/Software/Python/
```

2. Run Program

```
sudo python grove_switch_relay.py
```

4. Resources

[Grove - Relay Eagle File](#)

[Relay Datasheet](#)

[how to upload code](#)

[Buy it](#)



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



Как с нами связаться

Телефон: 8 (812) 309 58 32 (многоканальный)

Факс: 8 (812) 320-02-42

Электронная почта: org@eplast1.ru

Адрес: 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.