



Grove - 2-Coil Latching Relay

Release date : 9/20/2015

Version : 1.0

Wiki: [http://www.seeedstudio.com/wiki/Grove - 2-Coil Latching Relay](http://www.seeedstudio.com/wiki/Grove_-_2-Coil_Latching_Relay)

Bazaar: <http://www.seeedstudio.com/depot/Grove-2Coil-Latching-Relay-p-1446.html>

Document Revision History

| Revision | Date | Author | Description |
|----------|--------------|-----------|-------------|
| 1.0 | Sep 21, 2015 | Victor.He | Create file |
| | | | |

Contents

| | |
|---------------------------|---|
| Document Revision History | 2 |
| 1. Introduction | 2 |
| 2. Features | 3 |
| 3. Specifications | 4 |
| 4. Usage | 5 |
| 4.1 With Arduino | 5 |
| 4.2 With Raspberry Pi | 6 |
| 5. Resource | 8 |
| 6. Support | 9 |

Disclaimer

For physical injuries and possessions loss caused by those reasons which are not related to product quality, such as operating without following manual guide, natural disasters or force majeure, we take no responsibility for that.


Under the supervision of Seeed Technology Inc., this manual has been compiled and published which covered the latest product description and specification. The content of this manual is subject to change without notice.

Copyright

The design of this product (including software) and its accessories is under tutelage of laws. Any action to violate relevant right of our product will be penalized through law. Please consciously observe relevant local laws in the use of this product.

1. Introduction

This module is based on 2-Coil Latching Relay. Contrast to the ordinary relay, this latching relay does not need continuous power to keep the state, only a rising/falling pulse is needed to change the work state. Even the power can be removed when the work state do not need to change, making this module especially suitable for low-power projects.



2. Features

- Grove Connector
- Low power consumption
- Dual Switch

3. Specifications

| Item | Min | Typical | Max | Unit |
|------------------------|-------------|---------|-----|----------|
| Working Voltage | 4.7 | 5.0 | 5.3 | VDC |
| Set/Reset Voltage(Max) | 4.0 | | VDC | |
| Coil Resistance | 151 | 167 | 183 | Ω |
| Switching Voltage(Max) | 35VAC/35VDC | | / | |
| Switching Current(Max) | 3 | | A | |
| Set Time(Latching) | 4.5(max) | | ms | |
| Reset Time(Latching) | 3.5(max) | | ms | |

4. Usage

4.1 With Arduino

The latching relay only draws power during the changing of state. A rising/falling voltage pulse on the signal pin changes it's working state. This is very useful in situations where energy efficiency is important, and also in situations where you need the relay to remember its state.

Let's begin to use it.

- Connect the module to D3 port of [Grove - Base Shield](#).
- The relay hold in "set" status(Comm and NO connected) in default, when there is a rising edge on the SIG pin. It turns the "reset" state(Comm and NC connected). The reference code as show below:

```
#define LatchingRelay 3
void setup()
{
  pinMode(LatchingRelay,OUTPUT);

  digitalWrite(LatchingRelay,LOW);
  delay(1000);
  digitalWrite(LatchingRelay,HIGH);
  delay(1000);
}
void loop()
{
}
}
```

- The relay hold in "reset" status(Comm and NC Connected), when there is a falling edge on the SIG pin. It turns the "set" state(Comm and NO connected). The reference code as show below:

```
#define LatchingRelay 3
void setup()
{
  pinMode(LatchingRelay,OUTPUT);

  digitalWrite(3,HIGH);
  delay(1000);
}
```



```
digitalWrite(3,LOW);
delay(1000);
}
void loop()
{
}
}
```

- This module consumes little power when working state doesn't change. After setting the relay state, you do not need to supply power for the Latching Relay any more, which makes it especially low power consumption.

Note:

- 1) Relay is on the "reset" status when being released from stock.




Diagram shows the "reset" position
Energize terminals 1 and 16 to "set"
Energize terminals 2 and 15 to "reset"

- 2) The two-way relay are controlled at the same time.
- 3) The NO (NC) indicator will flash once when switch to "set"("reset") status.

4.2 With [Raspberry Pi](#)

1. You should have got a raspberry pi and a grovepi or grovepi+.
2. You should have completed configuring the development environment, otherwise follow [here](#).
3. Connection. Plug the sensor to grovepi socket D4 by using a grove cable.
4. Navigate to the demos' directory:

```
cd yourpath/GrovePi/Software/Python/
```

To see the code

```
nano grove_solid_state_relay.py # "Ctrl+x" to exit #
```

```
import time
import grovepi

# Connect the Grove Solid State Relay to digital port D4
# CTR,NC,VCC,GND
relay = 4

grovepi.pinMode(relay,"OUTPUT")

while True:
    try:
        # switch on for 5 seconds
        grovepi.digitalWrite(relay,1)
        print "on"
        time.sleep(5)

        # switch off for 5 seconds
        grovepi.digitalWrite(relay,0)
        print "off"
        time.sleep(5)

    except KeyboardInterrupt:
        grovepi.digitalWrite(relay,0)
        break
    except IOError:
        print "Error"}
```

5. Run the demo.

```
sudo python grove_solid_state_relay.py
```

5. Resource

[Grove - 2-Coil Latching Relay Eagle File](#)

[Latching Relay Datasheet](#)

6. Support

[Ask questions on Seeed forum.](#)



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



Как с нами связаться

Телефон: 8 (812) 309 58 32 (многоканальный)

Факс: 8 (812) 320-02-42

Электронная почта: org@eplast1.ru

Адрес: 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.