

1SP0340x2x0-CM1200HC-90RA

Preliminary Data Sheet

Compact, high-performance, plug-and-play single-channel IGBT driver based on SCALE™-2 technology for individual and parallel-connected modules in 2-level, 3-level and multilevel converter topologies

Abstract

The SCALE™-2 plug-and-play driver 1SP0340x2x0-CM1200HC-90RA is a compact single-channel intelligent gate driver designed for Mitsubishi IGBTs CM1200HC-90RA. The master driver 1SP0340V2M0-CM1200HC-90RA features a fiber-optic interface. It can be used as stand-alone driver or in conjunction with up to three 1SP0340D2S0-CM1200HC-90RA slaves to drive up to four parallel-connected IGBT modules of type CM1200HC-90RA.

The DC/DC power supply must be purchased as a separate unit (one per master driver).

For drivers adapted to other types of high-power and high-voltage IGBT modules, refer to:

www.power.com/igbt-driver/go/Plug-and-Play

Features

- ✓ Plug-and-play solution
- ✓ Allows parallel connection of IGBT modules
- ✓ For 2-level, 3-level and multilevel topologies
- ✓ Fiber-optic links (master)
- ✓ Built-in interface to 1SP0340D2S0 (slave)
- ✓ Duty cycle 0...100%
- ✓ Dynamic Advanced Active Clamping DA²C
- ✓ Dynamic IGBT short-circuit protection
- ✓ Monitoring of supply voltage
- ✓ Monitoring of gate voltage
- ✓ Extremely reliable; long service life
- ✓ Shortens application development time
- ✓ Suitable for CM1200HC-90RA
- ✓ Lead-free

Applications

- ✓ Traction
- ✓ Railroad power supplies
- ✓ Light rail vehicles
- ✓ HVDC
- ✓ Flexible AC transmission systems (FACTS)
- ✓ Medium-voltage converters
- ✓ Industrial drives
- ✓ Wind-power converters
- ✓ Medical applications
- ✓ Research
- ✓ And many others

Preliminary Data Sheet

Safety Notice!

The data contained in this data sheet is intended exclusively for technically trained staff. Handling all high-voltage equipment involves risk to life. Strict compliance with the respective safety regulations is mandatory!

Any handling of electronic devices is subject to the general specifications for protecting electrostatic-sensitive devices according to international standard IEC 60747-1, Chapter IX or European standard EN 100015 (i.e. the workplace, tools, etc. must comply with these standards). Otherwise, this product may be damaged.

Important Product Documentation

This data sheet contains only product-specific data. For a detailed description, must-read application notes and common data that apply to the whole series, please refer to the "Description & Application Manual for 1SP0340 SCALE-2 IGBT Drivers" on www.power.com/igbt-driver/go/1SP0340.

When applying SCALE-2 plug-and-play drivers, please note that these drivers are specifically adapted to a particular type of IGBT module. Therefore, the type designation of SCALE-2 plug-and-play drivers also includes the type designation of the corresponding IGBT module. These drivers are not valid for IGBT modules other than those specified. Incorrect use may result in failure.

Mechanical Dimensions

Dimensions: Refer to the relevant "Description and Application Manual"

Mounting principle: Connected to IGBT module with screws

Fiber-Optic Interfaces (1SP0340V2M0)

| Interface | Remarks | Part type # |
|--------------------|--------------------------------------|--------------|
| Drive signal input | Fiber-optic receiver (Notes 1, 2) | HFBR-2522ETZ |
| Status output | Fiber-optic transmitter (Notes 1, 3) | HFBR-1522ETZ |

Electrical Connectors

| Interface | Remarks | Part type # |
|---------------------------|------------------------------|-------------|
| Power supply connector X1 | On-board connector (Note 4) | 214012 |
| Bus connectors X2 and X3 | On-board connectors (Note 5) | 214013 |

Preliminary Data Sheet

Absolute Maximum Ratings

| Parameter | Remarks | Min | Max | Unit |
|---------------------------------|--|-----|------|-------------------|
| Supply voltage V_{DC} | VDC to COM | 0 | 30 | V |
| Average supply current I_{DC} | 1SP0340V2M0 only (Note 6) | | 180 | mA |
| Average supply current I_{DC} | 1SP0340V2M0 with three 1SP0340D2S0 (Note 6) | | 620 | mA |
| Gate output power | $T_a \leq 70^\circ\text{C}$ | | 2.8 | W |
| | $T_a \leq 85^\circ\text{C}$ | | 2.1 | W |
| Switching frequency f | $T_a \leq 70^\circ\text{C}$ | | 8.7 | kHz |
| | $T_a \leq 85^\circ\text{C}$ | | 6.5 | kHz |
| Gate peak current I_{out} | Note 7 | -35 | +35 | A |
| DC-link voltage | Switching operation (Note 8) | | 3000 | V |
| | Off state (Note 9) | | 3550 | V |
| Operating voltage | Collector-emitter voltage | | 4500 | V_{peak} |
| Emitter-emitter voltage | Between parallel connected drivers (Note 10) | | 200 | V_{peak} |
| $ dV/dt $ | Between parallel connected drivers (Note 11) | | 50 | kV/ μs |
| Interface current | X2 and X3, total RMS value (Note 12) | | 4 | A_{rms} |
| | X2 and X3, total peak value (Note 12) | | 20 | A_{peak} |
| Operating temperature | | -40 | +85 | $^\circ\text{C}$ |
| Storage temperature | | -40 | +90 | $^\circ\text{C}$ |

Recommended Operating Conditions

| Power Supply | Remarks | Min | Typ | Max | Unit |
|-------------------------|---------|------|-----|------|------|
| Supply voltage V_{DC} | To COM | 23.5 | 25 | 26.5 | V |

Preliminary Data Sheet

| |
|-----------------------------------|
| Electrical Characteristics |
|-----------------------------------|

All data refer to +25°C and $V_{DC} = 25V$ unless otherwise specified

| Power Supply | Remarks | Min | Typ | Max | Unit |
|---------------------------------------|--|------|------|------|------|
| Supply current I_{DC} | Without load, only 1SP0340V2M0 | | 47 | | mA |
| | Without load, per additional 1SP0340D2S0 | | 20 | | mA |
| Power Supply Monitoring | Remarks | Min | Typ | Max | Unit |
| Supply threshold $V_{iso}-V_{ee}$ | Clear fault | 11.6 | 12.6 | 13.6 | V |
| | Set fault (Note 13) | 11.0 | 12.0 | 13.0 | V |
| Monitoring hysteresis | Set/clear fault | 0.35 | | | V |
| Supply threshold $V_{ee}-V_{COM}$ | Clear fault | | 5.15 | | V |
| | Set fault (Note 13) | | 4.85 | | V |
| Monitoring hysteresis | Set/clear fault | | 0.3 | | V |
| Bus to 1SP0340D2S0 | Remarks | Min | Typ | Max | Unit |
| Supply voltage | | | VDC | | |
| Turn-off command | To COM | | 0 | | V |
| Turn-on command | To COM | | 15 | | V |
| Gate Monitoring | Remarks | Min | Typ | Max | Unit |
| Turn-on threshold $V_{GE,on,min}$ | G_{mean} to E, set fault (Note 14) | | 12.9 | | V |
| Turn-off threshold $V_{GE,off,max}$ | G_{mean} to E, set fault (Note 14) | | -7.6 | | V |
| Filter delay | Turn-on (Note 14) | | 32 | | µs |
| | Turn-off (Note 14) | | 47 | | µs |
| Short-circuit Protection | Remarks | Min | Typ | Max | Unit |
| Static V_{CE} -monitoring threshold | Between auxiliary terminals (Note 15) | | 170 | | V |
| Response time | DC-link voltage = 3000V (Note 16) | | 6.5 | | µs |
| | DC-link voltage = 2000V (Note 16) | | 6.5 | | µs |
| | DC-link voltage = 1500V (Note 16) | | 6.5 | | µs |
| | DC-link voltage = 1000V (Note 16) | | 9.7 | | µs |
| Delay to IGBT turn-off t_{CSHD} | After the response time (Note 17) | | 0.3 | | µs |
| Timing Characteristics | Remarks | Min | Typ | Max | Unit |
| Turn-on delay $t_{d(on)}$ | Note 18 | | 170 | | ns |
| Turn-off delay $t_{d(off)}$ | Note 18 | | 160 | | ns |
| Output rise time $t_{r(out)}$ | G to E (Note 19) | | 10 | | ns |
| Output fall time $t_{f(out)}$ | G to E (Note 19) | | 25 | | ns |

Preliminary Data Sheet

| Timing Characteristics | Remarks | Min | Typ | Max | Unit |
|--|--|-----|-----|------|---------|
| Transmission delay of fault state | Note 20 | | 90 | | ns |
| Delay to clear fault state $t_{(block)}$ | After IGBT short circuit (Note 21) | | 9 | | μ s |
| | After gate-monitoring fault (Notes 21, 25) | | 1 | | μ s |
| Acknowledge delay time $t_{d(ack)}$ | Note 22 | | 230 | | ns |
| Acknowledge pulse width $t_{(ack)}$ | On host side | 400 | 700 | 1050 | ns |

| Gate Output | Remarks | Min | Typ | Max | Unit |
|-------------------------------------|---------|-----|---------------|-----|----------|
| Turn-on gate resistor $R_{g(on)}$ | Note 23 | | 2.8 | | Ω |
| Turn-off gate resistor $R_{g(off)}$ | Note 23 | | 34 | | Ω |
| Auxiliary gate capacitor C_{ge} | | | not assembled | | nF |
| Gate voltage at turn-on | Note 24 | | 15 | | V |
| Gate-voltage at turn-off | Note 24 | | -10 | | V |

Footnotes to the Key Data

- 1) The transceivers required on the host controller side are not supplied with the gate driver. It is recommended to use the same types as used in the gate driver. For product information refer to www.power.com/igbt-driver/go/fiberoptics.
- 2) The recommended transmitter current at the host controller is 20mA. A higher current may increase jitter or delay at turn-off.
- 3) The typical transmitter current at the gate driver is 20mA. In case of supply undervoltage, the minimum transmitter current at the gate driver is 14mA: this is suitable for adequate plastic optical fibers with a length up to 10 meters.
- 4) This refers to the manufacturer ordering number, see www.power.com/igbt-driver/go/ext_erni. The customer-side connector as well as cables with different lengths can be supplied by Power Integrations. Refer to the "Description & Application Manual for 1SP0340 SCALE-2 IGBT Drivers" for more information.
- 5) This refers to the manufacturer ordering number, see www.power.com/igbt-driver/go/ext_erni. These connectors are to be used to connect 1SP0340V2M0 (master) or 1SP0340D2S0 (slave) to 1SP0340D2S0 (slave) if parallel connection of IGBT modules is required. Cables with different lengths can be supplied by Power Integrations. Refer to the "Description & Application Manual for 1SP0340 SCALE-2 IGBT Drivers" for more information.
- 6) If the specified value is exceeded, this indicates a driver overload. It should be noted that the driver is not protected against overload.
- 7) The gate current is limited by the gate resistors located on the driver and the load.
- 8) This limit is due to active clamping under switching conditions. Refer to the "Description & Application Manual for 1SP0340 SCALE-2 IGBT Drivers".
- 9) Due to the Dynamic Active Advanced Clamping Function (DA²C) implemented on the driver, the DC-link voltage can be increased in the off-state condition (e.g. after emergency shut-down). This value is only valid when the IGBTs are in the off state (not switching). The time during which the voltage can be applied should be limited to short periods (< 60 seconds). Refer to the "Description & Application Manual for 1SP0340 SCALE-2 IGBT Drivers".
- 10) The maximum dynamic voltage between auxiliary emitters of parallel-connected drivers due to asymmetrical operation at turn-on and turn-off must be limited to the given value.
- 11) Maximum allowed rate of change between auxiliary emitter voltages of parallel connected drivers.
- 12) Dynamic voltages between auxiliary emitters of parallel connected drivers at turn-on and turn-off lead to equalizing currents over the X2 or X3 bus. The peak and RMS values of the resulting current must be limited to the given value.
- 13) Undervoltage monitoring of the secondary-side supply voltage (Viso to Vee and Vee to COM which correspond with the approximate turn-on and turn-off gate-emitter voltages). If the corresponding

Preliminary Data Sheet

voltage drops below this limit on 1SP0340V2M0 (masters), all paralleled IGBTs (master and slaves) are switched off and a fault is transmitted to the status output. If the corresponding voltage drops below this limit on 1SP0340D2S0 (slaves), the corresponding IGBT is switched off. If the IGBT was turned on, a fault will be generated by the gate-monitoring function on the master which will turn off all paralleled IGBT after the corresponding delay.

- 14) The average value $V_{GE,mean}$ of all gate voltages (master and all slaves) is filtered and compared to the given values at turn-on and turn-off. If the specified values are exceeded ($V_{GE,mean} < V_{GE,on,min}$ at turn-on resp. $V_{GE,mean} > V_{GE,off,max}$ at turn-off) after the given filter delay, the driver turns off all parallel-connected IGBTs and a fault is transmitted to the status output.
- 15) A dynamic V_{CE} protection is implemented on the driver. The maximum allowed V_{CE} voltage at turn-on is dynamically adjusted in order to better fit to the IGBT characteristics at turn-on. At the end of the turn-on process the given static value applies.
- 16) The resulting pulse width of the direct output of the gate drive unit for short-circuit type I (excluding the delay of the gate resistors) is the sum of the response time plus the delay to IGBT turn-off.
- 17) The turn-off event of the IGBT is delayed by the specified time after the response time.
- 18) Including the delay of the external fiber-optic links (cable length: 1m). Measured from the transition of the turn-on or turn-off command at the optical transmitter on the host controller side to the direct output of the gate drive unit (excluding the delay of the gate resistors).
- 19) Output rise and fall times are measured between 10% and 90% of the nominal output swing. The values are given for the driver side of the gate resistors with $2\Omega/1\mu F$ load. The time constant of the output load in conjunction with the present gate resistors leads to an additional delay at their load side.
- 20) Delay of external fiber-optic links. Measured from the driver secondary side (ASIC output) to the optical receiver on the host controller with a 1m cable.
- 21) Measured on the host side. The fault status on the secondary side is automatically reset after the specified time.
- 22) Including the delay of the external fiber-optic links (cable length: 1m). Measured from the transition of the turn-on or turn-off command at the optical transmitter on the host controller side to the transition of the acknowledge signal at the optical receiver on the host controller side.
- 23) The gate resistors can be leaded or surface mounted. Power Integrations reserves the right to determine which type will be used. Typically, higher quantities will be produced with SMD resistors and small quantities with leaded resistors.
- 24) The driver supply voltage VDC is split into two distinct voltages on the driver. The first one is the turn-on voltage which is regulated at about 15V. The difference between VDC and the turn-on voltage is the turn-off voltage which is not regulated and mainly dependent on the driver input voltage VDC.
- 25) The given value applies if the driver goes from the "off state" to the "on state" and the gate-emitter voltage of one or more parallel connected drivers does not turn on. If the driver goes from the "on state" to the "off state" and the gate-emitter voltage of one or more parallel connected drivers does not turn off, the fault status is applied as long as the gate monitoring fault is present.

Preliminary Data Sheet

Legal Disclaimer

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. All parameters, numbers, values and other technical data included in the technical information were calculated and determined to our best knowledge in accordance with the relevant technical norms (if any). They may base on assumptions or operational conditions that do not necessarily apply in general. We exclude any representation or warranty, express or implied, in relation to the accuracy or completeness of the statements, technical information and recommendations contained herein. No responsibility is accepted for the accuracy or sufficiency of any of the statements, technical information, recommendations or opinions communicated and any liability for any direct, indirect or consequential loss or damage suffered by any person arising therefrom is expressly disclaimed.

 Preliminary Data Sheet

Ordering Information

The general terms and conditions of delivery of Power Integrations Switzerland GmbH apply.

| Interface | Power Integrations Driver Type # | Related IGBT |
|-------------------------------|----------------------------------|---------------|
| Master, Fiber-Optic Interface | 1SP0340V2M0-CM1200HC-90RA | CM1200HC-90RA |
| Slave, Electrical Interface | 1SP0340D2S0-CM1200HC-90RA | CM1200HC-90RA |

Product home page: www.power.com/igbt-driver/go/1SP0340

Refer to www.power.com/igbt-driver/go/nomenclature for information on driver nomenclature

Information about Other Products

For other drivers, product documentation and application support:

Please click onto: www.power.com/igbt-driver

Manufacturer

Power Integrations Switzerland GmbH
 Johann-Renfer-Strasse 15
 2504 Biel-Bienne, Switzerland

Phone +41 32 344 47 47
 Fax +41 32 344 47 40
 Email igbt-driver.sales@power.com
 Website www.power.com/igbt-driver

© 2012...2015 Power Integrations Switzerland GmbH.

We reserve the right to make any technical modifications without prior notice.

All rights reserved.
 Version 1.0 from 2016-05-20

Preliminary Data Sheet

Power Integrations Worldwide High Power Customer Support Locations

World Headquarters

5245 Hellyer Avenue
 San Jose, CA 95138 | USA
 Main +1 408 414 9200
 Customer Service:
 Phone +1 408 414 9665
 Fax +1 408 414 9765
 Email usasales@power.com

Switzerland (Biel)

Johann-Renfer-Strasse 15
 2504 Biel-Bienne | Switzerland
 Phone +41 32 344 47 47
 Fax +41 32 344 47 40
 Email igbt-driver.sales@power.com

Germany (Ense)

HellwegForum 1
 59469 Ense | Germany
 Phone +49 2938 643 9990
 Email igbt-driver.sales@power.com

Germany (Munich)

Lindwurmstrasse 114
 80337 Munich | Germany
 Phone +49 895 527 39110
 Fax +49 895 527 39200
 Email eurossales@power.com

China (Shanghai)

Rm 2410, Charity Plaza, No. 88
 North Caoxi Road
 Shanghai, PRC 200030
 Phone +86 21 6354 6323
 Fax +86 21 6354 6325
 Email chinasales@power.com

China (Shenzhen)

17/F, Hivac Building, No 2,
 Keji South 8th Road,
 Nanshan District
 Shenzhen | China, 518057
 Phone +86 755 8672 8725
 Fax +86 755 8672 8690
 Hotline +86 400 0755 669
 Email chinasales@power.com

Italy (Milano)

Via Milanese 20, 3rd. Fl.
 20099 Sesto San Giovanni | Italy
 Phone +39 024 550 8701
 Fax +39 028 928 6009
 Email eurossales@power.com

UK (Herts)

First Floor, Unit 15, Meadway Court,
 Rutherford Close, Stevenage,
 Herts SG1 2EF | United Kingdom
 Phone +44 1252 730 141
 Fax +44 1252 727 689
 Email eurossales@power.com

India (Bangalore)

#1, 14th Main Road
 Vasanthanagar
 Bangalore 560052 | India
 Phone +91 80 4113 8020
 Fax +91 80 4113 8023
 Email indiasales@power.com

Japan (Kanagawa)

Kosei Dai-3 Bldg., 2-12-11, Shin-
 Yokohama, Kohoku-ku, Yokohama-shi,
 Kanagawa 222-0033 | Japan
 Phone +81 45 471 1021
 Fax +81 45 471 3717
 Email japansales@power.com

Korea (Seoul)

RM 602, 6FL
 Korea City Air Terminal B/D, 159-6
 Samsung-Dong, Kangnam-Gu
 Seoul 135-728 | Korea
 Phone +82 2 2016 6610
 Fax +82 2 2016 6630
 Email koreasales@power.com

Taiwan (Taipei)

5F, No. 318, Nei Hu Rd., Sec. 1
 Nei Hu Dist.
 Taipei 11493 | Taiwan R.O.C.
 Phone +886 2 2659 4570
 Fax +886 2 2659 4550
 Email taiwansales@power.com



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



Как с нами связаться

Телефон: 8 (812) 309 58 32 (многоканальный)

Факс: 8 (812) 320-02-42

Электронная почта: org@eplast1.ru

Адрес: 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.