

## Class R Fuseblocks Catalog Data

| Catalog Number | Covers         |               | Voltage | Current | Number of Poles | Label       |
|----------------|----------------|---------------|---------|---------|-----------------|-------------|
| Class R        | w/o Indication | w/ Indication |         |         |                 |             |
| RM25100-1CR    | CVR-RH-25100   | CVRI-RH-25100 | 250     | 100     | 1               | RM25100-1CR |
| RM25100-2CR    |                |               |         |         | 2               | RM25100-2CR |
| RM25100-3CR    |                |               |         |         | 3               | RM25100-3CR |
| RM25200-1CR    | CVR-RH-25200   | CVRI-RH-25200 |         | 200     | 1               | RM25200-1CR |
| RM25200-2CR    |                |               |         |         | 2               | RM25200-2CR |
| RM25200-3CR    |                |               |         |         | 3               | RM25200-3CR |
| RM25400-1CR    | CVR-RH-25400   | CVRI-RH-25400 |         | 400     | 1               | RM25400-1CR |
| RM25400-2CR    |                |               |         |         | 2               | RM25400-2CR |
| RM25400-3CR    |                |               |         |         | 3               | RM25400-3CR |
| RM25600-1CR    | CVR-RH-25600   | CVRI-RH-25600 |         | 600     | 1               | RM25600-1CR |
| RM25600-2CR    |                |               |         |         | 2               | RM25600-2CR |
| RM25600-3CR    |                |               |         |         | 3               | RM25600-3CR |

| Catalog Number | Covers         |               | Voltage | Current | Number of Poles | Label       |
|----------------|----------------|---------------|---------|---------|-----------------|-------------|
| Class R        | w/o Indication | w/ Indication |         |         |                 |             |
| RM60100-1CR    | CVR-RH-60100   | CVRI-RH-60100 | 600     | 100     | 1               | RM60100-1CR |
| RM60100-2CR    |                |               |         |         | 2               | RM60100-2CR |
| RM60100-3CR    |                |               |         |         | 3               | RM60100-3CR |
| RM60200-1CR    | CVR-RH-60200   | CVRI-RH-60200 |         | 200     | 1               | RM60200-1CR |
| RM60200-2CR    |                |               |         |         | 2               | RM60200-2CR |
| RM60200-3CR    |                |               |         |         | 3               | RM60200-3CR |
| RM60400-1CR    | CVR-RH-60400   | CVRI-RH-60400 |         | 400     | 1               | RM60400-1CR |
| RM60400-2CR    |                |               |         |         | 2               | RM60400-2CR |
| RM60400-3CR    |                |               |         |         | 3               | RM60400-3CR |
| RM60600-1CR    | CVR-RH-60600   | CVRI-RH-60600 |         | 600     | 1               | RM60600-1CR |
| RM60600-2CR    |                |               |         |         | 2               | RM60600-2CR |
| RM60600-3CR    |                |               |         |         | 3               | RM60600-3CR |

**COOPER Bussmann**  
St. Louis MO 63178


TITLE:

**Class R fuse holder-CUST**



SCALE:  
1:1

SIZE:  
A3


SHEET:  
1 OF 14




PUSH DOWN



LIFT UP



LIFT UP , THEN  
ROTATE OVER



**COOPER Bussmann**  
St. Louis MO 63178


TITLE:

**Class R fuse holder-CUST**


SCALE:  
1:2

SIZE:  
A3


SHEET:  
2 OF 14









### RM25100-2CR



### RM25100-2CR WITH CVR-RH-25100 INSTALLED



### RM25100-2CR WITH CVRI-RH-25100 INSTALLED



**COOPER Bussmann**  
St. Louis MO 63178

TITLE:


**Class R fuse holder-CUST-250V**

SCALE:  
1:1


SIZE:  
A3

SHEET:  
4 OF 14







### RM25100-3CR



### RM25100-3CR WITH CVR-RH-25100 INSTALLED



### RM25100-3CR WITH CVRI-RH-25100 INSTALLED



**COOPER Bussmann**  
St. Louis MO 63178

TITLE:

**Class R fuse holder-CUST-250V**




SCALE:  
1:1

SIZE:  
A3



SHEET:  
5 OF 14

# RM25200-1CR



ALLEN KEY #:  
3/8"(10.0MM)



# RM25200-1CR WITH CVR-RH-25200 INSTALLED





# CVR-RH-25200




# RM25200-1CR WITH CVRI-RH-25200 INSTALLED

**WARNING**  
TO AVOID ELECTRICAL SHOCK, TURN POWER OFF BEFORE INSTALLING, REMOVING OR SERVICING.



# CVRI-RH-25200




**COOPER Bussmann**  
St. Louis MO 63178


**Class R fuse holder-CUST-250V**

SCALE: 1:1 SIZE: A3 SHEET: 6 OF 14







### RM25200-2CR



### RM25200-2CR WITH CVR-RH-25200 INSTALLED



### RM25200-2CR WITH CVRI-RH-25200 INSTALLED



**COOPER Bussmann**  
St. Louis MO 63178

TITLE:


**Class R fuse holder-CUST-250V**

SCALE:  
1:1


SIZE:  
A3

SHEET:  
7 OF 14






# RM25200-3CR



# RM25200-3CR WITH CVR-RH-25200 INSTALLED



# RM25200-3CR WITH CVRI-RH-25200 INSTALLED



**COOPER Bussmann**  
St. Louis MO 63178




TITLE:

**Class R fuse holder-CUST-250V**


SCALE:  
1:1

SIZE:  
A3


SHEET:  
8 OF 14









### RM25400-2CR



### RM25400-2CR WITH CVR-RH-25400 INSTALLED



### RM25400-2CR WITH CVRI-RH-25400 INSTALLED



REMOVE FOR WIRES  
ABOVE 250 KCMIL

**COOPER Bussmann**  
St. Louis MO 63178

TITLE:


**Class R fuse holder-CUST-250V**

SCALE:  
1:1


SIZE:  
A3

SHEET:  
10 OF 14







RM25400-3CR




RM25400-3CR  
WITH CVR-RH-25400 INSTALLED




RM25400-3CR  
WITH CVRI-RH-25400 INSTALLED




### RM25600-1CR





### RM25600-1CR WITH CVR-RH-25600 INSTALLED




### RM25600-1CR WITH CVRI-RH-25600 INSTALLED






**WARNING**  
TO AVOID ELECTRICAL SHOCK, TURN POWER OFF BEFORE INSTALLING, REMOVING OR SERVICING.



### CVR-RH-25600



### CVRI-RH-25600



CUT OPEN ALONG THIS DOTTED LINE FOR WIRES ABOVE 250 KCMIL

**COOPER Bussmann**  
St. Louis MO 63178








**Class R fuse holder-CUST-250V**

SCALE: 1:1 SIZE: A3 SHEET: 12 OF 14

### RM25600-2CR

### RM25600-2CR WITH CVR-RH-25600 INSTALLED

### RM25600-2CR WITH CVRI-RH-25600 INSTALLED




**COOPER Bussmann**  
St. Louis MO 63178


TITLE:  
**Class R fuse holder-CUST-250V**

SCALE: 1:1 SIZE: A3 SHEET: 13 OF 14







### RM25600-3CR



### RM25600-3CR WITH CVR-RH-25600 INSTALLED



### RM25600-3CR WITH CVRI-RH-25600 INSTALLED



**COOPER Bussmann**  
St. Louis MO 63178

TITLE:




**Class R fuse holder-CUST-250V**

SCALE:  
1:1




SIZE:  
A3

SHEET:  
14 OF 14

**RM60100-1CR  
WITH CVRI-RH-60100 INSTALLED**



**CVRI-RH-60100**



CUT OPEN ALONG  
THIS DOTTED LINE  
FOR WIRES ABOVE  
6 AWG

**COOPER Bussmann**  
St. Louis MO 63178


TITLE:


**Class R fuse holder-CUST-600V**

SCALE:  
1:

SIZE:  
A3

SHEET:  
1 OF 12





**COOPER Bussmann**  
St. Louis MO 63178


---


TITLE:

## Class R fuse holder-CUST-600V

---

SCALE: 1:1
SIZE: A3
SHEET: 3 OF 12





**COOPER Bussmann**  
St. Louis MO 63178

TITLE: **Class R fuse holder-CUST-600V**


SCALE: 1:1

SIZE: A3

SHEET: 5 OF 12

www.Bussmann.com

Drawing template A3 - Rev 05



**COOPER Bussmann**  
St. Louis MO 63178

---

TITLE:


## Class R fuse holder-CUST-600V


---

SCALE: 1:1

SIZE: A3

SHEET: 6 OF 12






**COOPER Bussmann**  
St. Louis MO 63178

---

TITLE: **Class R fuse holder-CUST-600V**

---

SCALE: 1:1
SIZE: A3
SHEET: 8 OF 12



**COOPER Bussmann**  
St. Louis MO 63178


TITLE:


## Class R fuse holder-CUST-600V

SCALE: 1:1

SIZE: A3

SHEET: 9 OF 12





**COOPER Bussmann**

St. Louis MO 63178

TITLE:

## Class R fuse holder-CUST-600V


SCALE: 1:5

SIZE: A3

SHEET: 11 OF 12

www.Bussmann.com

Drawing template A3 - Rev 05



**COOPER Bussmann**  
St. Louis MO 63178

---

TITLE:

## Class R fuse holder-CUST-600V

---

SCALE:  
1:5

SIZE:  
A3

SHEET:  
12 OF 12



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



#### Как с нами связаться

**Телефон:** 8 (812) 309 58 32 (многоканальный)

**Факс:** 8 (812) 320-02-42

**Электронная почта:** [org@eplast1.ru](mailto:org@eplast1.ru)

**Адрес:** 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.