

# **PWM DC/DC Controller with VID Inputs for Portable GPU Core-Voltage Regulator**

# ISL95870, ISL95870A, ISL95870B

The ISL95870, ISL95870A, ISL95870B ICs are Single-Phase Synchronous-Buck PWM regulators featuring Intersil's proprietary R<sup>4</sup> Technology<sup>™</sup>. The wide 3.3V to 25V input voltage range is ideal for systems that run on battery or AC-adapter power sources. The ISL95870A and ISL95870B are low-cost solutions for applications requiring dynamically selected slew-rate controlled output voltages. The soft-start and dynamic setpoint slew-rates are capacitor programmed. Voltage identification logic-inputs select four (ISL95870A, ISL95870B) resistor-programmed setpoint reference voltages that directly set the output voltage of the converter between 0.5V and 1.5V, and up to 5V with a feedback voltage divider.

Compared with R<sup>3</sup> modulator, the R<sup>4</sup> modulator has equivalent light-load efficiency, faster transient performance, accurately regulated frequency control and all internal compensation. These updates, together with integrated MOSFET drivers and schottky bootstrap diode, allow for a high-performance regulator that is highly compact and needs few external components. The differential remote sensing for output voltage and selectable switching frequency are another two new functions. For maximum efficiency, the converter automatically enters diode-emulation mode (DEM) during light-load conditions such as system standby.

1

### **Features**

- Input Voltage Range: 3.3V to 25V
- Output Voltage Range: 0.5V to 5V
- Precision Regulation
  - Proprietary R<sup>4</sup><sup>™</sup> Frequency Control Loop
  - ±0.5% System Accuracy Over -10°C to +100°C
- Optimal Transient Response
  - Intersil's R<sup>4</sup>™ Modulator Technology
- Output Remote Sense
- Extremely Flexible Output Voltage Programmability
  - 2-Bit VID Selects Four Independent Setpoint Voltages for ISL95870B
  - 2-Bit VID Selects Four Dependent or Three Independent Setpoint Voltages for ISL95870A
  - Simple Resistor Programming of Setpoint Voltages
- Selectable 300kHz, 500kHz, 600kHz or 1MHz PWM Frequency in Continuous Conduction
- Automatic Diode Emulation Mode for Highest Efficiency
- Power-Good Monitor for Soft-Start and Fault Detection

### **Applications**\*(see page 26)

- Mobile PC Graphical Processing Unit VCC Rail
- Mobile PC I/O Controller Hub (ICH) VCC Rail
- Mobile PC Memory Controller Hub (GMCH) VCC Rail



FIGURE 1. ISL95870 APPLICATION SCHEMATIC WITH ONE OUTPUT VOLTAGE SETPOINT AND DCR CURRENT SENSE

CAUTION: These devices are sensitive to electrostatic discharge; follow proper IC Handling Procedures. 1-888-INTERSIL or 1-888-468-3774 | Intersil (and design) is a registered trademark of Intersil Americas Inc. Copyright Intersil Americas Inc. 2009. All Rights Reserved

# **Applications Schematics: ISL95870**



FIGURE 2. ISL95870 APPLICATION SCHEMATIC WITH ONE OUTPUT VOLTAGE SETPOINT AND DCR CURRENT SENSE



FIGURE 3. ISL95870 APPLICATION SCHEMATIC WITH ONE OUTPUT VOLTAGE SETPOINT AND RESISTOR CURRENT SENSE

# Applications Schematics: ISL95870A



FIGURE 4. ISL95870A APPLICATION SCHEMATIC WITH FOUR OUTPUT VOLTAGE SETPOINTS AND DCR CURRENT SENSE



#### FIGURE 5. ISL95870A APPLICATION SCHEMATIC WITH FOUR OUTPUT VOLTAGE SETPOINTS AND RESISTOR CURRENT SENSE

### **Applications Schematics: ISL95870B**



FIGURE 6. ISL95870B APPLICATION SCHEMATIC WITH FOUR OUTPUT VOLTAGE SETPOINTS AND DCR CURRENT SENSE





4

# **Block Diagram**



FIGURE 8. SIMPLIFIED FUNCTIONAL BLOCK DIAGRAM OF ISL95870, ISL95870A, ISL95870B

СЛ

LGATE PVCC

1 20

19 VCC

18 BOOT

16 PHASE

14 PGOOD

13 FSEL

12 VO

11 FB OCSET

17

15 EN

UGATE

### **Pin Configurations**



# ISL95870 Functional Pin Descriptions

PIN NUMBER	SYMBOL	DESCRIPTION
1	GND	IC ground for bias supply and signal reference.
2	RTN	Negative remote sense input of V <sub>OUT</sub> . If resistor divider consisting of R <sub>FB</sub> and R <sub>OFS</sub> is used at FB pin, the same resistor divider should be used at RTN pin, i.e. keep R <sub>FB1</sub> =R <sub>FB</sub> , and R <sub>OFS1</sub> =R <sub>OFS</sub> .
3	EN	Enable input for the IC. Pulling EN above the rising threshold voltage initializes the soft-start sequence.
4	SREF	Soft-start and voltage slew-rate programming capacitor input. Connects internally to the inverting input of the $V_{\text{SET}}$ voltage setpoint amplifier.
5	FSEL	Input for programming the regulator switching frequency. Pull this pin to VCC for 1MHz switching. Pull this pin to GND with a 100k $\Omega$ resistor for 600kHz switching. Leave this pin floating for 500kHz switching. Pull this pin directly to GND for 300kHz switching.
6	FB	Voltage feedback sense input. Connects internally to the inverting input of the control-loop error amplifier. The converter is in regulation when the voltage at the FB pin equals the voltage on the SREF pin.
7	OCSET	Input for the overcurrent detection circuit. The overcurrent setpoint programming resistor R <sub>OCSET</sub> connects from this pin to the sense node.
8	VO	Output voltage sense input for the R <sup>4</sup> modulator. The VO pin also serves as the reference input for the overcurrent detection circuit.
9	PGOOD	Power-good open-drain indicator output. This pin changes to high impedance when the converter is able to supply regulated voltage.
10	PHASE	Return current path for the UGATE high-side MOSFET driver, $V_{IN}$ sense input for the R <sup>4</sup> modulator, and inductor current polarity detector input.
11	UGATE	High-side MOSFET gate driver output. Connect to the gate terminal of the high-side MOSFET of the converter.
12	BOOT	Positive input supply for the UGATE high-side MOSFET gate driver. The BOOT pin is internally connected to the cathode of the Schottky boot-strap diode. Connect an MLCC between the BOOT pin and the PHASE pin.
13	VCC	Input for the IC bias voltage. Connect +5V to the VCC pin and decouple with at least a MLCC to the GND pin.
14	PVCC	Input for the LGATE and UGATE MOSFET driver circuits. The PVCC pin is internally connected to the anode of the Schottky boot-strap diode. Connect +5V to the PVCC pin and decouple with a MLCC to the PGND pin.
15	LGATE	Low-side MOSFET gate driver output. Connect to the gate terminal of the low-side MOSFET of the converter.
16	PGND	Return current path for the LGATE MOSFET driver. Connect to the source of the low-side MOSFET.

# **ISL95870A Functional Pin Descriptions**

PIN NUMBER	SYMBOL	DESCRIPTION
1	LGATE	Low-side MOSFET gate driver output. Connect to the gate terminal of the low-side MOSFET of the converter.
2	PGND	Return current path for the LGATE MOSFET driver. Connect to the source of the low-side MOSFET.
3	GND	IC ground for bias supply and signal reference.
4	RTN	Negative remote sense input of V <sub>OUT</sub> . If resistor divider consisting of R <sub>FB</sub> and R <sub>OFS</sub> is used at FB pin, the same resistor divider should be used at RTN pin, i.e. keep R <sub>FB1</sub> =R <sub>FB</sub> , and R <sub>OFS1</sub> =R <sub>OFS</sub> .
5	VID1	Logic input for setpoint voltage selector. Use in conjunction with the VID0 pin to select among four setpoint reference voltages.
6	VIDO	Logic input for setpoint voltage selector. Use in conjunction with the VID1 pin to select among four setpoint reference voltages.
7	SREF	Soft-start and voltage slew-rate programming capacitor input and setpoint reference voltage programming resistor input. Connects internally to the inverting input of the V <sub>SET</sub> voltage setpoint amplifier.
8	SET0	Voltage set-point programming resistor input.
9	SET1	Voltage set-point programming resistor input.
10	FB	Voltage feedback sense input. Connects internally to the inverting input of the control-loop error transconductance amplifier. The converter is in regulation when the voltage at the FB pin equals the voltage on the SREF pin.
11	OCSET	Input for the overcurrent detection circuit. The overcurrent setpoint programming resistor R <sub>OCSET</sub> connects from this pin to the sense node.
12	VO	Output voltage sense input for the R <sup>4</sup> modulator. The VO pin also serves as the reference input for the overcurrent detection circuit.
13	FSEL	Input for programming the regulator switching frequency. Pull this pin to VCC for 1MHz switching. Pull this pin to GND with a 100k $\Omega$ resistor for 600kHz switching. Leave this pin floating for 500kHz switching. Pull this pin directly to GND for 300kHz switching.
14	PGOOD	Power-good open-drain indicator output. This pin changes to high impedance when the converter is able to supply regulated voltage.
15	EN	Enable input for the IC. Pulling EN above the rising threshold voltage initializes the soft-start sequence.
16	PHASE	Return current path for the UGATE high-side MOSFET driver, $V_{\rm IN}$ sense input for the R <sup>4</sup> modulator, and inductor current polarity detector input.
17	UGATE	High-side MOSFET gate driver output. Connect to the gate terminal of the high-side MOSFET of the converter.
18	BOOT	Positive input supply for the UGATE high-side MOSFET gate driver. The BOOT pin is internally connected to the cathode of the Schottky boot-strap diode. Connect an MLCC between the BOOT pin and the PHASE pin.
19	VCC	Input for the IC bias voltage. Connect +5V to the VCC pin and decouple with at least a MLCC to the GND pin.
20	PVCC	Input for the LGATE and UGATE MOSFET driver circuits. The PVCC pin is internally connected to the anode of the Schottky boot-strap diode. Connect +5V to the PVCC pin and decouple with a MLCC to the PGND pin.

# **ISL95870B** Functional Pin Descriptions

PIN NUMBER	SYMBOL	DESCRIPTION
1	RTN	Negative remote sense input of V <sub>OUT</sub> . If resistor divider consisting of R <sub>FB</sub> and R <sub>OFS</sub> is used at FB pin, the same resistor divider should be used at RTN pin, i.e. keep R <sub>FB1</sub> =R <sub>FB</sub> , and R <sub>OFS1</sub> =R <sub>OFS</sub> .
2	VID1	Logic input for setpoint voltage selector. Use in conjunction with the VIDO pin to select among four setpoint reference voltages.
3	VIDO	Logic input for setpoint voltage selector. Use in conjunction with the VID1 pin to select among four setpoint reference voltages.
4	SREF	Soft-start and voltage slew-rate programming capacitor input and setpoint reference voltage programming resistor input. Connects internally to the inverting input of the V <sub>SET</sub> voltage setpoint amplifier.
5	SET0	Voltage set-point programming resistor input.
6	SET1	Voltage set-point programming resistor input.
7	SET2	Voltage set-point programming resistor input.
8	FB	Voltage feedback sense input. Connects internally to the inverting input of the control-loop error transconductance amplifier. The converter is in regulation when the voltage at the FB pin equals the voltage on the SREF pin.
9	OCSET	Input for the overcurrent detection circuit. The overcurrent setpoint programming resistor R <sub>OCSET</sub> connects from this pin to the sense node.
10	VO	Output voltage sense input for the R <sup>4</sup> modulator. The VO pin also serves as the reference input for the overcurrent detection circuit.
11	FSEL	Input for programming the regulator switching frequency. Pull this pin to VCC for 1MHz switching. Pull this pin to GND with a 100k $\Omega$ resistor for 600kHz switching. Leave this pin floating for 500kHz switching. Pull this pin directly to GND for 300kHz switching.
12	PGOOD	Power-good open-drain indicator output. This pin changes to high impedance when the converter is able to supply regulated voltage.
13	EN	Enable input for the IC. Pulling EN above the rising threshold voltage initializes the soft-start sequence.
14	PHASE	Return current path for the UGATE high-side MOSFET driver, $V_{IN}$ sense input for the R <sup>4</sup> modulator, and inductor current polarity detector input.
15	UGATE	High-side MOSFET gate driver output. Connect to the gate terminal of the high-side MOSFET of the converter.
16	BOOT	Positive input supply for the UGATE high-side MOSFET gate driver. The BOOT pin is internally connected to the cathode of the Schottky boot-strap diode. Connect an MLCC between the BOOT pin and the PHASE pin.
17	VCC	Input for the IC bias voltage. Connect +5V to the VCC pin and decouple with at least a MLCC to the GND pin.
18	PVCC	Input for the LGATE and UGATE MOSFET driver circuits. The PVCC pin is internally connected to the anode of the Schottky boot-strap diode. Connect +5V to the PVCC pin and decouple with a MLCC to the PGND pin.
19	LGATE	Low-side MOSFET gate driver output. Connect to the gate terminal of the low-side MOSFET of the converter.
20	PGND	Return current path for the LGATE MOSFET driver. Connect to the source of the low-side MOSFET.
Bottom Pad	GND	IC ground for bias supply and signal reference.

## **Ordering Information**

PART NUMBER (Note 2)	PART MARKING	TEMP RANGE (°C)	PACKAGE (Pb-Free)	PKG. DWG. #
ISL95870HRUZ-T (Notes 1, 4)	GAV	-10 to +100	16 Ld 2.6x1.8 µTQFN	L16.2.6x1.8A
ISL95870AHRUZ-T (Notes 1, 4)	GAW	-10 to +100	20 Ld 3.2x1.8 µTQFN	L20.3.2x1.8
ISL95870BHRZ (Note 3)	870B	-10 to +100	20 Ld 3x4 QFN	L20.3x4
ISL95870BHRZ-T (Notes 1, 3)	870B	-10 to +100	20 Ld 3x4 QFN	L20.3x4
ISL95870IRUZ-T (Notes 1, 4)	GAZ	-40 to +100	16 Ld 2.6x1.8 µTQFN	L16.2.6x1.8A
ISL95870AIRUZ-T (Notes 1, 4)	GAX	-40 to +100	20 Ld 3.2x1.8 µTQFN	L20.3.2x1.8
ISL95870BIRZ (Note 3)	8701	-40 to +100	20 Ld 3x4 QFN	L20.3x4
ISL95870BIRZ-T (Notes 1, 3)	8701	-40 to +100	20 Ld 3x4 QFN	L20.3x4

NOTES:

1. Please refer to <u>TB347</u> for details on reel specifications.

2. For Moisture Sensitivity Level (MSL), please see device information page for <u>ISL95870A</u>, <u>ISL95870A</u>, <u>ISL95870A</u>. For more information on MSL please see techbrief <u>TB363</u>.

- 3. These Intersil Pb-free plastic packaged products employ special Pb-free material sets, molding compounds/die attach materials, and 100% matte tin plate plus anneal (e3 termination finish, which is RoHS compliant and compatible with both SnPb and Pb-free soldering operations). Intersil Pb-free products are MSL classified at Pb-free peak reflow temperatures that meet or exceed the Pb-free requirements of IPC/JEDEC J STD-020.
- 4. These Intersil Pb-free plastic packaged products employ special Pb-free material sets; molding compounds/die attach materials and NiPdAu plate e4 termination finish, which is RoHS compliant and compatible with both SnPb and Pb-free soldering operations. Intersil Pb-free products are MSL classified at Pb-free peak reflow temperatures that meet or exceed the Pb-free requirements of IPC/JEDEC J STD-020.

# **Table of Contents**

Applications Schematics: ISL95870	. 2
Applications Schematics: ISL95870A	. 3
Applications Schematics: ISL95870B	. 4
Block Diagram	. 5
ISL95870 Functional Pin Descriptions	. 7
ISL95870A Functional Pin Descriptions	. 8
ISL95870B Functional Pin Descriptions	. 9
Absolute Maximum Ratings	12
Thermal Information	12
Recommended Operating Conditions	12
Electrical Specifications	12
Theory of Operation	15
Power-On Reset	
Start-Up Timing	
Start-Up and Voltage-Step Operation for ISL95870	
Start-Up and Voltage-Step Operation for ISL95870A, ISL95870B	15
Output Voltage Programming for ISL95870	16
Output Voltage Programming for ISL95870A	16
Output Voltage Programming for ISL95870B	
High Output Voltage Programming	
R4 Modulator	
Stability	
Transient Response	
Diode Emulation	
Overcurrent	
Overvoltage	
Undervoltage	
Over-Temperature	
PGOOD Monitor Integrated MOSFET Gate-Drivers	
Adaptive Shoot-Through Protection	
General Application Design Guide	
Selecting the LC Output Filter	22
Selecting the Input Capacitor	
Selecting the Bootstrap Capacitor	
Driver Power Dissipation	
MOSFET Selection and Considerations	
Layout Considerations	. 24
Revision History	26
Products	26
L16.2.6x1.8A	27
L20.3.2x1.8	. 28
L20.3x4	. 29

#### **Absolute Maximum Ratings**

VCC, PVCC, PGOOD, FSEL to GND         -0.3V to +7.0V           VCC, PVCC to PGND         -0.3V to +7.0V           GND to PGND         -0.3V to +0.3V           FN CFTA         CFTA
EN, SETO, SET1, SET2, VO,
VID0, VID1, FB, RTN, OCSET, SREF-0.3V to GND, VCC + 0.3V
BOOT Voltage (V <sub>BOOT-GND</sub> )
BOOT TO PHASE Voltage (V <sub>BOOT-PHASE</sub> )0.3V to 7V (DC)
-0.3V to 9V (<10ns)
PHASE Voltage
GND -8V (<20ns Pulse Width, 10µJ)
UGATE Voltage VPHASE - 0.3V (DC) to VBOOT
V <sub>PHASE</sub> - 5V (<20ns Pulse Width, 10µJ) to V <sub>BOOT</sub>
LGATE Voltage GND - 0.3V (DC) to VCC + 0.3V
$\ldots$ GND - 2.5V (<20ns Pulse Width, 5µJ) to VCC + 0.3V
ESD Rating
Human Body Model
Machine Model
Charged Device Model
Latch Up JEDEC Class II Level A at +125°C

#### **Thermal Information**

Thermal Resistance (Typical)	$\theta_{JA}$ (°C/W)	θ <sub>JC</sub> (°C/W)
16 Ld µTQFN (Note 5)	90	N/A
20 Ld µTQFN (Note 5)		N/A
20 Ld QFN (Notes 6, 7)	44	5
Junction Temperature Range	55	°C to +150°C
Operating Temperature Range:		
For "H" Version Parts	10°	C to +100°C
For "I" Version Parts	40°	C to +100°C
Storage Temperature	65°	C to +150°C
Pb-Free Reflow Profile	S	ee link below
http://www.intersil.com/pbfree/Pb-	FreeReflow.	<u>asp</u>

#### **Recommended Operating Conditions**

Ambient Temperature Range:

For "H" Version Parts
For "I" Version Parts
Converter Input Voltage to GND
VCC, PVCC to GND

CAUTION: Do not operate at or near the maximum ratings listed for extended periods of time. Exposure to such conditions may adversely impact product reliability and result in failures not covered by warranty.

#### NOTES:

- 5.  $\theta_{JA}$  is measured with the component mounted on a high effective thermal conductivity test board in free air. See Tech Brief TB379 for details.
- 6. θ<sub>JA</sub> is measured in free air with the component mounted on a high effective thermal conductivity test board with "direct attach" features. See Tech Brief TB379.
- 7. For  $\theta_{JC}$ , the "case temp" location is the center of the exposed metal pad on the package underside.

<b>Electrical Specifications</b> All typical specifications $T_A = +25$ °C, VCC = 5V. Boldface limits apply over the operating temperature range, -40°C to +100°C, unless otherwise stated.						
PARAMETER	SYMBOL	TEST CONDITIONS	MIN (Note 11)	ТҮР	MAX (Note 11)	UNIT
VCC and PVCC						
VCC Input Bias Current	IVCC	EN = 5V, VCC = 5V, FB = 0.55V, SREF < FB	-	1.2	1.9	mA
VCC Shutdown Current	I <sub>VCCoff</sub>	EN = GND, VCC = 5V	-	0	1.0	μA
PVCC Shutdown Current	I <sub>PVCCoff</sub>	EN = GND, PVCC = 5V	-	0	1.0	μA
VCC POR THRESHOLD	<b>I</b>					
Rising VCC POR Threshold Voltage	V <sub>VCC_THR</sub>		4.40	4.52	4.60	V
Falling VCC POR Threshold Voltage	V <sub>VCC_THF</sub>		4.10	4.22	4.35	V
REGULATION	<b>I</b>					
System Accuracy		VID0 = VID1 = VCC, PWM Mode = CCM (For "H" Version Parts, $T_A = -10^{\circ}C$ to +100°C)	-0.5	-	+0.5	%
		VID0 = VID1 = VCC, PWM Mode = CCM	-0.75		+0.5	%
PWM	1	1	I		I	
Switching Frequency Accuracy	F <sub>SW</sub>	PWM Mode = CCM (For "H" Version Parts, $T_A = -10^{\circ}C$ to +100°C)	-15	-	+15	%
		PWM Mode = CCM	-22	-	+15	%
vo	1		1	1	1	1
VO Input Impedance	R <sub>VO</sub>	EN = 5V	-	600	-	kΩ
VO Reference Offset Current	I <sub>VOSS</sub>	V <sub>ENTHR</sub> < EN, SREF = Soft-Start Mode	-	8.5	-	μA

### ISL95870, ISL95870A, ISL95870B

#### **Electrical Specifications**

All typical specifications  $T_A = +25$ °C, VCC = 5V. Boldface limits apply over the operating temperature range, -40°C to +100°C, unless otherwise stated. (Continued)

PARAMETER	SYMBOL	TEST CONDITIONS	MIN (Note 11)	түр	MAX (Note 11)	UNIT
VO Input Leakage Current	I <sub>VOoff</sub>	EN = GND, VO = 3.6V	-	0	-	μA
ERROR AMPLIFIER	l			1	1	
FB Input Bias Current	I <sub>FB</sub>	EN = 5V, FB = 0.50V	-20	-	+50	nA
SREF (Note 8)	1				I	L
Soft-Start Current	I <sub>SS</sub>	SREF = Soft-Start Mode	8.5	17	25.5	μA
Voltage Step Current	I <sub>VS</sub>	SREF = Setpoint-Stepping Mode (For "H" Version Parts, $T_A = -10^{\circ}C$ to +100°C)	±51	85	±119	μA
		SREF = Setpoint-Stepping Mode	±46	±85	±127	μA
POWER GOOD			<b>I</b>			
PGOOD Pull-down Impedance	R <sub>PG</sub>	PGOOD = 5mA Sink	-	50	150	Ω
PGOOD Leakage Current	I <sub>PG</sub>	PGOOD = 5V	-	0.1	1.0	μA
GATE DRIVER				ı.		
UGATE Pull-Up Resistance (Note 9)	R <sub>UGPU</sub>	200mA Source Current	-	1.1	1.7	Ω
UGATE Source Current (Note 9)	IUGSRC	UGATE - PHASE = 2.5V	-	1.8	-	А
UGATE Sink Resistance (Note 9)	R <sub>UGPD</sub>	250mA Sink Current	-	1.1	1.7	Ω
UGATE Sink Current (Note 9)	IUGSNK	UGATE - PHASE = 2.5V	-	1.8	-	А
LGATE Pull-Up Resistance (Note 9)	R <sub>LGPU</sub>	250mA Source Current	-	1.1	1.7	Ω
LGATE Source Current (Note 9)	ILGSRC	LGATE - GND = 2.5V	-	1.8	-	А
LGATE Sink Resistance (Note 9)	R <sub>LGPD</sub>	250mA Sink Current	-	0.55	1.0	Ω
LGATE Sink Current (Note 9)	I <sub>LGSNK</sub>	LGATE - PGND = 2.5V	-	3.6	-	А
UGATE to LGATE Deadtime	t <sub>UGFLGR</sub>	UGATE falling to LGATE rising, no load	-	21	-	ns
LGATE to UGATE Deadtime	t <sub>LGFUGR</sub>	LGATE falling to UGATE rising, no load	-	21	-	ns
PHASE			<b>I</b>			
PHASE Input Impedance	R <sub>PHASE</sub>		-	33	-	kΩ
BOOTSTRAP DIODE		L		I		I
Forward Voltage	V <sub>F</sub>	$PVCC = 5V, I_F = 2mA$	-	0.58	-	V
Reverse Leakage	۱ <sub>R</sub>	V <sub>R</sub> = 25V	-	0	-	μA
CONTROL INPUTS			<b>I</b>			
EN High Threshold Voltage	V <sub>ENTHR</sub>		2.0	-	-	V
EN Low Threshold Voltage	V <sub>ENTHF</sub>		-	-	1.0	V
EN Input Bias Current	I <sub>EN</sub>	EN = 5V	0.85	1.7	2.55	μA
EN Leakage Current	I <sub>ENoff</sub>	EN = GND	-	0	1.0	μA
VID<0,1> High Threshold Voltage (Note 10)	V <sub>VIDTHR</sub>		0.65	-	-	V
VID<0,1> Low Threshold Voltage (Note 10)	V <sub>VIDTHF</sub>		-	-	0.5	V
VID<0,1> Input Bias Current (Note 10)	I <sub>VID</sub>	EN = 5V	-	0.5	-	μA
VID<0,1> Leakage Current (Note 10)	IVIDoff	EN=0V	-	0	-	μA
PROTECTION	•	·				

### ISL95870, ISL95870A, ISL95870B

# **Electrical Specifications** All typical specifications $T_A = +25$ °C, VCC = 5V. Boldface limits apply over the operating temperature range, -40°C to +100°C, unless otherwise stated. (Continued)

PARAMETER	SYMBOL	TEST CONDITIONS	MIN (Note 11)	түр	MAX (Note 11)	UNIT
OCP Threshold Voltage	V <sub>OCPTH</sub>	V <sub>OCSET</sub> - V <sub>O</sub>	-1.75	-	1.75	mV
OCP Reference Current	I <sub>OCP</sub>	EN = 5.0V (For "H" Version Parts, $T_A = -10^{\circ}C$ to $+100^{\circ}C$ )	7.65	8.5	9.35	μA
		EN = 5.0V	7.05	8.5	9.35	μΑ
OCSET Input Resistance	R <sub>OCSET</sub>	EN = 5.0V	-	600	-	kΩ
OCSET Leakage Current	I <sub>OCSET</sub>	EN = GND	-	0	-	μΑ
UVP Threshold Voltage	V <sub>UVTH</sub>	V <sub>FB</sub> = %V <sub>SREF</sub>	81	84	87	%
OVP Rising Threshold Voltage	V <sub>OVRTH</sub>	$V_{FB} = %V_{SREF}$ (For "H" Version Parts, $T_A = -10^{\circ}C$ to $+100^{\circ}C$ )	113	116	120	%
		V <sub>FB</sub> = %V <sub>SREF</sub>	112.5	116	120	%
OVP Falling Threshold Voltage	V <sub>OVFTH</sub>	V <sub>FB</sub> = %V <sub>SREF</sub>	98	102	106	%
OTP Rising Threshold Temperature (Note 9)	T <sub>OTRTH</sub>		-	150	-	°C
OTP Hysteresis (Note 9)	TOTHYS		-	25	-	°C

NOTES:

8. For ISL95870, there is one internal reference 0.5V. For ISL95870A, ISL95870B, there are four resistor-programmed reference voltages.

9. Limits established by characterization and are not production tested.

10. VID function is only for ISL95870A, ISL95870B.

11. Parameters with MIN and/or MAX limits are 100% tested at +25°C, unless otherwise specified. Temperature limits established by characterization and are not production tested.

## Theory of Operation

The following sections will provide a detailed description of the inner workings of the ISL95870, ISL95870A, ISL95870B.

#### **Power-On Reset**

The IC is disabled until the voltage at the VCC pin has increased above the rising power-on reset (POR) threshold voltage  $V_{VCC\_THR}$ . The controller will become disabled when the voltage at the VCC pin decreases below the falling POR threshold voltage  $V_{VCC\_THF}$ . The POR detector has a noise filter of approximately 1µs.

### Start-Up Timing

Once VCC has ramped above  $V_{VCC\_THR}$ , the controller can be enabled by pulling the EN pin voltage above the input-high threshold  $V_{ENTHR}$ . Approximately 20µs later, the voltage at the SREF pin begins slewing to the designated VID set-point. The converter output voltage at the FB feedback pin follows the voltage at the SREF pin. During soft-start, The regulator always operates in CCM until the soft-start sequence is complete.

# Start-Up and Voltage-Step Operation for ISL95870

When the voltage on the VCC pin has ramped above the rising power-on reset voltage  $V_{VCC\_THR}$ , and the voltage on the EN pin has increased above the rising enable threshold voltage  $V_{ENTHR}$ , the SREF pin releases its discharge clamp, and enables the reference amplifier  $V_{SET}$ . The soft-start current  $I_{SS}$  is limited to  $17\mu$ A and is sourced out of the SREF pin and charges capacitor  $C_{SOFT}$  until  $V_{SREF}$  equals  $V_{REF}$ . The regulator controls the PWM such that the voltage on the FB pin tracks the rising voltage on the SREF pin. The elapsed time from when the EN pin is asserted to when  $V_{SREF}$  has charged  $C_{SOFT}$  to  $V_{REF}$  is called the soft-start delay  $t_{SS}$  which is given by Equation 1:

$$t_{SS} = \frac{V_{SREF} \cdot C_{SOFT}}{I_{SS}}$$
(EQ. 1)

Where:

-  $I_{\mbox{SS}}$  is the soft-start current source at the  $17\mu\mbox{A}$  limit

-  $V_{SREF}$  is the buffered  $V_{REF}$  reference voltage The end of soft-start is detected by  $I_{SS}$  tapering off when capacitor  $C_{SOFT}$  charges to  $V_{REF}$ . The internal SSOK flag is set, the PGOOD pin goes high, and diode emulation mode (DEM) is enabled.

Choosing the  $C_{SOFT}$  capacitor to meet the requirements of a particular soft-start delay  $t_{SS}$  is calculated using Equation 2, which is written as follows:

$$C_{SOFT} = \frac{t_{SS} \cdot I_{SS}}{V_{SREF}}$$
(EQ. 2)

#### Where:

- t<sub>SS</sub> is the soft-start delay
- $I_{SS}$  is the soft-start current source at the  $17 \mu A$  limit
- $V_{SREF}$  is the buffered  $V_{REF}$  reference voltage

# Start-Up and Voltage-Step Operation for ISL95870A, ISL95870B

When the voltage on the VCC pin has ramped above the rising power-on reset voltage  $V_{VCC\_THR}$ , and the voltage on the EN pin has increased above the rising enable threshold voltage  $V_{ENTHR}$ , the SREF pin releases its discharge clamp and enables the reference amplifier  $V_{SET}$ . The soft-start current  $I_{SS}$  is limited to  $17\mu$ A and is sourced out of the SREF pin into the parallel RC network of capacitor  $C_{SOFT}$  and resistance  $R_T$ . The resistance  $R_T$  is the sum of all the series connected  $R_{SET}$  programming resistors and is written as Equation 3:

$$R_{T} = R_{SET1} + R_{SET2} + \dots R_{SET(n)}$$
(EQ. 3)

The voltage on the SREF pin rises as I<sub>SS</sub> charges C<sub>SOFT</sub> to the voltage reference setpoint selected by the state of the VID inputs at the time the EN pin is asserted. The regulator controls the PWM such that the voltage on the FB pin tracks the rising voltage on the SREF pin. Once C<sub>SOFT</sub> charges to the selected setpoint voltage, the I<sub>SS</sub> current source comes out of the 17µA current limit and decays to the static value set by V<sub>SREF</sub>/R<sub>T</sub>. The elapsed time from when the EN pin is asserted to when V<sub>SREF</sub> has reached the voltage reference setpoint is the soft-start delay t<sub>SS</sub> which is given by Equation 4:

$$t_{SS} = -(R_T \cdot C_{SOFT}) \cdot LN(1 - \frac{V_{START-UP}}{I_{SS} \cdot R_T})$$
(EQ. 4)

Where:

- $I_{\mbox{SS}}$  is the soft-start current source at the  $17\mu\mbox{A}$  limit
- V<sub>START-UP</sub> is the setpoint reference voltage selected by the state of the VID inputs at the time EN is asserted
- $\mathsf{R}_{\mathsf{T}}$  is the sum of the  $\mathsf{R}_{\mathsf{SET}}$  programming resistors

The end of soft-start is detected by  $I_{SS}$  tapering off when capacitor  $C_{SOFT}$  charges to the designated  $V_{SET}$  voltage reference setpoint. The SSOK flag is set, and the PGOOD pin goes high.

The I<sub>SS</sub> current source changes over to the voltage-step current source I<sub>VS</sub> which has a current limit of  $\pm 85\mu$ A. Whenever the VID inputs or the external setpoint reference programs a different setpoint reference voltage, the I<sub>VS</sub> current source charges or discharges capacitor C<sub>SOFT</sub> to that new level at  $\pm 85\mu$ A. Once C<sub>SOFT</sub> charges to the selected setpoint voltage, the I<sub>VS</sub> current source comes out of the 85µA current limit and decays to the static value set by V<sub>SREF</sub>/R<sub>T</sub>. The elapsed time to charge C<sub>SOFT</sub> to the new voltage is called the voltagestep delay t<sub>VS</sub> and is given by Equation 5:

$$t_{VS} = -(R_T \cdot C_{SOFT}) \cdot LN(1 - \frac{(V_{NEW} - V_{OLD})}{I_{VS} \cdot R_T})$$
(EQ. 5)

#### Where:

- $I_{VS}$  is the ±85µA setpoint voltage-step current; positive when  $V_{NEW}$  >  $V_{OLD}$ , negative when  $V_{NEW}$  <  $V_{OLD}$
- $V_{\mbox{NEW}}$  is the new setpoint voltage selected by the VID inputs
- $V_{\mbox{OLD}}$  is the setpoint voltage that  $V_{\mbox{NEW}}$  is changing from
- RT is the sum of the RSET programming resistors

Choosing the  $C_{SOFT}$  capacitor to meet the requirements of a particular soft-start delay  $t_{SS}$  is calculated with Equation 6, which is written as:

$$C_{\text{SOFT}} = \frac{-t_{\text{SS}}}{\left(R_{\text{T}} \cdot LN(1 - \frac{V_{\text{START-UP}}}{I_{\text{SS}} \cdot R_{\text{T}}})\right)}$$
(EQ. 6)

Where:

- t<sub>SS</sub> is the soft-start delay
- $I_{SS}$  is the soft-start current source at the  $17\mu\text{A}$  limit
- V<sub>START-UP</sub> is the setpoint reference voltage selected by the state of the VID inputs at the time EN is asserted
- RT is the sum of the RSET programming resistors

Choosing the C<sub>SOFT</sub> capacitor to meet the requirements of a particular voltage-step delay  $t_{VS}$  is calculated with Equation 7, which is written as:

$$C_{\text{SOFT}} = \frac{-t_{\text{VS}}}{\left(R_{\text{T}} \cdot LN(1 - \frac{V_{\text{NEW}} - V_{\text{OLD}}}{I_{\text{VS}} \cdot R_{\text{T}}})\right)}$$
(EQ. 7)

Where:

- t<sub>VS</sub> is the voltage-step delay
- V<sub>NEW</sub> is the new setpoint voltage
- $V_{\mbox{OLD}}$  is the setpoint voltage that  $V_{\mbox{NEW}}$  is changing from
- $I_{VS}$  is the ±85µA setpoint voltage-step current; positive when  $V_{NEW}$  >  $V_{OLD}$ , negative when  $V_{NEW}$  <  $V_{OLD}$
- R<sub>T</sub> is the sum of the R<sub>SET</sub> programming resistors

### **Output Voltage Programming for ISL95870**

The ISL95870 has a fixed 0.5V reference voltage (V<sub>SREF</sub>). As shown in Figure 9, the output voltage is the reference voltage if R<sub>FB</sub> is shorted and R<sub>OFS</sub> is open. A resistor divider consisting of R<sub>OFS</sub> and R<sub>FB</sub> allows the user to scale the output voltage between 0.5V and 5V. The relation between the output voltage and the reference voltage is given in Equation 8:

$$V_{OUT} = V_{SREF} \cdot \frac{R_{FB} + R_{OFS}}{R_{OFS}}$$
(EQ. 8)



FIGURE 9. ISL95870 VOLTAGE PROGRAMMING CIRCUIT

### **Output Voltage Programming for ISL95870A**

The ISL95870A allows the user to select four different reference voltages, thus four different output voltages, by voltage identification pins VID1 and VID0. The maximum reference voltage cannot be designed higher than 1.5V. The implementation scheme is shown in Figure 10. The setpoint reference voltages are programmed with resistors that use the naming convention  $R_{SFT(x)}$  where (x) is the first, second, or third programming resistor connected in series starting at the SREF pin and ending at the GND pin. As shown in Table 1, different combinations of VID1 and VID0 closes different switches and leaves other switches open. For example, for the case of VID1 = 1 and VID0 = 0, switch SW1 closes and all the other three switches SW0, SW2 and SW3 are open. For one combination of VID1 and VIDO, the internal switch connects the inverting input of the V<sub>SET</sub> amplifier to a specific node among the string of R<sub>SFT</sub> programming resistors. All the resistors between that node and the SREF pin serve as the feedback impedance R<sub>F</sub> of the V<sub>SET</sub> amplifier. Likewise, all the resistors between that node and the GND pin serve as the input impedance RIN of the VSET amplifier. Equation 9 gives the general form of the gain equation for the V<sub>SFT</sub> amplifier:

$$V_{\text{SETX}} = V_{\text{REF}} \cdot \left(1 + \frac{R_{\text{F}}}{R_{\text{IN}}}\right)$$
(EQ. 9)

Where:

- V<sub>RFF</sub> is the 0.5V internal reference of the IC
- $V_{\mbox{SETx}}$  is the resulting setpoint reference voltage that appears at the SREF pin

TABLE 1. ISL95870A VID TRUTH TABLE	TABLE 1.	ISL95870A	VID	TRUTH	TABLE
------------------------------------	----------	-----------	-----	-------	-------

VID STATE		RESULT		
VID1	VID0	CLOSE	V <sub>SREF</sub>	V <sub>OUT</sub>
1	1	SW0	V <sub>SET1</sub>	V <sub>OUT1</sub>
1	0	SW1	V <sub>SET2</sub>	V <sub>OUT2</sub>
0	1	SW2	V <sub>SET3</sub>	V <sub>OUT3</sub>

#### TABLE 1. ISL95870A VID TRUTH TABLE (Continued)

VID STATE		RESULT		
VID1	VID0	CLOSE	V <sub>SREF</sub>	V <sub>OUT</sub>
0	0	SW1, SW3	V <sub>SET4</sub>	V <sub>OUT4</sub>

Equations 10, 11, 12 and 13 give the specific  $V_{SET}$  equations for the ISL95870A setpoint reference voltages.

The ISL95870A V<sub>SET1</sub> setpoint is written as Equation 10: 
$$V_{SET1} = V_{REF}$$
 (EQ. 10)

The ISL95870A V<sub>SET2</sub> setpoint is written as Equation 11:

$$V_{SET2} = V_{REF} \cdot \left( 1 + \frac{R_{SET1}}{R_{SET2} + R_{SET3}} \right)$$
(EQ. 11)

The ISL95870A V<sub>SET3</sub> setpoint is written as Equation 12:

$$V_{\text{SET3}} = V_{\text{REF}} \cdot \left(1 + \frac{R_{\text{SET1}} + R_{\text{SET2}}}{R_{\text{SET3}}}\right)$$
(EQ. 12)

The ISL95870A V\_{SET4} setpoint is written as Equation 13:

$$V_{SET4} = V_{REF} \cdot \left(1 + \frac{R_{SET1}}{R_{SET2}}\right)$$
(EQ. 13)

The V<sub>SET1</sub> is fixed at 0.5V because it corresponds to the closure of internal switch SW0 that configures the V<sub>SET</sub> amplifier as a unity-gain voltage follower for the 0.5V voltage reference V<sub>REF</sub>. Theoretically, V<sub>SET3</sub> can be higher or lower or equal to V<sub>SET4</sub> depending on the selection of R<sub>SET1</sub>, R<sub>SET2</sub> and R<sub>SET3</sub>. However, it is recommended to design the four reference voltages in the following order:

- 
$$V_{SET1}$$
 <  $V_{SET2}$  <  $V_{SET3}$  <  $V_{SET4}$  Thus,

-  $V_{OUT1} < V_{OUT2} < V_{OUT3} < V_{OUT4}$ 

For given four user selected reference voltages  $V_{SETx}$ , the following equation needs to be satisfied in order to have non-zero solution for  $R_{SETx}$ .

$$V_{\text{SET1}} \cdot V_{\text{SET2}} + V_{\text{SET3}} \cdot V_{\text{SET4}} - V_{\text{SET2}} \cdot V_{\text{SET3}} - V_{\text{SET2}} \cdot V_{\text{SET4}} = 0$$
(EQ. 14)

The programmed resistors  $R_{SET1}$ ,  $R_{SET2}$  and  $R_{SET3}$  are designed in the following way. First, assign an initial value to  $R_{SET3}$  of approximately 100k $\Omega$  then calculate  $R_{SET1}$  and  $R_{SET2}$  using Equations 15 and 16 respectively.

$$R_{SET1} = \frac{R_{SET3} \cdot (V_{SET4} - V_{REF}) \cdot (V_{SET2} - V_{REF})}{V_{REF} \cdot (V_{SET4} - V_{SET2})}$$
(EQ. 15)

$$R_{SET2} = \frac{R_{SET3} \cdot (V_{SET2} - V_{REF})}{V_{SET4} - V_{SET2}}$$
(EQ. 16)

The sum of all the programming resistors should be approximately  $300k\Omega$ , as shown in Equation 17, otherwise adjust the value of R<sub>SET3</sub> and repeat the calculations.

$$R_{SET1} + R_{SET2} + R_{SET3} \cong 300 k\Omega \qquad (EQ. 17)$$



#### FIGURE 10. ISL95870A VOLTAGE PROGRAMMING CIRCUIT

If the output voltage is in the range of 0.5V to 1.5V, the external resistor-divider is not necessary. The output voltage is equal to one of the reference voltages depending on the status of VID1 and VID0. The external resistor divider consisting of  $R_{FB}$  and  $R_{OFS}$  allows the user to program the output voltage in the range of 1.5V to 5V. The relation between the output voltage and the reference voltage is given in Equation 18:

$$V_{OUT} = V_{SREF} \cdot \frac{R_{FB} + R_{OFS}}{R_{OFS}} = V_{SREF} \cdot k$$
(EQ. 18)

In this case, the four output voltages are equal to each of the corresponding reference voltages multiplying the factor k.

$$V_{OUTx} = V_{SETx} \cdot k$$
 (EQ. 19)

#### **Output Voltage Programming for ISL95870B**

The ISL95870B allows the user to select four different reference voltages, thus four different output voltages, by voltage identification pins VID1 and VID0. The maximum reference voltage cannot be designed higher than 1.5V. The implementation scheme is shown in Figure 11. The setpoint reference voltages are programmed with resistors that use the naming convention  $R_{SET(x)}$  where (x) is the first, second, third, or fourth programming resistor connected in series starting at the SREF pin and ending at the GND pin. As shown in Table 2, different combinations of VID1 and VIDO close different switches and leave other switches open. For example, for the case of VID1 = 1 and VID0 = 0, switch SW1 closes and all the other three switches SW0, SW2 and SW3 are open. For one combination of VID1 and VID0, the internal switch

connects the inverting input of the VSET amplifier to a specific node among the string of  $R_{\text{SET}}$  programming resistors. All the resistors between that node and the SREF pin serve as the feedback impedance R<sub>F</sub> of the V<sub>SET</sub> amplifier. Likewise, all the resistors between that node and the GND pin serve as the input impedance RIN of the V<sub>SET</sub> amplifier. Equation 20 gives the general form of the gain equation for the V<sub>SET</sub> amplifier:

$$V_{\text{SETX}} = V_{\text{REF}} \cdot \left(1 + \frac{R_{\text{F}}}{R_{\text{IN}}}\right)$$
(EQ. 20)

Where:

- V<sub>REF</sub> is the 0.5V internal reference of the IC
- V<sub>SETx</sub> is the resulting setpoint reference voltage that appears at the SREF pin

VID STATE		RESULT		
VID1	VID0	CLOSE	V <sub>SREF</sub>	V <sub>OUT</sub>
1	1	SW0	V <sub>SET1</sub>	V <sub>OUT1</sub>
1	0	SW1	V <sub>SET2</sub>	V <sub>OUT2</sub>
0	1	SW2	V <sub>SET3</sub>	V <sub>OUT3</sub>
0	0	SW3	V <sub>SET4</sub>	V <sub>OUT4</sub>

#### TABLE 2. ISL95870B VID TRUTH TABLE

Equations 21, 22, 23 and 24 give the specific V<sub>SET</sub> equations for the ISL95870B setpoint reference voltages.

The ISL95870B V<sub>SET1</sub> setpoint is written as Equation 21: 
$$V_{SET1} = V_{REF}$$
 (EQ. 21)

The ISL95870B V<sub>SET2</sub> setpoint is written as Equation 22:

$$V_{\text{SET2}} = V_{\text{REF}} \cdot \left(1 + \frac{R_{\text{SET1}}}{R_{\text{SET2}} + R_{\text{SET3}} + R_{\text{SET4}}}\right)$$
(EQ. 22)

The ISL95870B V<sub>SFT3</sub> setpoint is written as Equation 23:

$$V_{\text{SET3}} = V_{\text{REF}} \cdot \left( 1 + \frac{R_{\text{SET1}} + R_{\text{SET2}}}{R_{\text{SET3}} + R_{\text{SET4}}} \right)$$
(EQ. 23)

The ISL95870B V<sub>SET4</sub> setpoint is written as Equation 24:

$$V_{\text{SET4}} = V_{\text{REF}} \cdot \left(1 + \frac{R_{\text{SET1}} + R_{\text{SET2}} + R_{\text{SET3}}}{R_{\text{SET4}}}\right)$$
(EQ. 24)

The V<sub>SET1</sub> is fixed at 0.5V because it corresponds to the closure of internal switch SWO that configures the VSET amplifier as a unity-gain voltage follower for the 0.5V voltage reference  $V_{REF}$ . The setpoint reference voltages use the naming convention  $V_{SET(x)}$  where (x) is the first, second, third, or fourth setpoint reference voltage where:

- V<sub>SET1</sub> < V<sub>SET2</sub> < V<sub>SET3</sub> < V<sub>SET4</sub> Thus,

- 
$$V_{OUT1} < V_{OUT2} < V_{OUT3} < V_{OUT4}$$

For given four user selected reference voltages VSETX, the programmed resistors R<sub>SET1</sub>, R<sub>SET2</sub>, R<sub>SET3</sub> and RSET4 are designed in the following way. First, assign an initial value to  $R_{SET4}$  of approximately 100k $\Omega$  then

calculate R<sub>SET1</sub>, R<sub>SET2</sub> and R<sub>SET3</sub> using Equations 25, 26, and 27 respectively.

$$R_{\text{SET1}} = \frac{R_{\text{SET4}} \cdot v_{\text{SET4}} \cdot (v_{\text{SET2}} - v_{\text{REF}})}{V_{\text{REF}} \cdot V_{\text{SET2}}}$$
(EQ. 25)

$$R_{SET2} = \frac{R_{SET4} \cdot V_{SET4} \cdot (V_{SET3} - V_{SET2})}{V_{SET2} \cdot V_{SET3}}$$
(EQ. 26)

$$R_{SET3} = \frac{R_{SET4} \cdot (V_{SET4} - V_{SET3})}{V_{SET3}}$$
(EQ. 27)

The sum of all the programming resistors should be approximately 300kΩ, as shown in Equation 28, otherwise adjust the value of R<sub>SET4</sub> and repeat the calculations.

$$R_{SET1} + R_{SET2} + R_{SET3} + R_{SET4} \cong 300 k\Omega$$
 (EQ. 28)



#### FIGURE 11. ISL95870B VOLTAGE PROGRAMMING CIRCUIT

If the output voltage is in the range of 0.5V to 1.5V, the external resistor-divider is not necessary. The output voltage is equal to one of the reference voltages depending on the status of VID1 and VID0. The external resistor divider consisting of R<sub>FB</sub> and R<sub>OFS</sub> allows the user to program the output voltage in the range of 1.5V to 5V. The relation between the output voltage and the reference is given in Equation 29:

$$V_{OUT} = V_{SREF} \cdot \frac{R_{FB} + R_{OFS}}{R_{OFS}} = V_{SREF} \cdot k$$
 (EQ. 29)

In this case, the four output voltages are equal to each of the corresponding reference voltages multiplying the factor k.

$$V_{OUTx} = V_{SETx} \cdot k \tag{EQ. 30}$$

### **High Output Voltage Programming**

The ISL95870 has a fixed 0.5V reference voltage (V<sub>SREF</sub>). For high output voltage application, the resistor divider consisting of R<sub>FB</sub> and R<sub>OFS</sub> requires large ratio (R<sub>FB</sub> : R<sub>OFS</sub> = 9:1 for 5V output). The FB pin with large ratio resistor divider is noise sensitive and the PCB layout should be carefully routed. It is recommended to use small value resistor divider such as R<sub>FB</sub>=1k $\Omega$ .

In general the ISL95870A and ISL95870B have much better jitter performance than the ISL95870 when the output voltage is in the range of 3.3V to 5V, particularly in DCM. This is because  $V_{SREF}$  voltage can be set to 1.5V and a smaller ratio resistor divider can be used. This makes the singal to noise ratio at FB pin much better. So for 3.3V to 5V output, the ISL95870A and ISL95870B are recommended with  $V_{SREF}$  set to 1.5V.

#### **R4 Modulator**

The  $R^4$  modulator is an evolutionary step in  $R^3$  technology. Like  $R^3$ , the  $R^4$  modulator allows variable frequency in response to load transients and maintains the benefits of current-mode hysteretic controllers. However, in addition, the  $R^4$  modulator reduces regulator output impedance and uses accurate referencing to eliminate the need for a high-gain voltage amplifier in the compensation loop. The result is a topology that can be tuned to voltage-mode hysteretic transient speed while maintaining a linear control model and removes the need for any compensation. This greatly simplifies the regulator design for customers and reduces external component cost.

### Stability

The removal of compensation derives from the R<sup>4</sup> modulator's lack of need for high DC gain. In traditional architectures, high DC gain is achieved with an integrator in the voltage loop. The integrator introduces a pole in the open-loop transfer function at low frequencies. That, combined with the double-pole from the output L/C filter, creates a three pole system that must be compensated to maintain stability.

Classic control theory requires a single-pole transition through unity gain to ensure a stable system. Current-mode architectures (includes peak, peak-valley, current-mode hysteretic, R<sup>3</sup> and R<sup>4</sup>) generate a zero at or near the L/C resonant point, effectively canceling one of the system's poles. The system still contains two poles, one of which must be canceled with a zero before unity gain crossover to achieve stability. Compensation components are added to introduce the necessary zero.



FIGURE 13. UNCOMPENSATED INTEGRATOR OPEN-LOOP RESPONSE

Figure 12 illustrates the classic integrator configuration for a voltage loop error-amplifier. While the integrator provides the high DC gain required for accurate regulation in traditional technologies, it also introduces a low-frequency pole into the control loop. Figure 13 shows the open-loop response that results from the addition of an integrating capacitor in the voltage loop. The compensation components found in Figure 12 are necessary to achieve stability.

Because R<sup>4</sup> does not require a high-gain voltage loop, the integrator can be removed, reducing the number of inherent poles in the loop to two. The current-mode zero continues to cancel one of the poles, ensuring a single-pole crossover for a wide range of output filter choices. The result is a stable system with no need for compensation components or complex equations to properly tune the stability.



FIGURE 14. NON-INTEGRATED R4 ERROR-AMPLIFIER CONFIGURATION

Figure 14 shows the R<sup>4</sup> error-amplifier that does not require an integrator for high DC gain to achieve accurate regulation. The result to the open loop response can be seen in Figure 15.



FIGURE 15. UNCOMPENSATED R4 OPEN-LOOP RESPONSE

### **Transient Response**

In addition to requiring a compensation zero, the integrator in traditional architectures also slows system response to transient conditions. The change in COMP voltage is slow in response to a rapid change in output voltage. If the integrating capacitor is removed, COMP moves as quickly as VOUT, and the modulator immediately increases or decreases switching frequency to recover the output voltage.



#### FIGURE 16. R3 vs R4 IDEALIZED TRANSIENT RESPONSE

The dotted red and blue lines in Figure 16 represent the time delayed behavior of V<sub>OUT</sub> and V<sub>COMP</sub> in response to a load transient when an integrator is used. The solid red and blue lines illustrate the increased response of  $R^4$  in the absence of the integrator capacitor.

### **Diode Emulation**

The polarity of the output inductor current is defined as positive when conducting away from the phase node, and defined as negative when conducting towards the phase node. The DC component of the inductor current is positive, but the AC component known as the ripple current, can be either positive or negative. Should the sum of the AC and DC components of the inductor current remain positive for the entire switching period, the converter is in continuous-conduction-mode (CCM). However, if the inductor current becomes negative or zero, the converter is in discontinuous-conduction-mode (DCM).

Unlike the standard DC/DC buck regulator, the synchronous rectifier can sink current from the output filter inductor during DCM, reducing the light-load efficiency with unnecessary conduction loss as the low-side MOSFET sinks the inductor current. The ISL95870, ISL95870A, ISL95870B controllers avoid the DCM conduction loss by making the low-side MOSFET emulate the current-blocking behavior of a diode. This smart-diode operation called diode-emulation-mode (DEM) is triggered when the negative inductor current produces a positive voltage drop across the  $r_{DS}(ON)$  of the low-side MOSFET for eight consecutive PWM cycles while the LGATE pin is high. The converter will exit DEM on the next PWM pulse after detecting a negative voltage across the  $r_{DS}(ON)$  of the low-side MOSFET.

It is characteristic of the R<sup>4</sup> architecture for the PWM switching frequency to decrease while in DCM, increasing efficiency by reducing unnecessary gate-driver switching losses. The extent of the frequency reduction is proportional to the reduction of load current. Upon entering DEM, the PWM frequency is forced to fall approximately 30% by forcing a similar increase of the window voltage V<sub>W</sub>. This measure is taken to prevent oscillating between modes at the boundary between CCM and DCM. The 30% increase of V<sub>W</sub> is removed upon exit of DEM, forcing the PWM switching frequency to jump back to the nominal CCM value.

#### Overcurrent

The overcurrent protection (OCP) setpoint is programmed with resistor  $R_{OCSET}$ , which is connected across the OCSET and PHASE pins. Resistor  $R_{O}$  is connected between the VO pin and the actual output voltage of the converter. During normal operation, the VO pin is a high impedance path, therefore there is no voltage drop across  $R_{O}$ . The value of resistor  $R_{O}$  should always match the value of resistor  $R_{OCSET}$ .



FIGURE 17. OVERCURRENT PROGRAMMING CIRCUIT

Figure 17 shows the overcurrent set circuit. The inductor consists of inductance L and the DC resistance DCR. The inductor DC current  $I_L$  creates a voltage drop across DCR, which is given by Equation 31:

$$V_{DCR} = I_{L} \cdot DCR \tag{EQ. 31}$$

The I<sub>OCSET</sub> current source sinks  $8.5\mu$ A into the OCSET pin, creating a DC voltage drop across the resistor R<sub>OCSET</sub>, which is given by Equation 32:

$$V_{\text{ROCSET}} = 8.5 \mu A \cdot R_{\text{OCSET}}$$
(EQ. 32)

The DC voltage difference between the OCSET pin and the VO pin, which is given by Equation 33:

The IC monitors the voltage of the OCSET pin and the VO pin. When the voltage of the OCSET pin is higher than the voltage of the VO pin for more than  $10\mu s$ , an OCP fault latches the converter off.

The value of  $\mathsf{R}_{\mathsf{OCSET}}$  is calculated with Equation 34, which is written as:

$$R_{OCSET} = \frac{I_{OC} \cdot DCR}{I_{OCSET}}$$
(EQ. 34)

Where:

- $R_{\mbox{OCSET}}\left(\Omega\right)$  is the resistor used to program the overcurrent setpoint
- I<sub>OC</sub> is the output DC load current that will activate the OCP fault detection circuit
- DCR is the inductor DC resistance

For example, if  $I_{OC}$  is 20A and DCR is 4.5m $\Omega$ , the choice of  $R_{OCSET}$  is equal to 20A x 4.5m $\Omega$ /8.5 $\mu$ A = 10.5k $\Omega$ .

Resistor R<sub>OCSET</sub> and capacitor C<sub>SEN</sub> form an R-C network to sense the inductor current. To sense the inductor current correctly not only in DC operation, but also during dynamic operation, the R-C network time constant R<sub>OCSET</sub> C<sub>SEN</sub> needs to match the inductor time constant L/DCR. The value of C<sub>SEN</sub> is then written as Equation 35:

 $C_{SEN} = \frac{L}{R_{OCSET} \cdot DCR}$ (EQ. 35)

For example, if L is 1.5µH, DCR is 4.5m $\Omega$ , and R<sub>OCSET</sub> is 9k $\Omega$ , the choice of C<sub>SEN</sub> = 1.5µH/(9k $\Omega$  x 4.5m $\Omega$ ) = 0.037µF.

When an OCP fault is declared, the converter will be latched off and the PGOOD pin will be asserted low. The fault will remain latched until the EN pin has been pulled below the falling EN threshold voltage  $V_{ENTHF}$  or if VCC has decayed below the falling POR threshold voltage  $V_{VCC\_THF}$ .

### Overvoltage

The OVP fault detection circuit triggers after the FB pin voltage is above the rising overvoltage threshold  $V_{OVRTH}$  for more than 2µs. For example, if the converter is programmed to regulate 1.0V at the FB pin, that voltage would have to rise above the typical  $V_{OVRTH}$  threshold of

116% for more than 2µs in order to trip the OVP fault latch. In numerical terms, that would be 116% x 1.0V = 1.16V. When an OVP fault is declared, the converter will be latched off and the PGOOD pin will be asserted low. The fault will remain latched until the EN pin has been pulled below the falling EN threshold voltage V<sub>ENTHF</sub> or if VCC has decayed below the falling POR threshold voltage  $V_{VCC_THF}$ .

Although the converter has latched-off in response to an OVP fault, the LGATE gate-driver output will retain the ability to toggle the low-side MOSFET on and off, in response to the output voltage transversing the VOVRTH and VOVFTH thresholds. The LGATE gate-driver will turnon the low-side MOSFET to discharge the output voltage, protecting the load. The LGATE gate-driver will turn-off the low-side MOSFET once the FB pin voltage is lower than the falling overvoltage threshold V<sub>OVRTH</sub> for more than 2µs. The falling overvoltage threshold VOVFTH is typically 102%. That means if the FB pin voltage falls below 102% x 1.0V = 1.02V for more than  $2\mu s$ , the LGATE gate-driver will turn off the low-side MOSFET. If the output voltage rises again, the LGATE driver will again turn on the low-side MOSFET when the FB pin voltage is above the rising overvoltage threshold V<sub>OVRTH</sub> for more than 2µs. By doing so, the IC protects the load when there is a consistent overvoltage condition.

### Undervoltage

The UVP fault detection circuit triggers after the FB pin voltage is below the undervoltage threshold V<sub>UVTH</sub> for more than 2µs. For example if the converter is programmed to regulate 1.0V at the FB pin, that voltage would have to fall below the typical V<sub>UVTH</sub> threshold of 84% for more than 2µs in order to trip the UVP fault latch. In numerical terms, that would be 84% x 1.0V = 0.84V. When a UVP fault is declared, the converter will be latched off and the PGOOD pin will be asserted low. The fault will remain latched until the EN pin has been pulled below the falling EN threshold voltage V<sub>ENTHF</sub> or if VCC has decayed below the falling POR threshold voltage V<sub>VCC THF</sub>.

### **Over-Temperature**

When the temperature of the IC increases above the rising threshold temperature  $T_{OTRTH}$ , it will enter the OTP state that suspends the PWM, forcing the LGATE and UGATE gate-driver outputs low. The status of the PGOOD pin does not change nor does the converter latch-off. The PWM remains suspended until the IC temperature falls below the hysteresis temperature  $T_{OTHYS}$  at which time normal PWM operation resumes. The OTP state can be reset if the EN pin is pulled below the falling EN threshold voltage  $V_{ENTHF}$  or if VCC has decayed below the falling POR threshold voltage  $V_{VCC_THF}$ . All other protection circuits remain functional while the IC is in the OTP state. It is likely that the IC will detect an UVP fault because in the absence of PWM, the output voltage decays below the undervoltage threshold V<sub>UVTH</sub>.

### **PGOOD Monitor**

The PGOOD pin indicates when the converter is capable of supplying regulated voltage. The PGOOD pin is an undefined impedance if the VCC pin has not reached the rising POR threshold V<sub>VCC\_THR</sub>, or if the VCC pin is below the falling POR threshold V<sub>VCC\_THF</sub>. If there is a fault condition of output overcurrent, overvoltage or undervoltage, PGOOD is asserted low. The PGOOD pull-down impedance is 50 $\Omega$ .

### **Integrated MOSFET Gate-Drivers**

The LGATE pin and UGATE pins are MOSFET driver outputs. The LGATE pin drives the low-side MOSFET of the converter while the UGATE pin drives the high-side MOSFET of the converter.

The LGATE driver is optimized for low duty-cycle applications where the low-side MOSFET experiences long conduction times. In this environment, the low-side MOSFETs require exceptionally low  $r_{DS(ON)}$  and tend to have large parasitic charges that conduct transient currents within the devices in response to high dv/dt switching present at the phase node. The drain-gate charge in particular can conduct sufficient current through the driver pull-down resistance that the V<sub>GS(th)</sub> of the device can be exceeded and turned on. For this reason, the LGATE driver has been designed with low pull-down resistance and high sink current capability to ensure clamping the MOSFETs gate voltage below V<sub>GS(th)</sub>.

### **Adaptive Shoot-Through Protection**

Adaptive shoot-through protection prevents a gate-driver output from turning on until the opposite gate-driver output has fallen below approximately 1V. The dead-time shown in Figure 18 is extended by the additional period that the falling gate voltage remains above the 1V threshold. The high-side gate-driver output voltage is measured across the UGATE and PHASE pins while the low-side gate-driver output voltage is measured across the LGATE and PGND pins. The power for the LGATE gate-driver is sourced directly from the PVCC pin. The-power for the UGATE gate-driver is supplied by a boot-strap capacitor connected across the BOOT and PHASE pins. The capacitor is charged each time the phase node voltage falls a diode drop below PVCC such as when the low-side MOSFET is turned on.



FIGURE 18. GATE DRIVE ADAPTIVE SHOOT-THROUGH PROTECTION

### General Application Design Guide

This design guide is intended to provide a high-level explanation of the steps necessary to design a singlephase buck converter. It is assumed that the reader is familiar with many of the basic skills and techniques referenced in the following. In addition to this guide, Intersil provides complete reference designs that include schematics, bills of materials, and example board layouts.

### Selecting the LC Output Filter

The duty cycle of an ideal buck converter is a function of the input and the output voltage. This relationship is expressed in Equation 36:

$$D = \frac{V_O}{V_{IN}}$$
(EQ. 36)

The output inductor peak-to-peak ripple current is expressed in Equation 37:

$$P_{P-P} = \frac{V_{O} \cdot (1 - D)}{F_{SW} \cdot L}$$
(EQ. 37)

A typical step-down DC/DC converter will have an  $I_{PP}$  of 20% to 40% of the maximum DC output load current. The value of  $I_{P-P}$  is selected based upon several criteria such as MOSFET switching loss, inductor core loss, and the resistive loss of the inductor winding. The DC copper loss of the inductor can be estimated using Equation 38:

$$P_{COPPER} = I_{LOAD}^{2} \cdot DCR$$
 (EQ. 38)

Where,  $I_{LOAD}$  is the converter output DC current.

The copper loss can be significant so attention has to be given to the DCR of the inductor. Another factor to consider when choosing the inductor is its saturation characteristics at elevated temperature. A saturated inductor could cause destruction of circuit components, as well as nuisance OCP faults. A DC/DC buck regulator must have output capacitance  $C_O$  into which ripple current  $I_{P-P}$  can flow. Current  $I_{P-P}$  develops a corresponding ripple voltage  $V_{P-P}$  across  $C_{O_i}$ , which is the sum of the voltage drop across the capacitor ESR and of the voltage change stemming from charge moved in and out of the capacitor. These two voltages are expressed in Equations 39 and 40:

$$\Delta V_{ESR} = I_{P-P} \cdot ESR \tag{EQ. 39}$$

$$\Delta V_{\rm C} = \frac{I_{\rm P-P}}{8 \cdot C_{\rm O} \cdot F_{\rm SW}}$$
(EQ. 40)

If the output of the converter has to support a load with high pulsating current, several capacitors will need to be paralleled to reduce the total ESR until the required V<sub>P-P</sub> is achieved. The inductance of the capacitor can significantly impact the output voltage ripple and cause a brief voltage spike if the load transient has an extremely high slew rate. Low inductance capacitors should be considered. A capacitor dissipates heat as a function of RMS current and frequency. Be sure that I<sub>P-P</sub> is shared by a sufficient quantity of paralleled capacitors so that they operate below the maximum rated RMS current at F<sub>SW</sub>. Take into account that the rated value of a capacitor can fade as much as 50% as the DC voltage across it increases.

#### **Selecting the Input Capacitor**

The important parameters for the bulk input capacitors are the voltage rating and the RMS current rating. For reliable operation, select bulk capacitors with voltage and current ratings above the maximum input voltage and capable of supplying the RMS current required by the switching circuit. Their voltage rating should be at least 1.25x greater than the maximum input voltage, while a voltage rating of 1.5x is a preferred rating. Figure 19 is a graph of the input RMS ripple current, normalized relative to output load current, as a function of duty cycle that is adjusted for converter efficiency. The ripple current calculation is written as Equation 41:

$$I_{IN_{RMS}} = \frac{\sqrt{(I_{MAX}^{2} \cdot (D - D^{2})) + (x^{2} \cdot I_{MAX}^{2} \cdot \frac{D}{12})}}{I_{MAX}}$$
(EQ. 41)

Where:

- $I_{\mbox{MAX}}$  is the maximum continuous  $I_{\mbox{LOAD}}$  of the converter
- x is a multiplier (0 to 1) corresponding to the inductor peak-to-peak ripple amplitude expressed as a percentage of I<sub>MAX</sub> (0% to 100%)
- D is the duty cycle that is adjusted to take into account the efficiency of the converter

Duty cycle is written as Equation 42:

$$D = \frac{V_0}{V_{IN} \cdot EFF}$$
(EQ. 42)

In addition to the bulk capacitors, some low ESL ceramic capacitors are recommended to decouple between the

drain of the high-side MOSFET and the source of the low-side MOSFET.



# EFF = 1

### Selecting the Bootstrap Capacitor

The integrated driver features an internal bootstrap schottky diode. Simply adding an external capacitor across the BOOT and PHASE pins completes the bootstrap circuit. The bootstrap capacitor voltage rating is selected to be at least 10V. Although the theoretical maximum voltage of the capacitor is PVCC-V<sub>DIODE</sub> (voltage drop across the boot diode), large excursions below ground by the phase node requires at least a 10V rating for the bootstrap capacitor. The bootstrap capacitor can be chosen from Equation 43:

$$C_{BOOT} \ge \frac{Q_{GATE}}{\Delta V_{BOOT}}$$
(EQ. 43)

Where:

- Q<sub>GATE</sub> is the amount of gate charge required to fully charge the gate of the upper MOSFET
- $\Delta V_{BOOT}$  is the maximum decay across the BOOT capacitor

As an example, suppose the high-side MOSFET has a total gate charge  $Q_g$ , of 25nC at  $V_{GS} = 5V$ , and a  $\Delta V_{BOOT}$  of 200mV. The calculated bootstrap capacitance is 0.125µF; for a comfortable margin, select a capacitor that is double the calculated capacitance. In this example, 0.22µF will suffice. Use a low temperature-coefficient ceramic capacitor.

### **Driver Power Dissipation**

Switching power dissipation in the driver is mainly a function of the switching frequency and total gate charge of the selected MOSFETs. Calculating the power dissipation in the driver for a desired application is critical to ensuring safe operation. Exceeding the maximum allowable power dissipation level will push the IC beyond the maximum recommended operating junction temperature of +125°C. When designing the application, it is recommended that the following calculation be performed to ensure safe operation at the desired frequency for the selected MOSFETs. The power

dissipated by the drivers is approximated as Equation 44:

$$P = F_{sw}(1.5V_UQ_{11} + V_LQ_1) + P_L + P_U$$
(EQ. 44)

Where:

- F<sub>sw</sub> is the switching frequency of the PWM signal
- $V_U$  is the upper gate driver bias supply voltage
- V<sub>1</sub> is the lower gate driver bias supply voltage
- $\ensuremath{\mathbb{Q}}_U$  is the charge to be delivered by the upper driver into the gate of the MOSFET and discrete capacitors
- Q<sub>L</sub> is the charge to be delivered by the lower driver into the gate of the MOSFET and discrete capacitors
- $\ensuremath{\mathsf{P}}\xspace_L$  is the quiescent power consumption of the lower driver
- $\mathsf{P}_{U}$  is the quiescent power consumption of the upper driver



MOSFET Selection and Considerations

The choice of MOSFETs depends on the current each MOSFET will be required to conduct, the switching frequency, the capability of the MOSFETs to dissipate heat, and the availability and nature of heat sinking and air flow.

Typically, a MOSFET cannot tolerate even brief excursions beyond their maximum drain to source voltage rating. The MOSFETs used in the power stage of the converter should have a maximum  $V_{DS}$  rating that exceeds the sum of the upper voltage tolerance of the input power source and the voltage spike that occurs when the MOSFETs switch.

There are several power MOSFETs readily available that are optimized for DC/DC converter applications. The preferred high-side MOSFET emphasizes low gate charge so that the device spends the least amount of time dissipating power in the linear region. The preferred low-side MOSFET emphasizes low  $r_{DS(on)}$  when fully saturated to minimize conduction loss.

For the low-side MOSFET, (LS), the power loss can be assumed to be conductive only and is written as Equation 45:

$$\mathsf{P}_{\mathsf{CON}_{\mathsf{LS}}} \approx \mathsf{I}_{\mathsf{LOAD}}^{2} \cdot r_{\mathsf{DS}(\mathsf{ON})_{\mathsf{LS}}} \cdot (1 - \mathsf{D})$$
(EQ. 45)

For the high-side MOSFET, (HS), its conduction loss is written as Equation 46:

$$P_{CON_{HS}} = I_{LOAD}^{2} \cdot r_{DS(ON)_{HS}} \cdot D$$
 (EQ. 46)

For the high-side MOSFET, its switching loss is written as Equation 47:

$$\mathsf{P}_{\mathsf{SW}_{\mathsf{HS}}} = \frac{\mathsf{V}_{\mathsf{IN}} \cdot \mathsf{I}_{\mathsf{VALLEY}} \cdot \mathsf{t}_{\mathsf{ON}} \cdot \mathsf{F}_{\mathsf{SW}}}{2} + \frac{\mathsf{V}_{\mathsf{IN}} \cdot \mathsf{I}_{\mathsf{PEAK}} \cdot \mathsf{t}_{\mathsf{OFF}} \cdot \mathsf{F}_{\mathsf{SW}}}{2}$$
(EQ. 47)

Where:

- I<sub>VALLEY</sub> is the difference of the DC component of the inductor current minus 1/2 of the inductor ripple current
- I<sub>PEAK</sub> is the sum of the DC component of the inductor current plus 1/2 of the inductor ripple current
- $t_{\mbox{ON}}$  is the time required to drive the device into saturation
- $t_{\mbox{OFF}}$  is the time required to drive the device into cut-off

### Layout Considerations

As a general rule, power layers should be close together, either on the top or bottom of the board, with the weak analog or logic signal layers on the opposite side of the board. The ground-plane layer should be adjacent to the signal layer to provide shielding. The ground plane layer should have an island located under the IC, the components connected to analog or logic signals. The island should be connected to the rest of the ground plane layer at one quiet point.

There are two sets of components in a DC/DC converter, the power components and the small signal components. The power components are the most critical because they switch large amount of energy. The small signal components connect to sensitive nodes or supply critical bypassing current and signal coupling.

The power components should be placed first and these include MOSFETs, input and output capacitors, and the inductor. Keeping the distance between the power train and the control IC short helps keep the gate drive traces short. These drive signals include the LGATE, UGATE, PGND, PHASE and BOOT.

When placing MOSFETs, try to keep the source of the upper MOSFETs and the drain of the lower MOSFETs as close as thermally possible. See Figure 21. Input high frequency capacitors should be placed close to the drain of the upper MOSFETs and the source of the lower MOSFETs. Place the output inductor and output



#### FIGURE 21. TYPICAL POWER COMPONENT PLACEMENT

capacitors between the MOSFETs and the load. High frequency output decoupling capacitors (ceramic) should be placed as close as possible to the decoupling target, making use of the shortest connection paths to any internal planes. Place the components in such a way that the area under the IC has less noise traces with high dV/dt and di/dt, such as gate signals and phase node signals.

#### VCC AND PVCC PINS

Place the decoupling capacitors as close as practical to the IC. In particular, the PVCC decoupling capacitor should have a very short and wide connection to the PGND pin. The VCC decoupling capacitor should be referenced to GND pin.

#### EN, PGOOD, VID0, VID1, AND FSEL PINS

These are logic signals that are referenced to the GND pin. Treat as a typical logic signal.

#### **OCSET AND VO PINS**

The current-sensing network consisting of R<sub>OCSET</sub>, R<sub>O</sub>, and C<sub>SEN</sub> needs to be connected to the inductor pads for accurate measurement of the DCR voltage drop. These components however, should be located physically close to the OCSET and VO pins with traces leading back to the inductor. It is critical that the traces are shielded by the ground plane layer all the way to the inductor pads. The procedure is the same for resistive current sense.

#### FB, SREF, SET0, SET1, SET2, AND RTN PINS

The input impedance of these pins is high, making it critical to place the components connected to these pins as close as possible to the IC.

#### LGATE, PGND, UGATE, BOOT, AND PHASE PINS

The signals going through these traces are high dv/dt and high di/dt, with high peak charging and discharging current. The PGND pin can only flow current from the gate-source charge of the low-side MOSFETs when LGATE goes low. Ideally, route the trace from the LGATE pin in parallel with the trace from the PGND pin, route the trace from the UGATE pin in parallel with the trace from the PHASE pin. In order to have more accurate zero-crossing detection of inductor current, it is recommended to connect Phase pin to the drain of the low-side MOSFETs with Kelvin connection. These pairs of traces should be short, wide, and away from other traces with high input impedance; weak signal traces should not be in proximity with these traces on any layer.

### **Revision History**

The revision history provided is for informational purposes only and is believed to be accurate, but not warranted. Please go to web to make sure you have the latest Rev.

DATE	REVISION	CHANGE
December 22, 2009	FN6899.0	Initial Release

### Products

Intersil Corporation is a leader in the design and manufacture of high-performance analog semiconductors. The Company's products address some of the industry's fastest growing markets, such as, flat panel displays, cell phones, handheld products, and notebooks. Intersil's product families address power management and analog signal processing functions. Go to <u>www.intersil.com/products</u> for a complete list of Intersil product families.

\*For a complete listing of Applications, Related Documentation and Related Parts, please see the respective device information page on intersil.com: <u>ISL95870</u>, <u>ISL95870A</u>, <u>ISL95870B</u>

To report errors or suggestions for this datasheet, please go to www.intersil.com/askourstaff

FITs are available from our website at http://rel.intersil.com/reports/search.php

For additional products, see www.intersil.com/product\_tree

Intersil products are manufactured, assembled and tested utilizing ISO9000 quality systems as noted in the quality certifications found at <u>www.intersil.com/design/quality</u>

Intersil products are sold by description only. Intersil Corporation reserves the right to make changes in circuit design, software and/or specifications at any time without notice. Accordingly, the reader is cautioned to verify that data sheets are current before placing orders. Information furnished by Intersil is believed to be accurate and reliable. However, no responsibility is assumed by Intersil or its subsidiaries for its use; nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of Intersil or its subsidiaries.

For information regarding Intersil Corporation and its products, see www.intersil.com



### Ultra Thin Quad Flat No-Lead Plastic Package (UTQFN)











BOTTOM VIEW





L16.2.6x1.8A

16 LEAD ULTRA THIN QUAD FLAT NO-LEAD PLASTIC PACKAGE

	MILLIMETERS			
SYMBOL	MIN	NOMINAL	MAX	NOTES
А	0.45	0.50	0.55	-
A1	-	-	0.05	-
A3	0.127 REF			-
b	0.15	0.20	0.25	5
D	2.55	2.60	2.65	-
E	1.75	1.80	1.85	-
е	0.40 BSC			-
К	0.15	-	-	-
L	0.35	0.40	0.45	-
L1	0.45	0.50	0.55	-
N	16			2
Nd	4			3
Ne	4			3
θ	0	-	12	4

NOTES:

- 1. Dimensioning and tolerancing conform to ASME Y14.5-1994.
- 2. N is the number of terminals.
- 3. Nd and Ne refer to the number of terminals on D and E side, respectively.
- 4. All dimensions are in millimeters. Angles are in degrees.
- 5. Dimension b applies to the metallized terminal and is measured between 0.15mm and 0.30mm from the terminal tip.
- 6. The configuration of the pin #1 identifier is optional, but must be located within the zone indicated. The pin #1 identifier may be either a mold or mark feature.
- 7. Maximum package warpage is 0.05mm.
- 8. Maximum allowable burrs is 0.076mm in all directions.
- 9. JEDEC Reference MO-255.
- 10. For additional information, to assist with the PCB Land Pattern Design effort, see Intersil Technical Brief TB389.

Rev. 5 2/09

### **Package Outline Drawing**

### L20.3.2x1.8

20 LEAD ULTRA THIN QUAD FLAT NO-LEAD PLASTIC PACKAGE (UTQFN) Rev 0,  $5{\rm /}08$ 















#### NOTES:

- 1. Dimensions are in millimeters. Dimensions in ( ) for Reference Only.
- 2. Dimensioning and tolerancing conform to AMSE Y14.5m-1994.
- 3. Unless otherwise specified, tolerance : Decimal  $\pm 0.05$
- 4. Dimension b applies to the metallized terminal and is measured between 0.15mm and 0.30mm from the terminal tip.
- 5. Tiebar shown (if present) is a non-functional feature.
- 6. The configuration of the pin #1 identifier is optional, but must be located within the zone indicated. The pin #1 identifier may be either a mold or mark feature.

### **Package Outline Drawing**

#### L20.3x4

20 LEAD QUAD FLAT NO-LEAD PLASTIC PACKAGE Rev 0, 6/07













DETAIL "X"

#### NOTES:

- Dimensions are in millimeters.
   Dimensions in ( ) for Reference Only.
- 2. Dimensioning and tolerancing conform to AMSE Y14.5m-1994.
- 3. Unless otherwise specified, tolerance : Decimal  $\pm 0.05$
- 4. Dimension b applies to the metallized terminal and is measured between 0.15mm and 0.30mm from the terminal tip.
- 5. Tiebar shown (if present) is a non-functional feature.
- 6. The configuration of the pin #1 identifier is optional, but must be located within the zone indicated. The pin #1 indentifier may be either a mold or mark feature.



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



#### Как с нами связаться

**Телефон:** 8 (812) 309 58 32 (многоканальный) **Факс:** 8 (812) 320-02-42 **Электронная почта:** <u>org@eplast1.ru</u> **Адрес:** 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.