

DIO5632 Single Inductor-Dual Output Power Supply

Features

- **SIMO(Single-Inductor Multiple-Output) Regulator Technology**
- **>85% Efficiency at I_{OUT}>10mA**
- **2.5-V to 5.5-V Input Voltage Range**
- **Under voltage Lockout Rising/Falling**
- **Programmable Output Voltage**
- **Positive Output Voltage Range: 4V to 6V (0.1-V step)**
- **Negative Output Voltage Range: -4V to -6V (0.1-V step)**
- **1% Output Voltage Accuracy**
- **Programmable Active Discharge**
- **Internal EEPROM Type Memory (1000x Re-programmable)**
- **Excellent Line Regulation**
- **Advanced Power-Save Mode for Light-Load Efficiency**
- **Thermal Shutdown**
- **15-Ball CSP Package**
- **QFN3*4-20 Package**
- **QFN4*4-20 Package**

Applications

- **TFT LCD Smart phones**
- **TFT LCD Tablets**
- **OLED Displays**
- **General Dual Power Supply Applications**

Ordering Information

Descriptions

The DIO5632 is designed to support general positive/negative driven applications. The device uses a single inductor scheme in order to provide the user the smallest solution size possible as well as high efficiency. With its input voltage range of 2.5V to 5.5V, it is optimized for products powered by single-cell batteries (Li-lon, Ni-Li, Li-Polymer) and output currents up to 100 mA. The device is delivered in a WCSP package of 15 balls or in two QFN packages of 20 pins.

Typical Application

Pin Assignments

Pin Definitions

Absolute Maximum Ratings

Stresses beyond those listed under "Absolute Maximum Rating" may cause permanent damage to the device. These are stress ratings only and functional operation of the device at these or any other condition beyond those indicated in the operational sections of the specifications is not implied. Exposure to absolute maxim rating conditions for extended periods may affect device reliability.

Recommend Operating Conditions

The Recommended Operating Conditions table defines the conditions for actual device operation. Recommended Operating conditions are specified to ensure optimal performance to the datasheet specifications. DIOO does not Recommend exceeding them or designing to Absolute Maximum Ratings.

Electrical Characteristics

T_A=25°C, V_{IN}=3.7V, ENN=ENP=V_{IN}, V_{POS}=5.4V, V_{NEG}=-5.4V, unless otherwise specified.

I²C Interface Timing Requirements/Characteristics

Figure 2 Serial Interface Timing For F/S-Mode

Single Inductor - Dual Output Power Supply **Single Inductor – Dual Output Power Supply**

Detailed Description

1. Overview

The DIO5632, supporting input voltage from 2.5V to 5.5V, operates with a single inductor scheme to provide a high efficiency with a small solution size. The synchronous boost converter generates a positive voltage that is regulated down by an integrated LDO, providing the positive supply rail (V_{POS}). The negative supply rail (V_{NEG}) is generated by an integrative charge pump (or CPN) driven from the boost converter output pin REG. The operating mode can be selected between Smartphone and Tablet in order to select the necessary output current capability and to get the best efficiency possible based on the application. The device topology allows a 100% asymmetry of the output currents.

2. Functional Block Diagram

Figure 3. Function Block Diagram

3. Feature Description

3.1 Under Voltage Lockout (UVLO)

The DIO5632 integrates an under voltage lockout block (UVLO) that enables the device once the voltage on the VIN pin exceeds the UVLO threshold (2.5V maximum). No output voltage will however be generated as long as the enable signals are not pulled HIGH. The device, as well as all converters (boost converter, LDO, CPN), will be disabled as soon as the V_{IN} voltage falls below the UVLO threshold. The UVLO threshold is designed in a way that the DIO5632 will continue operating as long as V_{IN} stays above 2.3V. This guarantees a proper operation even in the event of extensive line transients when the battery gets suddenly heavily loaded.

For DIO5632, a 40ms delay is starting as soon as the UVLO threshold is reached. This delay prevents the device to be disabled and enabled by an unwanted VIN voltage spike. Once this delay has passed, the output rails can

be enabled as desired with the enable signals without any delay. And the UVLO 40ms delay time can be enable/disable by factory programming.

3.2 Active Discharge

An active discharge of the positive rail and/or the negative rail can be programmed (DISP and CISN bits respectively – refer to DAC Registers). If programmed to be active, the discharge will occur at power down, when the enable signals go LOW. See Power-Down And Discharge (LDO) and Power-Down And Discharge (CPN) for a detailed description of how each device variant implements the active discharge function.

3.3 Boost Converter

3.3.1 Boost Converter Operation

The synchronous boost converter uses a current mode topology and operates at a quasi-fixed frequency of typically 1.8MHz, allowing chip inductors such as 2.2µH or 4.7µH to be used. The converter is internally compensated and provides a regulated output voltage automatically adjusted depending on the programmed V_{POS} and V_{NEG} voltage. The boost converter operates either in continuous conduction mode (CCM) or Pulse Frequency Modulation mode (PFM), depending on the load current in order to provide the highest efficiency possible.

3.3.2 Power-Up And Soft-Start (Boost Converter)

The boost converter starts switching as soon as the enable signal is pulled HIGH and the voltage on VIN pin is above the UVLO threshold. For DIO5632, in the case where the enable signal is already HIGH when V_{IN} reaches the UVLO threshold, the boost converter will only start switching after a 40ms delay has passed.

The boost converter starts up with an integrated soft-start to avoid drawing excessive inrush current from the supply. The output voltage V_{REG} is slowly ramped up to its target value.

3.3.3 Power-Down (Boost Converter)

The boost converter stops switching when V_{IN} is below the UVLO threshold or when both output rails are disabled. For example, due to a special sequencing, the LDO might still be operating while the CPN is already disabled, in which case, the boost will continue operating until the LDO has been disabled.

3.3.4 Isolation (Boost Converter)

The boost converter output (REG) is isolated from the input supply V_{IN} , providing a true shutdown.

3.3.5 Output Voltage (Boost Converter)

The output voltage of the boost converter is automatically adjusted depending on the programmed V_{POS} and V_{NEG} voltage.

3.3.6 Advanced Power-Save Mode For Light-Load Efficiency And PFM

The DIO5632 device integrates a power save mode to improve efficiency at light load. In power save mode the converter stops switching when the inductor current reaches 0 A. The device resumes its switching activity with one or more pulses once the V_{RFG} voltage falls below its regulation level, and goes again into power save mode once the inductor current reaches 0 A. The pulse duration remains constant, but the frequency of these pulses varies according to the output load. This operating mode is also known as Pulse Frequency Modulation or PFM.

3.4 LDO Regulator

3.4.1 LDO Operation

The Low Dropout regulator (or LDO) generates the positive voltage rail V_{POS} by regulating down the output voltage of the boost converter (V_{REG}). Its inherent power supply rejection helps filtering the output ripple of the boost converter in order to provide on OUTP pin a clean voltage, e.g. to supply the source driver IC of the display.

3.4.2 Power-Up And Soft-Start (LDO)

The LDO starts operating as soon as the ENP signal is pulled HIGH, V_{IN} voltage is above the UVLO threshold and the boost converter has reached its Power Good threshold.

In the case where the enable signal is already HIGH when V_{IN} exceeds the UVLO threshold, the boost converter will start first and the LDO will only start after the boost converter has reached its target voltage.

The LDO integrates a soft-start that slowly ramps up its output voltage V_{POS} regardless of the output capacitor, as long as the LDO current limit is not reached. For DIO5632, the typical ramp-up time can be programmed to be 0.25ms/0.82ms by factory programming.

3.4.3 Power-Down And Discharge (LDO)

The LDO stops operating when V_{IN} is below the UVLO threshold or when ENP is pulled LOW.

The positive rail can be actively discharged to GND during power-down if required. A discharge selection bit is available to enable or disable this function.

3.4.4 Isolation (LDO)

The LDO is isolating the V_{POS} rail from V_{REG} (boost converter output) as long as the rail is not enabled in order to ensure flexible startup like V_{NEG} before V_{POS} .

3.4.5 Setting The Output Voltage (LDO)

The output voltage of the LDO is programmable via a I²C compatible interface, from 4.0V to 6.0V with 100mV steps. For more details, please refer to the DAC Settings section.

3.5 Negative Charge Pump

3.5.1 Operation

The negative charge pump (CPN) generates the negative voltage rail V_{NEG} by inverting and regulating the output voltage of the boost converter (V_{REG}). The charge pump uses 4 switches and an external flying capacitor to generate the negative rail. Two of the switches are turned on in the first phase to charge the flying capacitor up to V_{RFG} , and in the second phase they are turned-off and the two others turn on to pump the energy negatively out of the OUTN capacitor.

3.5.2 Power-Up And Soft-Start (CPN)

The CPN starts operating as soon as the ENN signal is pulled HIGH, VIN voltage is above the UVLO threshold and the boost converter has reached its Power Good threshold.

In the case where the enable signal is already HIGH when VIN reaches the UVLO threshold, the boost converter will start first and the CPN will only start after the boost converter has reached its target voltage.

The CPN integrates a soft-start that slowly ramps up its output voltage V_{NFG} within a time defined by the selected mode, the output voltage and the output capacitor value. For DIO5632, the typical ramp-up time can be programmed to be 0.4ms/1.6ms by factory programming.

3.5.3 Power-Down And Discharge (CPN)

The CPN stops operating when V_{IN} is below the UVLO threshold or when ENN is pulled LOW.

The negative rail can be actively discharged to GND during power-down if required. A discharge selection bit is available to enable or disable this function.

3.5.4 Isolation (CPN)

The CPN isolates the V_{NEG} rail from V_{REG} (boost converter output) as long as the rail is not enabled in order to ensure flexible startup like V_{POS} before V_{NEG} .

3.5.5 Setting The Output Voltage (CPN)

The output voltage of the CPN is programmable via a I²C compatible interface, from 4.0V to 6.0V with 100m\ steps. For more details, please refer to the DAC Settings section.

4. Device Functional Mode

4.1 Enabling and Disabling the Device

The DIO5632 is enabled as long as the VIN voltage is above the UVLO and one of the enable pins (ENP or ENN) is HIGH. Pulling ENP or ENN LOW disables either rail (V_{POS} or V_{NEG} respectively); and, pulling both pins LOW disables the device entirely.

5. Programming

5.1 I²C Serial Interface Description

The DIO5632 communicates through an industry standard I²C compatible interface, to receive data in slave mode. I²C is a 2-wire serial interface developed by Philips Semiconductor.

The DIO5632 integrates a non-volatile memory (EEPROM) that allows the storage of the DAC values into the registers with a capability of up to 1000 programming cycles maximum.

The bus consists of a data line (SDA) and a clock line (SCL) with pull-up structures. When the bus is idle, both SDA and SCL. A master device, usually a microcontroller or a digital signal processor, controls the bus. The master is responsible for generating the SCL signal and device addresses. The master also generates specific conditions that indicate the START and STOP of data transfer. A slave device receives and/or transmits data on the bus under control of the master device.

The DIO5632 works as a slave and supports the following data transfer modes, as defined in the I²C-Bus specification: standard mode (100 kbps) and fast mode (400 kbps). The data transfer protocol for standard and fast modes is exactly the same, therefore they are referred to as F/S-mode in this document. The DIO5632 supports 7-bit addressing. The device 7-bit address is 3E, and the LSB enables the write or read function.

Figure 4. DIO5632 Slave Address Bvte

The device that initiates the communication is called a master, and the devices controlled by the master are slaves. The master generates the serial clock on SCL, controls the bus access, and generates START and STOP conditions. A START initiates a new data transfer to a slave. Transitioning SDA from high to low while SCL remains high generates a START condition. A STOP condition ends a data transfer to slave. Transitioning SDA from low to high while SCL remains high generates a STOP condition.

Figure 5. Start And Stop Conditions

The master then generates the SCL pulses, and transmits the 7-bit address and the read/write direction bit R/(W) on the SDA line. During all transmissions, the master ensures that the data is valid. A valid data condition requires the SDA line to be stable during the entire high period of the clock pulse. All devices recognize the address sent by the master and compare it to their internal fixed addresses. Only the slave device with a matching address sent by the master and compare it to their internal fixed addresses. Only the slave device with a matching address generates an Acknowledgment, ACK, by pulling the SDA line low during the entire high period of the SCL cycle. Upon detecting this Acknowledgment, the master knows that communication link with a slave has been established.

Figure 7. Acknowledge On The IC Bus²

The master generates further SCL cycles to either transmit data to the slave (R/(W) bit=0) or receive data from the slave (R/(W) bit=1). In either case, the receiver needs to acknowledge the data sent by the transmitter. So an acknowledge signal can either be generated by the master or by the slave, depending on which one is the receiver. 9-bit valid data sequences consisting of 8-bit data and 1-bit acknowledge can continue as long as necessary. To terminate the data transfer, the master generates a STOP condition by pulling the SDA line from low to high while the SCL line is high. This releases the bus and stops the communication link with the addresses slave. All I²C compatible devices must recognize the bus and stops the communication link with the addressed slave. All I²C compatible devices must recognize the stop condition. Upon the receipt of a stop condition, all devices know that the bus is released, and they wait for a start condition followed by a matching address.

Featuring Register Address Auto-Increment

6. Register Maps

The DIO5632 has one non-volatile memory which contains the initial value of the DAC and one volatile memory which contains the DAC setting. The non-volatile memory is called the Initial Value Register (IVR) and the volatile memory is called DAC Register (DR). The non-volatile IVR and the volatile memory is called DAC Register (DR). The non-volatile IVR and the volatile DR are accessed with the same address.

Single Inductor – Dual Output Power Supply

Single Inductor - Dual Output Power Supply

Start option: At power-up, the value contained in the IVR is loaded into the volatile DR and IVR presets the DAC to the last stored setting within less than 20µs. The programmed factory value if IVR of each address is described below and, at power-up, these data byte set the output voltage of each rail.

Write description: The user has to program all data registers first (0x00 ~ 0x03). Then set the WED (Write EEPROM Data) bit to 1 once all desired data are addressed. A dead time of 50ms is then initiated during which all the register data (0x00 ~0x03) are stored into the non volatile EEPROM cell. During that time, there should be no data flowing through the I²C because the I²C interface is momentarily not responding.

Afetr the 50ms have passed, the WED bit is automatically reset to 0, and the user is able to read the values or program again.

Slave address: 0x3E

X=R/W R/W=1→read mode

R/W=0→write mode

6.1 DAC Registers

6.2 DAC Settings

The following tables show the DAC values and the corresponding voltages of each block address.

Application and Implementation

1. Application Information

The DIO5632 devices, primarily intended to supplying TFT LCD displays, can be used for any application that requires positive and negative supplies, ranging from ±4V to ±6V and current up to 100mA. Both output voltages can be set independently and their sequencing is also independent. The following section presents the different operating modes that the device can support as well as the different features that user can select.

2. Typical Applications

2.1 Low-current Applications(≤**50mA)**

The DIO5632 can be programmed to Smartphone mode with the APPS bit to support applications that require output currents up to 50mA (refer to DAC Settings). The Smartphone mode limits the negative charge pump output current to 50mA DC in order to provide the highest efficiency possible. The V_{POS} rail can deliver up to 200mA DC regardless of the mode. Output peak currents are supported by the output capacitors.

Figure 18. Typical Application Circuit For Smart phones

2.1.1 Design Requirements

2.1.2 Detailed Design Procedure

2.1.2.1 Sequencing

Each output rail (V_{POS} and V_{NEG}) is enabled and disabled using an external enable signal. If not explicitly specified, the enable signal in the rest of the document refers to ENN or ENP: ENP for positive rail V_{POS} and ENN for the negative rail V_{NFG} .

2.1.2.2 Boost Converter Design Procedure

The first step in the design procedure is to verify whether the maximum possible output current of the boost converter supports the specific application requirements. A simple approach is to estimate the converter efficiency, by taking the efficiency number from the provided efficiency curves at the application's maximum load or to use a worst case assumption for the expected efficiency, e.g., 85%.

1. **Duty Cycle**:
$$
D = 1 - \frac{V_{IN_min} \times \eta}{V_{REG}}
$$

- 2. Inductor ripple current: $\Delta I_L = \frac{I_{L}}{f_{SW} \times L}$ $IL = \frac{V_{IN}}{f_{SW} \times L}$ $L = \frac{V_{IN}}{f_{SW}} \times$ $\Delta I_L = \frac{V_{IN}}{c}$
- 3. Maximum output current: $IovT_{\text{max}} = \left(ILM \text{ min} \frac{\Delta IL}{2} \right) \times (1-D)$ J $\begin{pmatrix} I_{LIM} & \text{min} - \frac{\Delta I_L}{I} \end{pmatrix}$ l ΔL max $=\left(LIM \text{ min}-\frac{\Delta L}{2}\right) \times (1)$
- 4. Peak switch current of the application: $1 - V$ *REG* 2 *L REG* $SWPEAK = \frac{IOUT}{I} + \frac{\Delta I}{I}$ *V* $ISWPEAK = \frac{IOUT}{1 - VREG} + \frac{\Delta}{A}$

η = Estimated boost converter efficiency (use the number from the efficiency plots or 85% as an estimation) f_{SW} = Boost converter switching frequency (1.8 MHz)

L = Selected inductor value for the boost converter (see the Inductor Selection section)

 I_{SWPEAK} = Boost converter switch current at the desired output current (must be < $[I_{\text{LIM}}_{\text{min}} + \Delta I_{\text{L}}]$)

 ΔI_{\parallel} = Inductor peak-to-peak ripple current

 V_{REG} = max (V_{POS} , $|V_{NEG}|$) + 200 mV (in Smartphone mode $-$ + 300 mV in Tablet mode)

 $I_{\text{OUT}} = I_{\text{OUT_VPOS}} + |I_{\text{OUT_VNEG}}|$ ($I_{\text{OUT_max}}$ being the maximum current delivered on each rail)

The peak switch current is the current that the integrated switch and the inductor have to handle. The calculation must be done for the minimum input voltage where the peak switch current is highest.

2.1.2.2.1 Inductor Selection (Boost Converter)

Saturation current: the inductor must handle the maximum peak current (I_{L SAT}>I_{SWPEAK}, or I_{L SAT}>[I_{LIM min} +∆I_L] as conservation approach).

DC Resistance: the lower the DCR, the lower the losses.

Inductor value: in order to keep the ratio IOUT/∆IL low enough for proper sensing operation purpose, it is recommended to use a 4.7µH inductor for Smartphone mode (a 2.2µH might however be used, but the efficiency might be lower than with 4.7µH at light output loads depending on the inductor characteristics).

2.1.2.2.2 Input Capacitor Selection (Boost Converter)

For best input voltage filtering low ESR ceramic capacitors are recommended. DIO5632 has an analog input pin VIN. A 4.7µF minimum bypass capacitor is required as close as possible from VIN to GND. This capacitor is also

used as the boost converter input capacitor.

For better input voltage filtering, this value can be increase or two capacitors can be used: one 4.7µF input capacitor for the boost converter as well as a 1µF bypass capacitor close to the VIN pin.

2.1.2.2.3 Output Capacitor Selection (Boost Converter)

For the best output voltage filtering, low-ESR ceramic capacitors are recommended. A minimum of 4.7µF ceramic output capacitor is required. Higher capacitor values can be used to improve the load transient response.

2.1.2.3 Input Capacitor Selection (LDO)

The LDO input capacitor is also the boost converter output capacitor.

2.1.2.4 Output Capacitor Selection (LDO)

The LDO is designed to operate with a 4.7µF minimum ceramic output capacitor.

2.1.2.5 Input Capacitor Selection (CPN)

The CPN input capacitor is also the boost converter output capacitor.

2.1.2.6 Output Capacitor Selection (CPN)

The CPN is designed to operate with a 4.7µF minimum ceramic output capacitor.

2.1.2.7 Flying Capacitor Selection (CPN)

The CPN needs an external flying capacitor. The minimum value is 2.2µF. Special care must be taken while choosing the flying capacitor as it will directly impact the output voltage accuracy and load regulation performance. Therefore, a minimum capacitance of 1µF must be achieved by the capacitor at a DC bias voltage of $|V_{NEG}|+300mV$. For proper operation, the flying capacitor value must be lower than the output capacitor of the boost converter on REG pin.

2.2 Mid-current Applications(≤**100mA)**

The DIO5632 can be programmed to Tablet mode with the APPS bit to support applications that require output currents up to 100mA. The Tablet mode is limiting the negative charge pump (CPN) output current to 100mA DC in order to provide the highest efficiency possible where the $V_{(POS)}$ rail can deliver up to 200mA DC regardless of the mode. Output peak currents are supported are supported by the output capacitors.

Figure 19. Typical Application Circuit For Tables

2.2.1 Design Requirements

2.2.2 Detailed Design Procedure

The design procedure for thr Tablet mode is identical to the Smartphone mode, except for the BOM (bill of materials). Refer to the Sequencing for details about the sequencing. And the general component selection.

2.2.2.1 Boost Converter Design Procedure

2.2.2.1.1 Inductor Selection (Boost Converter)

In order to keep the ratio I_{OUT}/∆I_L low enough for proper sensing operation purpose, it is recommended to use a

2.2µH inductor for Tablet mode. Refer to the Inductor Selection (Boost Converter) for details about the boost inductor selection.

2.2.2.1.2 Inductor Capacitor Selection (Boost Converter)

A 4.7µF minimum bypass capacitor is required as close as possible from VIN to GND. This capacitor is also used as the boost converter input capacitor.

For better input voltage filtering, this value can be increased or two capacitors can be used: one 4.7µF input capacitor for the boost converter as well as 1µF bypass capacitor close to the VIN pin.

2.2.2.1.3 Output Capacitor Selection (Boost Converter)

For best output voltage filtering low ESR ceramic capacitors are recommended. A minimum of 10µF ceramic output capacitor is required. Higher capacitor values can be used to improve the load transient response.

2.2.2.2 Input Capacitor Selection (LDO)

The LDO input capacitor is also the boost converter output capacitor.

2.2.2.3 Output Capacitor Selection (LDO)

The LDO is designed to operate with a 4.7µF minimum ceramic output capacitor.

2.2.2.4 Input Capacitor Selection (CPN)

The CPN input capacitor is also the boost converter output capacitor.

2.2.2.5 Output Capacitor Selection (CPN)

The CPN is designed to operate with a 10µF minimum ceramic output capacitor.

2.2.2.6 Flying Capacitor Selection (CPN)

The CPN needs an external flying capacitor. The minimum value is 4.7µF. Special care must be taken while choosing the flying capacitor as it will directly impact the output voltage accuracy and load regulation performance. Therefore, a minimum capacitance of 2.2µF must be achieved by the capacitor at a DC bias voltage of $|V_{NEG}|$ +300mV. For proper operation, the flying capacitor value must be lower than the output capacitor of the boost converter on REG pin.

Power Supply Recommendations

The devices are designed to operate from an input voltage supply range between 2.5V and 5.5V. This input supply must be well regulated. A ceramic input capacitor with a value of 4.7µF is a typical choice.

Layout

Layout Guidelines

PCB layout is an important task in the power supply design. Good PCB layout minimizes EMI and allows very good output voltage regulation. For the DIO5632 the following PCB layout guidelines are recommended.

- Keep the power ground plane on the top layer (all capacitor grounds and PGND pins must be connected together with one uninterrupted ground plane).
- AGND and PGND must be connected together on the same ground plane.
- Place the flying capacitor as close as possible to the IC.
- Always avoid vias when possible. They have high inductance and resistance. If vias are necessary, always use more than one in parallel to decrease parasitic especially for power lines.

- Connect REG pins together.
- For high dv/dt signals (switch pin trances): keep copper area to a minimum to prevent making unintentional parallel plate capacitors with other traces or to a ground plane. Best to route signal and return on same layer.
- For high di/dt signals: keep traces short, wide and closely spaced. This will reduce stray inductance and decrease the current loop area to help prevent EMI.
- Keep input capacitor close to the IC with low inductance traces.
- Keep trace from switching node pin to inductor short if possible: it reduces EMI emission and noise that may couple into other portions of the converter.
- Isolate analog signal paths from power paths.

CONTACT US

Dioo is a professional design and sales corporation for high-quality and performance analog semiconductors. The company focuses on industry markets, such as, cell phone, handheld products, laptop, and medical equipment and so on. Dioo's product families include analog signal processing and amplifying, LED drivers and charger IC. Go to http://www.dioo.com for a complete list of Dioo product families.

For additional product information, or full datasheet, please contact with our Sales Department or Representatives.

Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits,General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.

Как с нами связаться

Телефон: 8 (812) 309 58 32 (многоканальный) **Факс:** 8 (812) 320-02-42 **Электронная почта:** org@eplast1.ru **Адрес:** 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.