

MAXREFDES27# IO-Link Proximity Sensor Quick Start Guide

Rev 0; 4/14



Maxim Integrated cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim Integrated product. No circuit patent licenses are implied. Maxim Integrated reserves the right to change the circuitry and specifications without notice at any time.

Maxim Integrated 160 Rio Robles, San Jose, CA 95134 USA 1-408-601-1000

© 2014 Maxim Integrated Products, Inc. Maxim Integrated and the Maxim Integrated logo are trademarks of Maxim Integrated Products, Inc.

Table of Contents

1.	Required Equipment	. 3
2.	Overview	. 3
3.	Included Files	.5
4.	Procedure	.6
5.	Appendix A: Project Structure and Key Filenames	25
6.	Trademarks	25
7.	Revision History	26

1. Required Equipment

- PC with Windows® 7 (Verify with Balluff that your version of Windows is supported before purchasing their software.)
- Saratoga (MAXREFDES27#) board
- One Balluff USB IO-Link® master (silver box) with corresponding USB and power cables (This must be purchased separately.)
- Balluff IO-Link Device Tool (tested with version 2.11.1 and comes with the Balluff USB IO-Link master)
- One IO-Link cable (yellow) (This must be purchased separately.)
- RD27_RL78_V01_XX.ZIP (Maxim-Saratoga-20140318-IODD1.0.1.xml), where XX = minor version

2. Overview

Below is a high-level overview of the steps required to quickly get the Saratoga design running by connecting it to the Balluff USB IO-Link master and Balluff software. Detailed instructions for each step are provided in the following pages. The Saratoga (MAXREFDES27#) subsystem reference design will be referred to as Saratoga throughout this document.

- 1) Connect the A-to-B Type USB cable from the PC and yellow IO-Link cable to the Balluff USB IO-Link master (silver box with part number BNI USB-901-000-A501) as shown in Figure 1.
- Connect the MAXREFDES27# proximity sensor board to the other side of the yellow IO-Link cable. Make sure the green LED is lit as shown in <u>Figure 2</u>. The red and yellow LEDs do not need to be lit.
- 3) Download the latest "all design files" **RD27V01_XX.ZIP** file located at the Saratoga page.
- 4) Extract the RD27V01_XX.ZIP file to a directory on your PC.
- 5) Install the Balluff IO-Link Device Tool.
- 6) Add the Saratoga proximity sensor as a device into the Balluff IO-Link Device Tool.
- 7) Connect to the Saratoga by pressing the online connection button.



Figure 1. MAXREFDES27# Board Connected to a Balluff USB IO-Link Master



Figure 2. Green LED Is Lit

3. Included Files

The **RD27_RL78_V01_XX.ZIP** contains the corresponding IO-Link Device Descriptor (IODD) files. The IODD contains information on communication properties, device parameters, identification, process, and diagnostic data. It includes an XML file, an image of the device, an icon image, and the manufacturer's logo. The IODD structure is the same for all devices of all manufacturers, and is always represented in the same way by the IODD interpreter tools.



Figure 3. Block Diagram of System

4. Procedure

- Connect the A-to-B Type USB cable from the PC and yellow IO-Link cable to the Balluff USB IO-Link master (silver box with part number BNI USB-901-000-A501) as shown in <u>Figure 1</u>.
- Connect the MAXREFDES27# proximity sensor board to the other side of the yellow IO-Link cable. Make sure the green LED is lit as shown in <u>Figure 2</u>. The red and yellow LEDs do not need to be lit.
- Download the latest "all design files" RD27V01_XX.ZIP file at <u>www.maximintegrated.com/AN5868</u>. All files available for download are available at the bottom of the page.
- 4. Extract the **RD27V01_XX.ZIP** file to a directory on your PC. The location is arbitrary but the maximum path length limitation in Windows (260 characters) should not be exceeded.
- 5. Install the Balluff IO-Link Device Tool. This tool comes with the purchase of the Balluff USB IO-Link master (silver box with part number BNI USB-901-000-A501). Run the **setup.exe** file using the **Run as administrator** mode.

DVD RW Drive (D:) Disc 🔸 Setup						√ 4 ₇
^						
Name		Date modified	Туре		Size	
 Files Currently on the Disc (6)) —					
E Autorun.exe		5/3/2011 2:52 AM	Applicat	tion	8 KB	
Autorun1.exe		5/3/2011 2:52 AM	Applicat	tion	268 KB	
🔂 Balluff IO-Link Device Tool - Set	up.ms	i 5/3/2011 1:42 AM	Window	s Installer	2,992 KB	
NIO_Link.ico		12/3/2008 9:41 AM	Icon		4 KB	
🔂 setup.exe		Onen	A 12 1	ion	492 KB	
🕂 tool.ico		Run as administrator			4 KB	
	<u> </u>	Troubleshoot compatibility				
		Edit with Notenad++				
	1	TortoiseSVN	•			
	U	Scan for threats				
	0	Share in WebEx Meeting	+			
		WinMerge				
=		Send to	•			
		Conv				
		copy				
		Create shortcut				
		Properties				
	_			·		

6. Choose the default installation folder and press the **Next** button.

Balluff IO-Link Device Tool
Select Installation Folder BALLUFF
IO-Link Device Tool
The installer will install Balluff IO-Link Device Tool to the following folder.
To install in this folder, click "Next". To install to a different folder, enter it below or click "Browse".
Eolder: C:\Program Files (x86)\Balluff GmbH\IO-Link Device Tool\ Browse
Install Balluff IO-Link Device Tool for yourself, or for anyone who uses this computer:
⊘ Just <u>m</u> e
Cancel < <u>B</u> ack Next >

7. Press the **Next** button.





8. Change the language to English if applicable.

9. Close the program by clicking the **X** in the top right corner.

10. Press the **Close** button to complete the installation.



11. Verify the version of the IO-Link Device Tool. In this case, version 2.1.11 was used.



Balluff IO-Link Device Tool	Annual 1 Annual Annua	
File Options View Help		
🔄 🛛 🗣 🔛 Offline 🔛 🔡 .	+ + +? + Operator • ()	
Topology	Balluff IO-Link Device Tool User Login Operator Authorization Maintenance © Specialist Password Exit Login	Catalog PC-Interfaces Deluff GmbH Balluff USB IO-Link DO-Link-Devices TMG TE GmbH Generative Sample Devices Sample Devices Catalog Catalog PC-Interfaces Sample Devices Catalog Sample Devices Sample Devices

12. The User Login should be in Specialist mode. Password is special.

13. Import the IODD xml file for the Maxim sensor. In this case, the file is Maxim-Saratoga-20140318-IODD1.0.1.xml and can be located in the RD27_RL78_V01_00.ZIP file.

Balluff IO-Link Device Tool	Annual of the local division of the local di	
File Options View Help	_	
Change Language	+ +? + Specialist - ()	
Topolo Change Login Status		Catalog
User Management		PC-Interfaces
Import Device Description		Balluff GmbH
	-	Balluff USB IO-Link Ma
		Vendor
		B. Sample Devices
		Sample Device
		•
		A
<u></u> ,		

14. In this case, this is the IODD file shown below, but may be a different .xml file if a different Maxim sensor is used.



15. See the Maxim Sensor show up in the IO-Link devices in the Catalog window.



Salluff IO-Link Device Tool	
File Options View Help	
New ne 🔛 🔠 🕇 🕇 🕇 🕇	pecialist 👻 🕕
Open	Catalog
Save	rfaces ador
Save as	Balluff GmbH
Properties	Balluff USB IO-Link Master -Devices
Exit	ndor
	Renesas Electronics Europe G
	Renesas-RL78-Maxim
	- Sample Devices
	Sample Device
	<

16. Select File | Properties.

Salluff IO-Link Device Tool	· · ·	-	
File Options View Help			
🔄 🧟 😫 Offline 🔮	器 . + i + +? + Specialist ▼ (
Topology	Project Description Changes		Catalog X
	Project Name		ndor
	Author	Version	Balluff GmbH
	Company	created	-Devices
	Organzation	Project Description	Renesas Electronics Europe G
			Renesas-RL78-Maxim
			TMG TE GmbH
			Sample Device
		~	^

17. After **Properties** is selected, the screen looks like the below screenshot.

18. Verify that the USB cable is plugged into the silver USB IO-Link Master box.

Balluff IO-Link Device Tool File Options View Help Image: State S	음입 . +1 + +? + Specialist • ①	
Topology	Common Common Evice Balleff USB IO-Link Master DE (COM15) Version Research for interfaces Connected Device Name Vendor Description Vendor ID Delete Device Delete Device	Catalog Catalo
		× A

19. Drag the **Balluff USB IO-Link Master** to the **Topology** window.

Salluff IO-Link Device Tool		×
File Options View Help		
[月 🧟 😫 Offline 🔮 (昭	+ +? + Specialist ▼ (1)	
Topology	Common	X
Balluff USB IO-Link Master DE (Verian 1.0.A Verian Verian Balluff GmbH Balluff GmbH Verian Balluff GmbH	er 1C.
< >	Proximity and Ambiant Light Sensor with Max44000, MAX14821, RL78 TMG TE IO-Link Device Stack	r ^

20. Drag the Maxim sensor to the Name field in the Common window.

21. Verify a picture of the sensor shows up with the name **Maxim Saratoga Demo**.



Salluff IO-Link Device Tool		
File Options View Help		
🔢 🔍 🔛 🛛 Offline 🛛 😫 🗔 🕂 🕐	+? + Specialist • ①	
Topology Common		Catalog
Topology Common Topology Common Image: Second Common Device Image: Second Common Common Image: Second Common Device Image: Second Common Common Image: Second Common Device Image: Second Common Common Image: Second Common C	Specialist • () O-Link Image: Comparison of the system of the	Catalog Catalo
(r)		

22. Press the **Connect** button on the Balluff IO-Link Device Tool software.

23. If your sensor has a problem or is unconnected, you will see the below figure.

Salluff IO-Link Device Tool		
File Options View Help Image: Construction of the state of the s	Algemein Process Data Parameter Scope IO-Link Hersteller Renesas Bectronics Europe Gml Maxim Vendor ID 0x018C maxim CCONESAS	Catalog X PC-Interfaces Catalog Vendor Catalog Vendor
	Gerät Renesas-RL78-Maxim-Sample Beschreibung Sample Device for RL78 with MAX14821 Device ID 0x18C001 Hardware-Version 1.0 Baudrate COM3 SIO-Mode yes Dokumentversion V1.0 Okumentversion V1.0	→ © IO-Ink Sample Device → TMG TE GmbH → Sample Device → Sample Device

24. If you see the green **Online** indication on the software, the sensor has connected. Click on the Maxim sensor device icon to make the **Parameter** tab show up. Change the values as shown in the figure below by right-clicking with the mouse.

Balluff IO-Link Device Tool	or a few seconds and then cover	the tip of	the MAXPER	DES27# sens		×
File Options View Help						
🛃 💐 😫 Online 🔮 🗄	野」。 🕇 🛧 🕂? 🔸 🚃 Specialist 🕞 🕕					
Topology	Common Process Data Parameter Oscilloscope					
	Name	R/W	Preadjustment	Value	Unit	<u> </u>
	[-] Identification					
	Vendor Name	ro	Maxim Integrated Product	Maxim Integrated Product		
	Vendor Text	ro	http://www.maximintegrat	http://www.maximintegrat		
	Product Name	ro	Maxim Saratoga	Maxim Saratoga		
	Hardware Revision	ro	1.0	1.0		
	Firmware Revision	ro	1.0	1.0		
Click here to	Application Specific Name	rw	USE IO-Link	USE IO-Link		=
make the	[-] Parameter					
Banamatana tah	Operating Mode	rw	Proximity Sensor	Proximity Sensor		
	Pin2 Mode	rw	Sensor Switch	Sensor Switch		
show up.	Gain	rw	1x	1x		
	Conversion Time	rw	100	100		
Then click on	Trim Gain	rw	use factory-programmed tri.	use factory-programmed tr		
the Parameters	gain trim green channel	rw	0	0		
tab and change	gain trim IR channel	rw	0	0		
the velues of	gain trim green channel factory setting	ro	0	0		
the values as	gain trim IR channel factory setting	ro	0	0		
shown to the	LED Current	rw	disabled	00		
right.	Ambient Light Teach Value	rw	500	disabled		
	Proximity Value	rw	128	10		
Right Click	System Command <restore factory="" setting=""></restore>	wo		30		
the mouse to	System Command <teach></teach>	wo		40		
chenge the	[-] Observation			60		
change the				70		
values	L			90		

25. Click on the **Process Data** tab and vary your hand approximately 20mm to 150mm from the tip of the proximity sensor to see the changing value.

Balluff IO-Link Device Tool			
File Options View Help			
🔄 🔄 🔍 😫 Online 😫	Specialist 🔹 🕦		
Topology	Common Process Data Parameter Oscilloscope		
⊡ Balluff USB IO-Link Master DE ((Name	Processdata	Unit
[0] Maxim Saratoga Demo	[-] Process Data Inputs		
	Digital Out	false	
	Sensor Switch	false	
	Value	70	
	[-] Process Data Outputs		
	Pin 2 Value	false	
	L		



5. Appendix A: Project Structure and Key Filenames



- Redricted					1.00.000			
😋 🔵 🗢 📙 « FW On Your Board 🕨 Publ	lic FW	RD27_RL78_V01_0	0 🕨	_	✓ Search RD27	7_RL78_V01_00	Q	
Organize 🔻 📄 Open Burn Ne	ew fol	der					. ?	
🌗 InstallAnywhere	*	Name	<u>^</u>		Date modified	Туре	Size	
Links) IODD			4/7/2014 5:23 PM	File folder		
My Music		퉬 UserManual			4/7/2014 5:23 PM	File folder		
My Music		Maxim_Saratog	a.a87		3/18/2014 5:03 PM	A87 File		
My Videos		🖺 Readme.txt			4/7/2014 5:24 PM	Text Document		
Saved Games Searches			Binary	file	programmed	d into the	•	
Virtual Machines workspace	Ш		KL/O					
Network	Ŧ	•					,	
Maxim_Saratoga.a87 Date modified: 3/18/2014 5:03 PM Date created: 4/7/2014 5:23 PM A87 File Size: 32.8 KB								

6. Trademarks

IO-Link is a registered trademark of ifm electronic GmbH. Windows is a registered trademark and registered service mark of Microsoft Corp.

7. Revision History

REVISION	REVISION	DESCRIPTION	PAGES
NUMBER	DATE		CHANGED
0	4/14	Initial release	



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



Как с нами связаться

Телефон: 8 (812) 309 58 32 (многоканальный) **Факс:** 8 (812) 320-02-42 **Электронная почта:** <u>org@eplast1.ru</u> **Адрес:** 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.