

TECHNICAL DATA

Fluke PQ400 Electrical Measurement Window



REDUCED RISK

Permanently installed voltage and current connections can be accessed without opening the panel door

INCREASED EFFICIENCY

Quickly connect your logger or analyzer and begin taking measurements faster than ever

EASY INSTALLATION

A standard step drill bit and electro-hydraulic hole punch provide the simple means to quickly mount the window in the panel

The Fluke PQ400 Electrical Measurement Window enables the connection of three phase measurement equipment to energized panels, without the need to open the panel door, or wear supplemental personal protective equipment (PPE)¹

Compliance without compromise. Safety without sacrifice.

The Fluke PQ400 gives you access to the critical power quality and energy data you need, all while decreasing testing time and helping you to maintain safety.

- Reduce the risk of arc-flash and electrocution, while increasing the safety of your personnel
- Decrease maintenance costs and reduce downtime by making critical power quality and energy measurements without opening the panel door, enabling logging and monitoring at any time—without disrupting operations
- Reduce work permit requirements and processes by reducing the hazards associated with taking measurements on open panels, saving time and effort
- Increase measurement efficiency and reduce the need for arc-flash PPE¹, saving time, increasing efficiency and increasing operator comfort

Features

- Permanently connected voltage and current sensors located inside the electrical panel allow you to make power quality and energy measurements using the external access points without opening the panel door, reducing operator risk
- Voltage and current connections for three-phase voltages, neutral and ground cover most measurement scenarios
- Automatic probe detection for Fluke 1740 and 1730 series power quality and energy loggers and compatible clamps, eliminates the need to open cabinet to check the clamp model
- Full 360 degree rotation allows the PQ400 window to be oriented in any direction
- Simple installation using a step drill bit and electro-hydraulic hole punch (114.3 mm, 4.5 inch diameter)
- CAT IV, 600V and CATIII 1,000V rating according to IEC61010-2-30
- Compatibility with standard 4mm shrouded safety-socket voltage test leads makes it easier to make voltage connections, increases safety by reducing the risk of accidentally touching live electrical components, and reduces the need for purchasing specialized voltage leads

¹Comply with local and national safety codes. Use personal protective equipment (approved rubber gloves, face protection, and flame-resistant clothes) to prevent shock and arc blast injury where hazardous live conductors are exposed.

How it works

The Fluke PQ400 Electrical Measurement Window is a permanently installed interface that provides technicians with near instant access to electrical panels for making critical power quality and energy measurements. The PQ400 installs using a standard step drill bit and electro-hydraulic hole punch (114.3 mm, 4.5-inch hole diameter), and allows users to make three-phase voltage, current and ground connects covering most measurement configurations. Once installed users can simply unlock the window cover, lift the lid, and connect the voltage leads of the logger or analyzer. Then, connect the leads for the current sensors and start making critical measurements. Once complete, simply remove the voltage and current connections from the front panel interface and lock the window lid, leaving the internal connections in place for future use.



Specifications

| General specifications | |
|---|---|
| Maximum voltage between any voltage terminal and earth ground | 1000 V |
| Maximum voltage between any current terminal and earth ground | 30 V |
| Safety | |
| General | IEC 61010-1: pollution degree 2 |
| Measurement | IEC 61010-2-030: CAT IV 600 V / CAT III 1000 V |
| Dimensions | |
| Outside | 148 mm x 187 mm x 23 mm (W x H x D) (148 mm x 370 mm x 19 mm with cover opened) |
| Inside | 140 mm x 158 mm x Di (W x H x D) Di = 58 – thickness of panel door in mm |
| Supported electrical enclosures | |
| Enclosure | UL 50/NEMA environmental type 1 (Type 12 when PQ400 cover is closed) |
| Panel thickness | Max. 3.5 mm (10 gauge) |
| Environment | |
| Operating/storage temperature | -25 °C to 60 °C (-13 °F to 140 °F) |
| Humidity | 10 % to 90 % in dependency of temperature according to IEC 60721-3-3 Class 3K6 (modified):-25 °C to 35 °C: 10 % to 90 %, 50°C: max. 35 %, 60°C: max. 23 % |
| Altitude | |
| Operating | 2,000 m (up to 4000 m derate to CAT II 1000 V, CAT III 600 V, CAT IV 300 V) |
| Storage | 12 000 m |
| Ingress protection | |
| Rating | IEC 60529: IP67 with cover closed, IP50 with cover opened and all connectors attached |
| Vibration | IEC 60068-2-6 , MIL-PRF28800F: Random vibration class 2 |
| Weight | 2.1 kg (4.6 lb) |

Voltage

Input

| | |
|------------------|--|
| Number of inputs | 5 (A/L1, B/L2, C/L3, N, and earth/ground) |
| Wire gauge | Solid/flexible: 0.25 mm ² to 1.5 mm ² (AWG 24 to AWG 16) |
| Voltage | Max. 1000 V |
| Fuse | 2 A 1000 V 1.5 A ² s, 10 kA IR (A/L1, B/L2, C/L3, N) |

Output

| | |
|--------------|--|
| Connectors | 5x 4 mm safety terminals, 3x red for A/L1, B/L2, C/L3, 1x black for N, 1x green for earth/ground |
| Load current | Max. 1 A rms |

Current

Input/output

| | |
|------------|--|
| Connectors | 5x 4-pin circular compatible with Fluke 354x FC, 173x, and 174x power and energy loggers (these loggers can all be powered from the measured voltage up to 500V) |
|------------|--|



Current inputs for installing measurement probes inside the electrical panel



Ordering information

Fluke-PQ400, Power Quality Window*

Fluke-PQ400/B, Power Quality Basic**

I17XX-FLEX2M-M2M4P, male-male cable 2m for connection of Fluke-17xx iFlex® current probes (4pcs).

I17XX-FLEX2M-M2M1P male-male cable 2m for connection of Fluke-17xx iFlex® current probes, (1pcs).

I17XX-BNC-M2M, Fluke-17xx 4pin male to BNC male cable 2m (1pcs)

I17XX-BNC-M2F, Fluke-17xx 4pin male to BNC female cable 0.1m (1pcs)

Fluke-PQ-MARKER, cable marker set 3P+N+PE

* **Fluke PQ400 contents:** PQ400 enclosure, 4 x male-male cable 2m for connection of Fluke-17xx iFlex® current probes, cable marker set 3P+N+PE, cable ties and instruction sheet.

** Basic version does not include cables, cable ties or markers.

Additional accessories for Fluke 173x and 174x products

| | |
|--------------------|---|
| I17XX-FLEX1500 | Fluke-17xx iFlex 1500A 12in |
| I17XX-FLEX1500/3PK | Fluke-17xx iFlex 1500A 12in, 3 pack |
| I17XX-FLEX1500/4PK | Fluke-17xx iFlex 1500A 12in, 4 pack |
| I17XX-FLEX3000 | Fluke-17xx iFlex 3000A 24in |
| I17XX-FLEX3000/3PK | Fluke-17xx iFlex 3000A 24in, 3 pack |
| I17XX-FLEX3000/4PK | Fluke-17xx iFlex 3000A 24 in, 4 pack |
| I17XX-FLEX6000 | Fluke-17xx iFlex 6000A 36in |
| I17XX-FLEX6000/3PK | Fluke-17xx iFlex 6000A 36in, 3 pack |

| | |
|--------------------|--|
| I17XX-FLEX6000/4PK | Fluke-17xx iFlex 6000A 36in, 4 pack |
| I40S-EL3X | Fluke-17xx I40S-EL 40A clamp-on current transformer |
| I40S-EL3X/3PK | Fluke-17xx I40S-EL 40A clamp-on current transformer, 3 pack |
| I40OS-EL | Fluke-17xx I40OS-EL 400A clamp-on current transformer |
| I40OS-EL/3PK | Fluke-I40OS-EL 3PK, 17xx 400A clamp-on current clamp, 3 pack |

Additional accessories for Fluke 430 Series II products

| | |
|---------------------|--|
| I430-IFLEX-TF-II* | 6000A Fluke 430 Thin iFlex 61cm (24in) |
| I430-IFLEX-TFII-4P* | 6000A Fluke 430 Thin iFlex 61cm (24in) 4 pack |
| I430-FLX-TFII-12* | 6000A Fluke 430 Thin iFlex 30cm (12in) |
| I430-FLX-TFII-48 | 6000A Fluke 430 Thin iFlex 122cm (48in) |
| I40OS* | Fluke I40OS-EL 400A clamp-on current transformer |
| I5S* | 5A AC current probe |
| I5SPQ3* | 5A AC current probe 3 pack for 430 |

* Requires I17XX-BNC-M2F to connect probe to PQ400

Fluke. *Keeping your world
up and running.®*

Fluke Corporation
PO Box 9090, Everett, WA 98206 U.S.A.

Fluke Europe B.V.
PO Box 1186, 5602 BD
Eindhoven, The Netherlands

For more information call:
In the U.S.A. (800) 443-5853 or
Fax (425) 446-5116
In Europe/M-East/Africa +31 (0) 40 2675 200 or
Fax +31 (0) 40 2675 222
In Canada (800)-36-FLUKE or
Fax (905) 890-6866
From other countries +1 (425) 446-5500 or
Fax +1 (425) 446-5116
Web access: <http://www.fluke.com>

©2019 Fluke Corporation.
Specifications subject to change without notice.
Printed in U.S.A. 2/2019 6012030-en

**Modification of this document is not permitted
without written permission from Fluke Corporation.**



Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.



Как с нами связаться

Телефон: 8 (812) 309 58 32 (многоканальный)

Факс: 8 (812) 320-02-42

Электронная почта: org@eplast1.ru

Адрес: 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.