

# DS1600SPE-3

# 1600 Watts

**Distributed Power System** 

Total Power:800 - 1600 WattsInput Voltage:90 to 264 Vac# of Outputs:Single Main

## **Special Features**

- Active Power Factor Correction
- High-power and short form factor
- 80plus Platinum Efficiency
- 1U power supply
- High-density design: 40 W / in<sup>3</sup>
- Inrush current control
- EN61000-3-2 Harmonic compliance
- N+1 or N+N Redundant
- Active current sharing (10 - 100% load)
- PMBus compliant
- Full digital control
- Compatible with Artesyn's Universal PMBus GUI
- Full digital control
- · Two year warranty
- Reverse airflow option
- Class A + 6 dB margin Conducted/Radiated EMI
- ROHS

## Safety

UL/cUL 60950 (UL Recognized) DEMKO+ CB Report EN60950 EN60950 CE Mark BSMI China CQC





# **Product Descriptions**

The DS1600SPE-3 power supply features a very wide 90 to 264 Vac input voltage range and employ active power factor correction to minimize input harmonic current distortion and to ensure compliance with the international EN61000-3-2 standard. The power supplies also feature active ac inrush current control, to automatically limit inrush current at turn-on to 55 A maximum.

The DS1600SPE-3 can deliver up to 133.3 A from its main +12 Vdc payload output, and up to 3.5 A from its +12 Vdc auxiliary output. The form factor is 1U and may be used in single or in redundant configurations.

DS1600SPE-3 has a power density of more than 40.0 Watts per cubic inch, and compliant 80plus Platinum Efficiency, its efficiency will be 94% at nominal high AC line with 50 percent full load.

DS1600SPE-3 is equipped with an I2C interface available with industry-standard PMBus<sup>™</sup> communications protocol. It also contains a memory device that is preprogrammed with data about the unit – including its type, serial number and date of manufacture – to facilitate replacement in the field.





# **Model Numbers**

Standard	Output Voltage	Minimum Load	Maximum Load	Standby Supply	Air Flow Direction
DS1600SPE-3	12.0Vdc	0A	133.3A	12V@3.5A	Forward (DC Connector to Handle)
DS1600SPE- 3-001	12.0Vdc	0A	133.3A	12V@3.5A	Reverse (Handle to DC Connector)

-

## **Options**

None



# **Electrical Specifications**

## Absolute Maximum Ratings

Stress in excess of those listed in the "Absolute Maximum Ratings" may cause permanent damage to the power supply. These are stress ratings only and functional operation of the unit is not implied at these or any other conditions above those given in the operational sections of this TRN. Exposure to any absolute maximum rated condition for extended periods may adversely affect the power supply's reliability.

Table 1. Absolute Maximum Ratings:

Parameter	Model	Symbol	Min	Тур	Max	Unit
Input Voltage:						
AC continuous operation	All models	V <sub>IN,AC</sub>	90	-	264	Vac
$\begin{array}{l} \mbox{Maximum Output Power (Main + Stand-by)} \\ V_{AC} \leq 180 \mbox{Vac} \\ V_{AC} > 180 \mbox{Vac} \end{array}$	All models	P <sub>O,max</sub>	-	- -	800 1600	W W
Isolation Voltage						
Input to outputs	All models		-	-	3000	Vac
Input to safety ground	All models		-	-	2113	Vac
Ambient Operating Temperature	All models	T <sub>A</sub>	0	-	+50 <sup>1</sup>	°C
Storage Temperature	All models	T <sub>STG</sub>	-40	-	+70	°C
Humidity (non-condensing)						
Operating	All models		20	-	95	%
Non-operating	All models		10	-	95	%
Altitude						
Operating	All models		-	-	16,400 <sup>2</sup>	feet
Non-operating	All models		-	-	50,000	feet

Note 1 - DS1600SPE-3: 1600W from 0 to 50 °C, can operate up to 65°C at 2% derated power for every °C above 50°C.

DS1600SPE-3-001: 1600W from 0 to 40°C, can operate up to 60°C at 1% derated power for every °C above 40°C

Note 2 - Operating altitude up to 16,400 feet, derated after 10,000 feet, detail see page 19.

## Input Specifications

Table 2. Input Specifications:

Parameter	Conditions	Symbol	Min	Тур	Max	Unit
Operating Input Voltage, AC		V <sub>IAC</sub>	90	115/230	264	Vac <sub>RMS</sub>
Input Vac Source Frequency		f <sub>IAC</sub>	47	50/60	63	Hz
Maximum Input Current ( $I_O = I_{O,max}, I_{Vsb} = I_{Vsb,Max}$ )	$V_{IAC} = 90V_{AC}$	I <sub>I,max</sub>	-	-	10.5	A <sub>RMS</sub>
Harmonic Line Currents	All	THD	Pe	r IEC1000-	3-2	
Power Factor	20% load and above		-	0.9	-	
Startup Surge Current (Inrush) @ 25°C	$V_{IAC} = 264V_{AC}$	I <sub>I,surge</sub>	-	-	55	А <sub>РК</sub>
Input Fuse	Internal,5x20mm, Quick Acting 16A, 250V		-	-	16	A
Leakage Current to earth ground	$V_{IAC} = 240V_{AC}$ $f_{IAC} = 50/60$ Hz		-	-	1.75	mA
	$I_{O} = 10\% I_{O,max}$ $V_{IAC} = 230V_{AC}$	η	-	-	89	%
	$I_{O} = 20\% I_{O,max}$ $V_{IAC} = 230V_{AC}$	η	-	-	93	%
Operating Efficiency	$I_{O} = 50\% I_{O,max}$ $V_{IAC} = 230V_{AC}$	η	-	-	94	%
	$I_{O} = 100\% I_{O,max}$ $V_{IAC} = 230V_{AC}$	η	-	-	91.5	%
	Efficiency measurements do Internal AC-DC and DC-DC F	ne as per Gen Power Supplies	eralized Test F	Protocol for Ca	lculating Energ	y Efficiency of
System Stability: Phase Margin Gain Margin			45 -6	-	-	Ø dB

## **Output Specifications**

Table 3.	<b>Output Specifications:</b>
----------	-------------------------------

Parameter	Condition	Symbol	Min	Тур	Max	Unit
	AU	±%V <sub>O</sub>	-0.2		+0.2	%
Factory Set Voltage	All	±%V <sub>sb</sub>	-3		+3	%
	Inclusive of set-point,	Vo	11.4	12.0	12.6	
Output Regulation	temperature change, warm-up drift and dynamic load	$V_{Vsb}$	11.4	12.0	12.6	V
	Measure with a 0.1uF ceramic capacitor in	Vo	-	-	150	
Output Ripple, pk-pk	parallel with a 10uF tantalum capacitor, 0 to 20MHz bandwidth	$V_{Vsb}$	-	-	150	mV <sub>PK-PK</sub>
	$V_{AC} \le 180 Vac$		2 <sup>1</sup>	-	66.67	А
Output Current	V <sub>AC</sub> > 180Vac	1 <sub>0</sub>	2 <sup>1</sup>		133.3	
	$90 \le V_{IAC} \le 264 Vac$	I <sub>Vsb</sub>	0.1 <sup>1</sup>	-	3.5	
V <sub>O</sub> Current Share Accuracy	10% to 100% l <sub>o</sub>		-6.65	-	6.65	А
Minimum Load for Current Sharing			10	-	-	%I <sub>O,max</sub>
Number of Parallel Units	Main Output Current Share connected		-	-	6	
V Lood Constitutes	Ctortura	Vo	2250	-	14,000	μF
	Start up	V <sub>Vsb</sub>	47	-	1000	μF
V <sub>O</sub> Dynamic Response Peak Deviation	50% load change, slew rate = 1A/μs	±%V <sub>O</sub>	-	-	5	%
V <sub>o</sub> Long Term Stability Max change over 24 hours	After thermal equilibrium (30 mins)	±%V <sub>O</sub>	-	-	0.2	%
MTBF	Telcordia Issue 2 Method 1, Case 3 at full load, 25°C		2		-	10⁵ h

Note 1 - Minimum current for transient load response testing only. Unit is designed to operate and be within output regulation range at zero load.

## **System Timing Specifications**

Label	Parameter	Min	Тур	Max	Unit
T1	Delay from AC being applied to $V_{\mbox{\scriptsize SB}}$ being within regulation	20	-	2000	mSec
T2	Delay from AC being applied to main output voltages being within regulation.	-	-	2300	mSec
Т3	Delay from Standby output to ACOK assertion	-	-	20	mSec
T4	Delay from output voltages within regulation limits to PWR_Good asserted.	100	-	1000	mSec
T5	Delay from loss of AC to deassertion of PWR_Good	10	-	-	mSec
T6	Delay from deassertion of PWR_Good to output voltages falling out of regulation.	1	-	-	mSec
T7	Delay from loss of AC to main output being within regulation	11	-	-	mSec
Т8	Delay from loss of AC to assertion of ACOK	-	-	7	mSec
Т9	Delay from Standby output to main output voltage being within regulation.	-	-	300	mSec
T10	Delay from PS_ON_L assertion to output voltages being within regulation.	-	-	350	mSec
T11	Delay from loss of AC to Standby output being within regulation.	150	-	-	mSec
T12	Output voltage rise time from the main output.	2	-	60	mSec
T13	Output voltage rise time from the standby output.	2	-	60	mSec

Table 4. System Timing Specifications:

## System Timing Specifications



Rev.10.10.14\_#1.0 DS1600SPE-3 Series Page 8

### DS1600SPE-3 Performance Curves













Rev.10.10.14\_#1.0 DS1600SPE-3 Series Page 9

### DS1600SPE-3 Performance Curves











Figure 10: DS1600SPE-3 Ripple and Noise Measurement – Vin = 180Vac Full Load: Io = 129.8A, Isb = 3A Ch 4: Vo



Rev.10.10.14\_#1.0 DS1600SPE-3 Series Page 10

## **DS1600SPE-3 Performance Curves**









## **Protection Function Specification**

## Input Fusing

DS1600SPE-3 series is equipped with an internal non user serviceable 16A Fast Acting 250Vac fuse to IEC 127 for fault protection in the L line input.

## Over Voltage / Under Voltage Protection (OVP / UVP)

The power supply will provide latch mode over and under voltage protection as defined by the output under voltage and output over voltage parameters for each output. A fault on the main output and standby will not cause the standby output to shutdown.

OVP

Parameter	Min	Nom	Max	Unit
V <sub>O</sub> Output Overvoltage	13.5	/	15.0	V
Standby Overvoltage	13.5	/	15.0	V

UVP

Parameter	Min	Nom	Max	Unit
V <sub>O</sub> Output Undervoltage	10.5	/	11.0	V
Standby Undervoltage	10.0	/	11.0	V

## **Over Current Protection (OCP)**

DS1600SPE-3 series includes internal current limit circuitry to prevent damage in the event of overload or short circuit. Recovery must be automatic when the overload is removed, if the overload lasts for 500 millisecond or less, and if it is less than or equal to 115% of rated load. If the overload is > 125% of rated load, the power supply will latch off immediately within 10ms. The latched state will require AC power / PS\_ON\_L recycling to restart the power supply. A fault in the main output will not cause the Standby output to shut down. No damage will result to the supply as the result of either short term or long term overloads of the outputs.

The standby output will have an OCP limit from 120% to 150% and will auto-recover when the overload is removed. A fault in the standby output will shutdown other outputs and will auto-recover as well when the overload on the standby is removed.

Parameter	Min	Nom	Max	Unit
V <sub>O</sub> Output Overcurrent	115	/	150	%l <sub>o</sub>
Standby Overcurrent	120	/	150	%l <sub>o</sub>



## Short Circuit Protection (SCP)

The DS1600SPE-3 power supply will withstand a continuous short circuit with no permanent damage, applied to its main output during start-up or while running. A short circuit is defined as an impedance on Vo of 0.04 ohms or less.

When the Standby output is shorted the output will go into "hiccup mode". When the Standby output attempts to restart, the maximum peak current from the Standby output will be less than 20.0A peak. The maximum average current, taking into account the "hiccup" duty cycle, is less than rated output current.

Excessive peak currents due to the discharge of output capacitors are not controllable in the event of short circuit at the output.

## **Over Temperature Protection (OTP)**

The power supply will be internally protected against over temperature conditions. There will be three over-temperature protection sensing - on the main output, the PFC circuit and on the standby output. When one of the sensing circuits has reached the OTP limit, all outputs, except standby, will shut down and will remain off until the over-temperature condition no longer exists. The standby output will shut down due to OTP only when the ambient temp has gone above 80degC. A suitable hysteresis point between the OTP threshold and the recovery point will be set to ensure there is no frequent on-off cycling of the outputs. The temperature recovery point will be set well-within the operating temperature range. Upon reaching the temperature recovery point, all outputs will auto-recover.

Any OTP fault will be reported in the PMBus status flag, without discriminating on which OTP sensing circuit was triggered.

### Input Brown-out Protection

When the power supply is operating at high line input and at full load rating, the power supply can protect itself when the input voltage drops down to less than 180Vac. The power supply is dual-rated for input line so it will revert to the low-line over-current limit when the input line transitions to low line during brown-out testing.

The latched state will require recycling AC power or PS\_ON or an On/OFF command.

### Fan Fault Protection

The power supply will be internally protected against fan fault conditions.

# **Mechanical Specifications**

## **Mechanical Outlines**







MODEL	AIRFLOW DIRECTION
DS1600SPE-3	Forward <
DS1600SPE-3-001	REVERSE
DS1600SPE-3-401	FORWARD

### **Connector Definitions**

#### **AC Input Connector**

Pin 1 - L1 Pin 2 - L2 Pin 3 - Earth Ground

## Output Connector – Power Blades

- P1-P8 + Main Output ( $V_0$ )
- P9-P18 Return
- P19-P20 + Standby Output (Vsb)
- P21-P28 Return
- P29-P36 + Main Output (V<sub>O</sub>)

#### **Output Connector – Control Signals**

- S1
   PS\_PRESENT

   S2
   A1

   S3
   A0
- S4 PWR\_Good
- S5 ACOK (AC Input Present)
- S6 RETURN
- S7 I SHARE
- S8 Reserved
- S9 PS\_INTERRUPT\_L
- S10 RETURN
- S11 Reserved
- S12 Reserved
- S13 PS ON L
- S14 PS\_KILL\_H
- S15 Reserved
- S16 RETURN
- S17 SDA
- S18 RETURN
- S19 SCL
- S20 RETURN
- S21 REMOTE SENSE-
- S22 RETURN
- S23 REMOTE SENSE+
- S24 A2



#### Power Supply Output Card Edge (Bottom Side)



Power Supply Output Card Edge (Top Side)



## Power / Signal Mating Connectors and Pin Types

Table 5. Mating Connectors for DS1600SPE-3 series

Reference	On Power Supply	Mating Connector or Equivalent	
AC Input Connector	IEC320-C13	IEC320-C14	
Quitaut Connector	Card adap	FCI Power Blade 10107844-002LF Straight Pins	
Output Connector	Card-edge	FCI Power Blade 10115859-004LF Right Angle Pins	



## **LED indicator Definition**



One bi-color (green/amber) LED at the power supply front provides status signal. The status LED conditions is shown on the below table.

Condition	LED Status
AC Input = OFF	Off
$V_{SB} = ON, V_O = ON$	Solid Green
$V_{SB} = ON, V_O = OFF, AC Input = ON$	Blinking Amber
$V_O/V_{SB} = OCP / OVP / OTP / FAN FAULT$	Blinking Amber



# <u>Weight</u>

The DS1600SPE-3 series weight is 2.2 lbs / 1 kg maximum.

# **Environmental Specifications**

## **EMC Immunity**

DS1600SPE-3 series power supply is designed to meet the following EMC immunity specifications:

Table 6. Environmental Specifications:

Document	Description
FCC 47CFR 15 Subpart C/ ISPR 22/ B/ EN55022, Class A	Conducted and Radiated EMI Limits
EN61000-3-2	Harmonic Currents
EN61000-3-3	Voltage Fluctuations
IEC/EN 61000-4-2	Electromagnetic Compatibility (EMC) - Testing and measurement techniques – Electrostatic discharge immunity test. +/-15KV air, +/-8KV contact discharge, performance Criteria B
IEC/EN 61000-4-3	Electromagnetic Compatibility (EMC) - Testing and measurement techniques, Radiated, radio-frequency, electromagnetic field immunity test, Criteria A
IEC/EN 61000-4-4	Electromagnetic Compatibility (EMC) - Testing and measurement techniques, Electrical Fast Transient/Burst Immunity Test. 2KV for AC power port Criteria B, 0.5KV for DC ports, I/O and signal ports performance Criteria A.
IEC/EN 61000-4-5	Electromagnetic Compatibility (EMC) - Testing and measurement techniques – 2KV common mode and 1KV differential mode for AC ports performance criteria B.
IEC/EN 61000-4-11	Electromagnetic Compatibility (EMC) - Testing and measurement techniques : Voltage Dips and Interruptions: >30% reduction for 500ms, Criteria C,>95% reduction for 10mS, Criteria C, >95% reduction for 500mS, Criteria C
EN55022	Information Technology Equipment-Immunity Characteristics, Limits and Method of Measurements



DS1600SPE-3 Series

Page 19

## **Safety Certifications**

The DS1600SPE-3 power supply is intended for inclusion in other equipment and the installer must ensure that it is in compliance with all the requirements of the end application. This product is only for inclusion by professional installers within other equipment and must not be operated as a stand alone product.

Table 7. Safety Certifications for DS1600SPE-3 series power supply system	n.
---	----

Document	File#	Description
UL 60950 No.		US and Canada Requirements
CSA 22.2 No. 60950-1		Information Technology Equipment - Safety - Part 1: General Requirements (Bi-National standard, with UL 60950-1)
EN60950		European Requirements
EN60950 Deviations		International Requirements
CB Certificate and Report		(All CENELEC Countries)
CHINA CQC Approval		China Requirements
BSMI		Taiwan Requirement



#### **EMI Emissions**

The DS1600SPE-3 series has been designed to comply with the Class A limits of EMI requirements of EN55022 (FCC Part 15) and CISPR 22 (EN55022) for emissions and relevant sections of EN61000 (IEC 61000) for immunity. The unit is enclosed inside a metal box, tested at 1600W using resistive load with cooling fan.

#### **Conducted Emissions**

The applicable standard for conducted emissions is EN55022 (FCC Part 15). Conducted noise can appear as both differential mode and common mode noise currents. Differential mode noise is measured between the two input lines, with the major components occurring at the supply fundamental switching frequency and its harmonics. Common mode noise, a contributor to both radiated emissions and input conducted emissions, is measured between the input lines and system ground and can be broadband in nature.



The DS1600SPE-3 power supplies have internal EMI filters to ensure the convertors' conducted EMI levels comply with EN55022 (FCC Part 15) Class A and EN55022 (CISPR 22) Class A limits. The EMI measurements are performed with resistive loads at maximum rated loading.

DS1600SPE-3 Series

Page 20

Sample of EN55022 Conducted EMI Measurement at 110Vac input

Note: Red Line refers to Emerson Quasi Peak margin, which is 6dB below the CISPR international limit. Blue Line refers to the Emerson Average margin, which is 6dB below the CISPR international limit.

#### **Conducted Emissions**

Table 8. Conducted EMI emission specifications of the DS1600SPE-3 series

Parameter	Model	Symbol	Min	Тур	Max	Unit
FCC Part 15, class A	All	Margin	-	-	6	dB
CISPR 22 (EN55022) class A	All	Margin	-	-	6	dB



#### **Radiated Emissions**

Unlike conducted EMI, radiated EMI performance in a system environment may differ drastically from that in a stand-alone power supply. It is thus recommended that radiated EMI be evaluated in a system environment. The applicable standard is EN55022 Class A (FCC Part 15). Testing ac-dc convertors as a stand-alone component to the exact requirements of EN55022 can be difficult, because the standard calls for 1m leads to be attached to the input and outputs and aligned such as to maximize the disturbance. In such a set-up, it is possible to form a perfect dipole antenna that very few ac-dc convertors could pass. However, the standard also states that 'an attempt should be made to maximize the disturbance consistent with the typical application by varying the configuration of the test sample.



## **Forced Air Cooling**

supply.

The DS1600SPE-3 series power supplies included internal cooling fans as part of the power supply assembly to provide forced air-cooling to maintain and control temperature of devices and ambient temperature in the power supply to appropriate levels. The standard direction of airflow is from the DC connector end to the AC connector end of the power

DS1600SPE-3 Series

Page 22

The cooling fan is a variable speed fan. In Standby mode power supply fan will operate at minimum speed to maintain component reliability at all load, line and ambient conditions. When 12V output is enabled, power supply fan will operate at minimum achievable fan speed. Power supply fan speed control algorithms will vary the speed so that the critical component temperatures do not exceed safe operating levels. Fans will be powered from voltage source inside the power supply and from system side voltage source.



DS1600SPE-3 Series

Page 23

## **Power Derating Curves**

DS1600SPE-3 series total output power will be derated according to the curve shown below. All models can provide derated output power from 50degC up to 65deg C ambient temperature max.

![](_page_22_Figure_3.jpeg)

![](_page_22_Figure_4.jpeg)

![](_page_23_Picture_0.jpeg)

### Storage and Shipping Temperature / Humidity

The DS1600SPE-3 series power supplies can be stored or shipped at temperatures between -40 °C to +70 °C and relative humidity from 10% to 95% non-condensing.

### <u>Altitude</u>

The DS1600SPE-3 series will operate within specifications at altitudes up to 16,400 feet above sea level. The power supply will not be damaged when stored at altitudes of up to 50,000 feet above sea level.

When Altitude come up to 16400 feet of see level, (ambient temperature derated to 40 degrees C at 10,000 feet), power derates to 80% load at 50°C or 100% load at 35°C.

![](_page_23_Figure_6.jpeg)

### Humidity

Operating: Power supply will be designed to operate with no degradation of performance while operating in range of 20% RH to 95%RH non-condensing.

Non-Operating: Power supply will be designed to operate with no degradation of performance while operating in range of 10%RH-95%RH non-condensing.

### **Vibration**

The DS1600SPE-3 series power supply will pass the following vibration specifications:

## **Non-Operating Random Vibration**

Acceleration	2.21	gRMS			
Frequency Range	5-500	Hz			
Duration	30	mins			
Direction	Rotating each axis on vertical vibration				
PSD Profile	SLOPE FREQ <u>dB/oct</u> 5 Hz 20Hz 500 Hz	<b>PSD</b> <u>g<sup>2</sup>/Hz</u> 0.001 g <sup>2</sup> /Hz 0.010 g <sup>2</sup> /Hz 0.010 g <sup>2</sup> /Hz			

Acceleration	3.12	gRMS			
Frequency Range	5-500	Hz			
Duration	30	mins			
Direction	Rotating each axis on vertical vibration				
PSD Profile	SLOPE FREQ <u>dB/oct</u> 5 Hz 20Hz 500 Hz	<b>PSD</b> <u>g²/Hz</u> 0.002 g²/Hz 0.020 g²/Hz 0.020 g²/Hz			

## Shock

The DS1600SPE-3 power supply will pass the following vibration specifications:

## Non-Operating Half-Sine Shock

Acceleration	30	G	
Duration	18	msec	
Pulse	Half-Sine		
No. of Shock	3 shock on each of 6 faces		

![](_page_25_Picture_0.jpeg)

# **Power and Control Signal Descriptions**

## AC Input Connector

This connector supplies the AC Mains to the DS1600SPE-3 power supply.

Pin 1 - L1 Pin 2 - L2 Pin 3 - Earth Ground

### **Output Connector – Power Blades**

These pins provide the main output for the DS1600SPE-3. The + Main Output ( $V_0$ ) and the Main Output Return pins are the positive and negative rails, respectively, of the  $V_0$  main output of the DS1600SPE-3 power supply. The Main Output ( $V_0$ ) is electrically isolated from the power supply chassis.

P1-P8- + Main Output (V\_O)P9-P18- Main Output ReturnP19-P20- Standby Output (Vsb)P21-P28- + Main Output / Standby ReturnP29-P36- + Main Output (V\_O)

### **Output Connector - Control Signals**

The DS1600SPE-3 series contains a 24 pins control signal header providing an analogue control interface, Standby power and I<sup>2</sup>C interface signal connections.

### PS\_ON\_L - (pin S13)

This signal input pin controls the normal turning ON and Off of the Main Output of the DS1600SPE-3 power supply. The power supply main output ( $V_0$ ) will be enabled when this signal is pulled low, below 0.8 V. The Power supply output (except Vsb output) will be disabled when this input is driven higher than 2.0 V, or left open circuited. Recommended pull-up resistor to 12 Vsb is 8.2 k with a 3.0 k pull-down to ground. A 100 pF decoupling capacitor is also recommended.

![](_page_25_Figure_13.jpeg)

![](_page_26_Picture_0.jpeg)

#### Main Output Remote Sense Return, Main Output Remote Sense - (pins S21, S23)

The main output of the DS1600SPE-3 is equipped with a Remote Sensing capability that will compensate for a power path drop around the entire loop of 200 millivolt. This feature is implemented by connecting the Main Output Remote Sense (pin S23) and the Main Output Remote Sense Return (pin S21) to the positive and negative rails of the main output, respectively, at a location that is near to the load. Care should be taken in the routing of the sense lines as any noise sources or additional filtering components introduced into the voltage rail may affect the stability of the power supply. The DS1600SPE-3 will operate appropriately without the sense lines connected; however it is recommended that the sense lines be connected directly to the main output terminals if remote sensing is not required. This remote sense circuit will not raise the power supply's output voltage to the OVP trip level. Main Output Remote Sense has no effect on the Standby Output (Vsb).

12V Main output and Standby output return lines are connected together inside PSU and connected to PSU chassis directly. It is recommended to connect 12V return to system chassis on end system application for better common mode noise.

#### Standby Output, Standby Output Return - (pins P19-P12, P21-P28)

The DS1600SPE-3 provides a regulated 12 volt 3 amp auxiliary output voltage to power critical circuitry that must remain active regardless of the on/off status of the power supply's main output. The Standby Output (Vsb) voltage is available whenever a valid AC input voltage is applied to the unit. The Standby Output is independently short circuit protected and is referenced to the Standby Output Return pins (P21-P28).

#### ACOK – (pin S5)

Signal used to indicate the presence of AC input to the power supply. A logic level HIGH will indicate that the AC input to the power supply is within the operating range while a logic level LOW will indicate that AC has been lost. This is an open collector/drain output. This pin is pulled high by a 1.0kohm resistor connected to 3.3V inside the power supply. It is recommended that this pin be connected to a 100pF decoupling capacitor and pulled down by a 100kohm resistor.

![](_page_26_Figure_9.jpeg)

#### I\_SHARE – (pin S7)

The DS1600SPE-3 supports active current sharing through a single wire connection between the power supplies. This input/output signal pin allows two or more power supplies to share the main output load current to increase the overall power capability or to operate the units in a N+N configuration for redundancy purposes.

![](_page_27_Picture_0.jpeg)

The voltage of this signal will be a linear slope from no load to full load. At 66.6A output when two supplies are running in parallel must be between 3.85 and 4.15V. At 133.3A output when two supplies are running in parallel must be between 7.75 and 8.25V.

All outputs with active current sharing will share load current and the current share errors (CSE) are 4%, 8%, 16% and 40% of the average current at 100%, 50%, 25% and 10% rated load respectively. Example: If the maximum rated output current of an output is 100A, then the difference between half of total load and supplies' current cannot be greater than +-2A/100%, +-2A/50%, +-2A/25% and +-2A/10% load. The current share loop should be activated when the output current exceed 10% of total load.

#### PS\_KILL\_H - (pin S14)

First break/Last Mate active LOW signal which enables/disables the main output. This signal will have to be pulled to ground at the system side with a 220ohm resistor. A 100pF decoupling capacitor is also recommended (Standby output will remain on).

![](_page_27_Figure_6.jpeg)

#### SDA, SCL and S\_INTERRUPT\_L – (pins S17, S19, S9)

Please refer to "Communication Bus Descriptions" section.

#### PWR\_Good – (pin S4)

Signal used to indicate that main output voltage is within regulation range. The PWR\_Good signal will be driven HIGH when the output voltage is valid and will be driven LOW when the output falls below the under-voltage threshold. This signal also gives an advance warning when there is an impending power loss due to loss of AC input or system shutdown request.

This is an open collector/drain output. This pin is pulled high by a 1.0kohm resistor connected to 3.3V inside the power supply. It is recommended that this pin be connected to a 100pF decoupling capacitor and pulled down by a 10kohm resistor.

![](_page_28_Picture_0.jpeg)

#### PS\_PRESENT – (pin S1)

Signal used to indicate to the system that a power supply is inserted in the power bay. This pin is shorted to the Standby return in the power supply. Recommended pull-up resistor to 12Vsb is 8.2k with a 3.0k pull-down to ground. A 100pF decoupling capacitor is also recommended.

### SDA, SCL and PS\_INTERRUPT\_L – (pin S17, S19 and S9)

Please refer to "Communication Bus Descriptions" section.

#### A0, A1 and A2- (pins S2, S3 and S24)

Please refer to "Communication Bus Descriptions" section.

![](_page_29_Picture_0.jpeg)

# **Communication Bus Descriptions**

## I<sup>2</sup>C Bus Signals

The DS1600SPE-3 power supply contains enhanced monitor and control functions implemented via the l<sup>2</sup>C bus. The DS1600SPE-3 l<sup>2</sup>C functionality (PMBus<sup>™</sup> and FRU data) can be accessed via the output connector control signals. The communication bus is powered either by the internal 3.3V supply or from an external power source connected to the Standby Output (ie: accessing an unpowered power supply as long as the Standby Output of another power supply connected in parallel is on).

If units are connected in parallel or in redundant mode, the Standby Outputs must be connected together in the system. Otherwise, the I<sup>2</sup>C bus will not work properly when a unit is inserted into the system without the AC source connected.

Note: PMBus<sup>™</sup> functionality can be accessed only when the PSU is powered-up. Guaranteed communication I<sup>2</sup>C speed is 100KHz.

#### SDA, SCL (I<sup>2</sup>C Data and Clock Signals) – (pins S17, S19)

I<sup>2</sup>C serial data and clock bus - these pins are internally pulled up to internal 3.3V supply with a 100K resistor. These pins must be pulled-up in the system by an 2.2K ohm resistor to 3.3V and a 200pF decoupling capacitor at the system side.

Refer to the communication interface specifications for more details

#### PS\_INTERRUPT\_L – (pin S9)

PS\_INTERRUPT\_L is used to send a signal to the system that a fault in the power supply occurred. This signal is normally logic level HIGH. It will go to a LOW logic level when a fault bit has been set in the power supply's status register. This event can be triggered by faults such as OVP, OCP, OTP, and fan fault. This signal can be cleared by a CLEAR\_FAULT command. Recommended pull-up resistor to 12Vsb is 8.2k with a 3.0k pull-down to ground. A 200pF decoupling capacitor is also recommended.

#### A0, A1 and A2 (I<sup>2</sup>C Address) – (pin S2, S3 and S24)

These three input pins are the address lines A0, A1 and A2 to indicate the slot position the power supply occupies in the power bay and define the power supply addresses for FRU data and PMBus<sup>™</sup> data communication. This allows the system to assign different addresses for each power supply. During I<sup>2</sup>C communication between system and power supplies, the system will be the master and power supplies will be slave.

They are internally pulled up to internal 3.3V supply with a 2.2K resistor.

#### I<sup>2</sup>C Bus Communication Interval

The interval between two consecutive I<sup>2</sup>C communications to the power supply should be at least 15ms to ensure proper monitoring functionality.

#### I<sup>2</sup>C Bus Signal Integrity

The noise on the I<sup>2</sup>C bus (SDA, SCL lines) due to the power supply will be less than 400mV peak-to-peak. This noise measurement should be made with an oscilloscope bandwidth limited to 100MHz. Measurements should be make at the power supply output connector with 2.2K ohm resistors pulled up to Standby Output and 100pf ceramic capacitors to Standby Output Return.

![](_page_30_Picture_0.jpeg)

#### I<sup>2</sup>C Bus Internal Implementation, Pull-ups and Bus Capacitances

![](_page_30_Figure_3.jpeg)

### I<sup>2</sup>C Bus - Recommended external pull-ups:

Electrical and Interface specifications of I<sup>2</sup>C signals (referenced to Standby Output Return pin, unless otherwise indicated):

Parameter	Condition	Symbol	Min	Тур	Max	Unit
SDA, SCL internal pull-up resistor		R <sub>int</sub>	-	100	-	Kohm
		R <sub>int</sub>	-	2.2	-	Kohm
Recommended external pull-up resistor	1730	C <sub>int</sub>	-	200	-	pF
	6 PSU	R <sub>int</sub>	-	0.37	-	Kohm
A0,A1,A2 internal pull-up resistor	1 PSU	R <sub>int</sub>	-	2.2	-	Kohm
A0,A1,A2 internal bus capacitance	1 PSU	C <sub>int</sub>	-	200	-	рF
Recommended external pull-down resistor	1 PSU	R <sub>ext</sub>	-	220	-	ohm
Recommended external pull-down capacitance	1 PSU	C <sub>ext</sub>	-	100	-	pF

![](_page_31_Picture_0.jpeg)

## Logic Levels

DS1600SPE-3 series power supply I2C Communication Bus will respond to logic levels as per below:

Logic High: 5.1V Nominal (Specs is 2.1V to 5.5V)\*\* Logic Low: 500mV nominal (Specs is 800mV max)\*\*

## Timings

![](_page_31_Figure_6.jpeg)

Devenuelen	Ormahal	Standard-M	lode Soecs	Actual		l lucia
Parameter	Symbol	Min	Max			Unit
SCL Clock Frequency	f <sub>SCL</sub>	0	100	100		KHz
Hold time (repeated) START condition	t <sub>HD;STA</sub>	4.0	-	4.9		us
LOW period of SCL clock	t <sub>LOW</sub>	4.7	-	5	.3	us
HIGH period of SCL clock	t <sub>HIGH</sub>	4.0	-	4	.1	us
Setup time for repeated START condition	t <sub>SU;STA</sub>	4.7	-	20.4		us
Data hold time	t <sub>HD;DAT</sub>	0	3.45	1.7		us
Data setup time	t <sub>SU;DAT</sub>	250	-	4688		ns
Rise time	t <sub>r</sub>	-	1000	SCL = 961	SDA = 811	ns
Fall time	t <sub>f</sub>	-	300	SCL = 125	SDA = 211	ns
Setup time for STOP condition	t <sub>su;sto</sub>	4.0	-	6.9		us
Bus free time between a STOP and START condition	t <sub>BUF</sub>	4.7	-	62.1		msec

![](_page_32_Picture_0.jpeg)

## **Device Addressing**

The DS1600SPE-3 series will respond to supported commands on the  $I^2C$  bus that are addressed according to pins A2, A1 and A0 pins of output connector.

Address pins are held HIGH by default via pulled up to internal 3.3V (5V)supply with a 2.2K resistor. To set the address as "0", the corresponding address line should be pulled down to logic ground level. Below tables show the address of the power supply with A0, A1 and A2 pins set to either "0" or "1".

DCII Clot		Slot ID Bits EEPROM (M/R)		EEPROM (FRU)	
P30 5101	A2	A1	A0		Address (W/R)
1	0	0	0	0xB0/0xB1	0xA0/0xA1
2	0	0	1	0xB2/0xB2	0xA2/0xA2
3	0	1	0	0xB4/0xB5	0xA4/0xA5
4	0	1	1	0xB6/ 0xB7	0xA6/ 0xA7
5	1	0	0	0xB8/0xB9	0xA8/0xA9
6	1	0	1	0xBA/0xBB	0xAA/0xAB
7	1	1	0	0xBC/ 0xBD	0xAC/ 0xAD
8	1	1	1	0xBE/ 0xBF*	0xAE/ 0xAF*

\* Default PMBus<sup>™</sup> address when A0, A1 and A2 are left open

![](_page_33_Picture_0.jpeg)

## **Reporting Functions**

The power supply will have enhanced monitor and control functions implemented via the I2C bus. This will use the SDA and SCL pins. The power supply monitor will operate as an I2C slave device. The accuracy of the report functions will be as follows:

Firmware Reporting And Monitoring						
Output loading	5 to 20%	50 to 100%				
Input voltage		±5%				
Input current	±0.55A fixed error	±5	5%			
Input power	±5W at <125W ±1.25%					
Output voltage	±2%					
Output current	±1.2 A error for DS1600SPE <sup>1</sup> ±3%					
Temperature	±5 degC on the operating range					
E <sub>IN</sub>	±15% from 10% to 20% load ±5%					
Fan speed	±250 RPM					

PMBus	Yes
Remote ON/OFF	Yes

Note1 - reporting error shall not be more than 2A when the load is below 5%

![](_page_34_Picture_0.jpeg)

## **I<sup>2</sup>C Clock Synchronization**

The DS1600SPE-3 power supply might apply clock stretching. An addressed slave power supply may hold the clock line (SCL) low after receiving (or sending) a byte, indicating that it is not yet ready to process more data. The system master that is communicating with the power supply will attempt to raise the clock to transfer the next bit, but must verify that the clock line was actually raised. If the power supply is clock stretching, the clock line will still be low (because the connections are open-drain).

The maximum time out condition for clock stretching for DS1600SPE-3 is 100 microsecond.

![](_page_34_Figure_5.jpeg)

#### FRU (EEPROM) Data

The FRU (Field Replaceable Unit) data format is compliant with the Intel IPMI v1.0 specification.

The DS1600SPE-3 uses 1 page of EEPROM for FRU purpose. A page of EEPROM contains up to 256 byte-sized data locations.

Where:	OFFSET	- The OFFSET denotes the address in decimal format of a particular data byte within
		DS1600SPE-3 EEPROM.

- VALUE The VALUE details data written to a particular memory location of the EEPROM.
- DEFINITION The contents DEFINITION refers to the definition of a particular data byte.

#### DS1600SPE-3 FRU (EEPROM) Data:

OFFSET		DEFINITION	SPEC	VALUE
(DEC)	(HEX)	(REMARKS)	(DEC)	(HEX)
		COMMON HEADER, 8 BYTES		
0	00	FORMAT VERSION NUMBER (Common Header)	1	01
		7:4 - Reserved, write as 0000b		
	01		010	Da
1	01		216	D8
2	02		8	80
3	03		0	00
4	04		5	05
5	05	MULTI RECORD AREA OFFSET	13	0D
6	06	PAD (reserved) Default value is 0.	0	00
7	07	ZERO CHECK SUM (256 – (Sum of bytes 0 to 6))	209	D1
		CHASSIS INFO AREA( 32 BYTES)		
				04
8	08	7'4 - Reserved write as 0000b	1	01
		3:0 - Format Version Number = 1h for this specification		
9	09	CHASSIS INFO AREA LENGTH in multiple of 8 bytes	4	04
10	0A	CHASSIS TYPE (Default value is 0.)	0	00
		CHASSIS PART NUMBER Type/Length CAh (if used)		
11	0B	Type = "ASCII+LATIN1" = (11)b Length = 10 Bytes = (001010)b	202	CA
12	0C	CHASSIS PART NUMBER BYTES (Default value is 0.)	0	00
13	0D		0	00
14	0E		0	00
15	10		0	00
17	10		0	00
17	12		0	00
19	13		0	00
20	14		0	00
21	15		0	00
22	16	CHASSIS SERIAL NUMBER Type/Length CFH (if used) Type = "ASCII+LATIN1" = (11)b Length = 15 Bytes = (001111)b	207	CF
23	17	CHASSIS SERIAL NUMBER BYTES. Default value is 0	0	00
24	18		Ő	00
25	19		0	00
26	1A		0	00
27	1B		0	00
28	1C		0	00
29	1D		0	00
30	1E		0	00
31	1F		0	00
32	20		0	00

## DS1600SPE-3 FRU (EEPROM) Data:

OFF	SET	DEFINITION	SPEC VALUE	
(DEC)	(HEX)	(REMARKS)	(DEC)	(HEX)
33	21	CHASSIS SERIAL NUMBER BYTES, Default value is 0.	0	00
34	22		0	00
35	23		0	00
36	24		0	00
37	20		0	00
38	26	End Tag (0C1h if used)	193	C1
39	27	CHKSUM (Zero CHKSUM if used)	161	A1
		PRODUCT INFORMATION AREA, 64 BYTES		
40	28	FORMAT VERSION NUMBER (Product Info Area)	1	01
		7:4 - Reserved, write as 0000b		
		3:0 - Format Version Number = 1h for this specification		
41	29	PRODUCT INFO AREA LENGTH (In multiples of 8 bytes)	8	08
42	2A	Language (English)	25	19
43	2B	MANUFACTURER NAME TYPE / LENGTH (0C5H)	199	C7
		7:6 - (11)b, 8-Bit ASCII+Latin 1,		
		5:0 – (000101)b, 5-Byte Allocation		
		MANUFACTURER'S NAME 5 byte sequence		
44	2C	"A"= 41h	65	41
45	2D 2E	R = 520 T"_ 545	82	52
40	2L 2F	"E"- 45h	69 69	45
48	30	"S"= 53h	83	53
49	31	"Y"= 59h	89	59
50	32	"N"=4Eh	78	4E
51	33	PRODUCT NAME Type/Length (CCH)	207	CF
		Type = "ASCII+LATIN1" = (11)b Length = 15 Bytes = (001111)b		
52	34	PRODUCT NAME BYTES (5 Byte sequence)	68	44
53	35		83	53
54	36	"D"	49	31
55	37	"S"	54	36
56	38	4 1 " Kon	48	30
57	39	"6" "6"	48	30
58	3A	-0°	83	53
59	3B	-0°	80	50
60	30		69	45
61	3D		45	2D
62	3E		51	33
63	3⊢	-D*	32	20
64	40	1 - 7 	32	20
65	41	-37	32	20
66	42		32	20
67	43	PRODUCT PART/MODEL NUMBER Type/Length (CFH)	207	CF
		Type = "ASCII+LATIN1" = (11)b Length = 15 Bytes = (001111)b		
68	44	PRODUCT PART/MODEL NUMBER BYTES	68	44
69	45	-D"	83	53
70	46		49	31
/1	47		54	36
/2	48	-6- 	48	30
73	49	"0"	48	30
74	4A	"O"	83	53
75	4B	"5 <i>"</i>	80	50
76	4C	"P"	69	45
77	4D	"E"	45	2D
78	4E	"D"	51	33
79	4F	<u>u_</u> n	32	20
80	50	"3"	32	20
81	51		32	20
82	52		32	20

## DS1600SPE-3 FRU (EEPROM) Data:

OFF	OFFSET DEFINITION			SPEC VALUE	
(DEC)	(HEX)	(REMARKS)	(DEC)	(HEX)	
83	53	PRODUCT VERSION NUMBER Type/Length (C2h)	194	C2	
		Type = "ASCII+LATIN1" = (11)b Length = 2 bytes = (000010)b			
		PRODUCT VERSION NUMBER BYTES			
	- /	Refer to Section 1.2 Product Revision History in latest IPS			
84	54	"A" "A"	65 65	41	
65	55		60	41	
86	56	<b>PRODUCT SERIAL NUMBER</b> Type/Length $= 13$ bytes $= (001101)$ b	205	CD	
00	50		203	00	
		Model ID = DS1600SPE-3 / K369			
87	57	"K"	75	4B	
88	58	"3"	51	33	
89	59	"6"	54	36	
90	5A	"9"	57	39	
		MANUFACTURING YEAR AND WEEK CODE			
91	5B	"W"=57h (Per Unit)	87	57	
92	5C	"W"=57h (Per Unit)	87	57	
		UNIQUE SERIAL NUMBER			
		"SSSS"		50	
93	5D	"S" = 53 (Per Unit)	83	53	
94	DE FE	"S" = 53 (Per Unit)	83	53	
95	5F 60	S = 53 (Per Unit)   "S" = 53 (Per Unit)	83	53	
	00	MODEL DEVISION Actor Model Day See Latest Medel Day in IDS See 1.9			
07	61	"A"	65	41	
98	62	"A"	65	41	
99	63	MANUFACTURING LOCATION			
00	00	"Z" for "Zhonshan, China" In Decimal = 090 In Hex = 5AH	90	5A	
100	64	End Tag	193	C1	
101	65	PAD (reserved), Default value is 0.	0	00	
102	66		0	00	
		ZERO CHECK SUM (256 – (Sum of bytes 40 to 102)) Per Unit			
103	67	Zero Check Sum :Should follow check sum calculation as per IPMI v1.1 specs	187	BB	
		Multi Record Area, 88 Bytes			
		Power Supply Record Header			
104	68	Record type = 00 for Power supply	0	00	
105	69	End of List /Record Format Version Number	2	02	
106	6A	Record Length of Power Supply Record	24	18	
107	6B	Record CHECKSUM of Power Supply Record (Zero CHECKSUM)	23	17	
109	60	(200-(SUM OF DYTES 109 TO 132)	207	CE	
100	00	(256-(sum of bytes 104 to 107)	207	UF UF	
	1	Power Supply Record	4	1	
		Overall Capacity of the Power Supply	1		
		2 Bytes Sequence			
		1600W = 0640H			
109	6D	In Decimal = 64, 06	64	40	
110	6E	In Hex = 40H, 06H	06	06	

## DS1600SPE-3 FRU (EEPROM) Data:

OFF	SET	DEFINITION	SPEC Y	VALUE
(DEC)	(HEX)	(REMARKS)	(DEC)	(HEX)
111 112	6F 70	Peak VA, 1834W = 072AH 2 Bytes Sequence In Decimal = 42, 07 In Hex = 2AH, 07H	42 07	2A 07
113	71	Inrush Current, 55A In Decimal = 055 In Hex = 37H	55	37
114	72	Inrush Interval, 10mS In Decimal = 010 In Hex = 0AH	10	0A
115 116	73 74	Low End Input Voltage Range 1(10mV), (90V / 10mV) 9000 = 2328H 2 Bytes Sequence In Decimal = 040, 035 In Hex = 28H, 23H	40 35	28 23
117 118	75 76	High End Input Voltage Range 1(10mV), (264V/10mV) 26400= 6720H 2 Bytes Sequence In Decimal = 032, 103 In Hex = 20H, 67H	32 103	20 67
119 120	77 78	Low End Input Voltage Range 2(10mV) Not Applicable (Autoswitch)	0	00 00
121 122	79 7A	High End Input Voltage Range 2(10mV) Not Applicable (Autoswitch)	0	00 00
123	7B	Low End Input Frequency Range, 47Hz = 2FH	47	2F
124	7C	Low End Input Frequency Range, 63Hz = 3FH	63	3F
125	7D	AC Dropout Tolerance in ms, 10mS= 0AH	10	0A
126	7E	<ul> <li>Binary Flags, 1 indicates function supported and a 0 indicates function not supported.</li> <li>Bits 7-5: RESERVED, WRITE AS 000B</li> <li>Bit 5: PMBUS capable or not. 1 if Supported 0 if not. BIT = 1</li> <li>Bit 4: Tachometer Pulses Per Rotation / Predictive Fail Polarity BIT = 0</li> <li>Bit 3: Hot Swap / Redundancy Support BIT = 1</li> <li>Bit 2: Auto switch Support BIT = 1</li> <li>Bit 1: Power Factor Correction Support BIT = 1</li> <li>Bit 0: Predictive Fail Support BIT = 0</li> </ul>	46	2E
127 128	7F 80	Peak Wattage Capacity and Holdup Time 2 Bytes Sequence 1600W = 0640H 10ms = 0BH	64 166	40 A6
129 130 131	81 82 83	Combined Wattage, Not Applicable Byte 1: 0000 0000 0000 0000 Byte 2 and Byte 3: 00H, 00H 3 Bytes Sequence	0 0 0	00 00 00
132	84	Predictive Fail Tachometer Lower Threshold, Not Applicable. Predictive Failure is not Supported.	0	00
	67	12V DC OUTPUT RECORD HEADER		
133	85 86	Record type = 01 for DC Output Record	1	01
134	87	Record Length of 12V DC Output Record	∠ 13	02 0D
136	88	Record CHECKSUM of 12V DC Output Record (Zero CHECKSUM) (256-(sum of bytes 138 to 150) Header CHECKSUM of 12V DC Output Record Header (Zero CHECKSUM)	184	B6
137	09	(256-(sum of bytes 1313to 136)	50	50

## DS1600SPE-3 FRU (EEPROM) Data:

OFF	SPEC	VALUE		
(DEC)	(HEX)	(REMARKS)	(DEC)	(HEX)
		12V OUTPUT RECORD		
138	8A	Output Information, 001 = 01H Bit 7: Standby Information = 0B Bits 6-4: Reserved, Write as 000B Bits 3-0: Output Number 1 = 001B	1	01
139 140	8B 8C	Nominal Voltage (10mV), (12V / 10mV) 1200 = 04B0H 2 Bytes Sequence In Decimal: 176, 004 In Hex: B0H, 04H	176 4	B0 04
141 142	8D 8C	Maximum Negative Voltage Deviation (10mV), 1140 = 0474H 2 Bytes Sequence In Decimal: 116, 004 In Hex: 74H, 04H	116 4	74 04
143 144	8F 90	Maximum Positive Voltage Deviation (10mV), 1260 =04ECH         2 Bytes Sequence         In Decimal: 236, 004         In Hex: ECH, 04H         Ripple and Noise pk-pk (mV), 150 = 96H         2 Bytes Sequence	236 4	EC 04
145 146	91 92	In Decimal: 150, 000 In Hex: 96H, 00H	120 0	78 00
147 148	93 94	Minimum Current Draw (10mA), 0200 = 00C8H 2 Bytes Sequence In Decimal: 050, 000 In Hex: 32H, 00H	200 0	C8 00
149 150	95 96	Maximum Current Draw (10mA), 6250 = 3415H In Decimal: 21, 52 In Hex: 15H, 34H	21 52	15 34
		Vsb OUTPUT RECORD HEADER		
151 152 153 154 155	97 98 99 9A 9B	Record type = 01 for DC Output Record End of List /Record Format Version Number for 3V3SB Output Record Record Length of 3V3SB Output Record Record CHECKSUM of 3V3SB Output Record (Zero CHECKSUM) (256-(sum of bytes 156 to 168) Header CHECKSUM of 3V3SB Output Record Header (Zero CHECKSUM) (256-(sum of bytes 151 to 154)	1 2 13 179 61	01 02 0D B3 3D
156	9C	Output Information, 002 = 02H Bit 7: Standby Information = 1B Bits 6-4: Reserved, Write as 000B Bits 3-0: Output Number 2 = 010B	130	82
157 158	9D 9E	Nominal Voltage (10mV), (12V / 10mV) 1200 = 04B0H 2 Bytes Sequence In Decimal: 176, 004 In Hex: B0H, 04H	176 4	B0 04
159 160	9F A0	Maximum Negative Voltage Deviation (10mV), 1140 = 0474H 2 Bytes Sequence In Decimal: 116, 004 In Hex: 74H, 04H	116 4	74 04
161 162	A1 A2	Maximum Positive Voltage Deviation (10mV), 1260 =04ECH 2 Bytes Sequence In Decimal: 236, 004 In Hex: ECH, 04H	236 4	EC 04
163 164	A3 A4	Ripple and Noise pk-pk (mV), 120 = 78H 2 Bytes Sequence In Decimal: 120, 000 In Hex: 78H, 00H	120 0	78 00

## DS1600SPE-3 FRU (EEPROM) Data:

IDEC         (HEX)         (HEX)         (DEC)         (HEX)           A         Minimum Current Draw (TonA), (0:A / 10mA) 10 = 000AH         -	OFF	SET	DEFINITION	SPEC	VALUE
Instructure         Minimum Current Draw (10mA), (0.1A / 10mA) 10 – 000AH         Instructure         Instructu	(DEC)	(HEX)	(REMARKS)	(DEC)	(HEX)
165         AS         Potestimation         10         0A           1166         AS         In Decimation 200,000         0         0         0         0           167         A7         In Decimation 201,000         1         0         0         0         0           168         AS         In Decimation 24,001         294         5E         5E           170         AS         Endod Lisk Record Formal Version Number for 3.3Vsb output Record         120         A2         2A           171         AB         Endod Lisk Record Formal Version Number for 3.3Vsb output Record         42         2A           172         AA         Record Length of OEM Record Lisk Ceve Chemose (Zero CHECKSUM)         148         94           172         AA         Record Length of OEM Record Lisk Ceve Chemose (Zero CHECKSUM)         148         94           173         AD         Header CHECKSUM Of DEM Record Lisk Ceve Chemose (Zero CHECKSUM)         0         0         00           174         AE         Manufacturer ID (3 bytes, Default is 0)         0         0         00         00           177         BA         RESERVED         0         0         00         00         00           177         BH <td< td=""><td></td><td></td><td>Minimum Current Draw (10mA), (0.1A / 10mA) 10 = 000AH</td><td></td><td></td></td<>			Minimum Current Draw (10mA), (0.1A / 10mA) 10 = 000AH		
165         A5         In Decimal: 01, 000         00         00           166         A6         In Neto: 041, 001         0         00           167         A7         In Decimal: 94, 001         94         5E           168         A8         In Neto: 5E1, 011         1         01           OEM RECORD HEADER           CO           TO MA End of Ust Record Format Version Number for 3.3Vsb output Record         192         CO           170         AA         Record Lepth of CEM Record (Zero CHECKSUM)         0         0         00           173         AA         Record CHECKSUM of CEM Record Head (Zero CHECKSUM)         148         94           IEM and Lepth of CEM Record Head (Zero CHECKSUM)         0         0         00           IEM and Lepth Header (Zero CHECKSUM)         0         0         00           IEM and Lepth Header (Zero CHECKSUM)         148         94           IEM ESERVED         0         0         00         00           IEM ESERVED         0         0         00         00           IEM ESERVED         0         0         00         00         00         00 <t< td=""><td></td><td></td><td>2 Bytes Sequence</td><td></td><td></td></t<>			2 Bytes Sequence		
166         A6         In Hac: 0AH, 00H         Maximum Current Draw (10mA), (3.5A / 10mA), 350 = 015EH         0         00         00           167         A7         In Decimics 34, 001         1         0         0         0           168         A3         In the:: SEH, 01H         0         0         0         0           170         AA         End of Lisk Record For CMR Record         130         82         0         0         0         0           171         AB         Record Lingth of OEM Record         20         22         C0         0	165	A5	In Decimal: 010, 000	10	0A
International Constraints         In	166	A6	In Hex: 0AH, 00H	0	00
167 188         A7 bit Decimal S4, 001         94 5E         5E 01           198         A9 A8         Record Upp = .00H for OEM Record PRecord Upp = .00H for OEM Record A8         130 42         22 20 20 20 20 20 20 20 20 20 20 20 20 2			Maximum Current Draw (10mA), (3.5A / 10mA) 350 = 015EH		
103         A         In Education (0, 0)         94         1         01           Im Education (0, 0)           Im Education (0, 0)           100         A)         Record (0, 0)         192         CO           170         AA         Record (0, 0)         192         CO           171         AA         Record (1, 1)         0         0         0           172         AC         Record (1, 1)         0         0         0         0           172         AC         Record (1, 1)         0         Record (2 arc) CHECKSUM)         0         0         0         0           173         AF         RESERVED         0         0         0         0         0           174         AF         RESERVED         0	167	<u>۸</u> 7	2 Bytes Sequence	04	55
100         Initial Cut, Yun         OEM RECORD HEADER           160         A9         Record type = COH for OEM Record         132         C0           170         AA         End of Lis/Record Found Version Number for 3.3Vsb output Record         42         2A           171         AB         Record Longth of OEM Record (Zero CHECKSUM)         42         2A           173         AD         Header CHECKSUM of OEM Record (Zero CHECKSUM)         148         94           125         CEM RECORD         0         00         00           173         AD         Header CHECKSUM of OEM Record (Zero CHECKSUM)         148         94           1265         RESERVED         0         0         00         00           174         AE         Manufacturer ID (3 bytes, Default is 0)         76         B0         0         00           176         BC         RESERVED         0         0         00         00         00           177         B1         RESERVED         0         0         00         00         00         00         00         00         00         00         00         00         00         00         00         00         00         00         00	167	A7 A8	In Decimal. 94, 001	94 1	5E 01
169         A9         Record type = COH for OEM Record         192         C0           170         AA         End of List /Record Format Version Number for 3.3Vsb output Record         130         82           171         AA         Record CHEQNSUM         0         0         0           173         AC         Record CHECKSUM of OEM Record (Zero CHECKSUM)         0         0         0           173         AC         Record CHECKSUM of OEM Record Leader (Zero CHECKSUM)         148         94           174         AC         Reserved CHECKSUM of OEM Record Header (Zero CHECKSUM)         0         0         0           174         AF         RESERVED         0         0         00         0           174         AF         RESERVED         0         0         00         00           176         BO         RESERVED         0         0         00         00           177         B1         RESERVED         0         0         00         00         00           180         B4         RESERVED         0         0         00         00         00         00         00         00         00         00         00         00         00         <	100	7.0	OEM RECORD HEADER	1	01
170         AA         End of List /Record Format Version Number for 3.3Vsb output Record         130         82           171         AB         Record Length of OEM Record         42         23           173         AD         Header Clenck SUM of OEM Record Header (Zero CHECKSUM)         0         00           173         AD         Header Clenc CHECKSUM of OEM Record Header (Zero CHECKSUM)         148         94           OEM RECORD         0         00         00           175         AF         RESERVED         0         00         00           176         BD         RESERVED         0         00         00           177         B1         RESERVED         0         00         00           178         B2         RESERVED         0         00         00           180         B4         RESERVED         0         00         00           181         B5         RESERVED         0         00         00           182         B6         RESERVED         0         00         00           183         B7         RESERVED         0         00         00         00           184         B8         RESERV	169	Δ9	Becord type = C0H for OFM Becord	192	C0
171         AB         Record Length of OEM Record (Zero CHECKSUM) Header CHECKSUM of OEM Record (Zero CHECKSUM) (Z66-(sum of bytes 169to 172)         0         0         00           173         AD         Header CHECKSUM of OEM Record (Zero CHECKSUM) (Z66-(sum of bytes 169to 172)         0         0         00           174         AE         Manufacturer ID (3 bytes, Default is 0)         0         0         00           175         AF         RESERVED         0         00         00           176         BO         RESERVED         0         00         00           177         B1         RESERVED         0         00         00           178         B2         RESERVED         0         00         00           180         B4         RESERVED         0         00         00           181         B5         RESERVED         0         00         00           182         B5 RESERVED         0         00         00         00           184         B8         RESERVED         0         00         00           184         B8         RESERVED         0         00         00           184         B4         C         0	170	AA	End of List /Record Format Version Number for 3.3Vsb output Record	130	82
172         AC         Record CHECKSUM of OEM Record Header (Zero CHECKSUM) (256-(sum of bytes 169to 172)         0         00         148         94           Image: CHECKSUM of OEM Record Header (Zero CHECKSUM) (256-(sum of bytes 169to 172)         0 <td< td=""><td>171</td><td>AB</td><td>Record Length of OEM Record</td><td>42</td><td>2A</td></td<>	171	AB	Record Length of OEM Record	42	2A
173         AD         Header CHECKSUM of OEN Record Header (Zero CHECKSUM) (264-(sum of bytes 199to 172)         148         94           OEM RECORD           174         AE         Manufacturer ID (3 bytes, Default is 0) RESERVED         0         00         00           176         AF         RESERVED         0         00         00           176         B0         RESERVED         0         00         00           177         B1         RESERVED         0         00         00           178         B2         RESERVED         0         00         00           180         B4         RESERVED         0         00         00         00           181         B5         RESERVED         0         00         00         00           182         B6         RESERVED         0         00         00         00           184         B8         RESERVED         0         00         00         00           184         B8         RESERVED         0         0         00         00           184         B8         RESERVED         0         0         00         00           185	172	AC	Record CHECKSUM of OEM Record (Zero CHECKSUM)	0	00
Image: Constraint of bytes (1980 172)         DEM RECORD           174         AE         Manufacturer ID (3 bytes, Default is 0)         0         00         00           175         B0         RESERVED         0         00         00           177         B1         RESERVED         0         00         00           177         B1         RESERVED         0         00         00           178         B2         RESERVED         0         00         00           178         B3         RESERVED         0         00         00           180         B4         RESERVED         0         00         00           181         B5         RESERVED         0         00         00           182         B4         RESERVED         0         00         00           184         B7         RESERVED         0         00         00           185         B8         RESERVED         0         00         00           188         BC         A1         (reserved), Default value is 0.         0         00         00           189         B0         C0         00         00         00 <td>173</td> <td>AD</td> <td>Header CHECKSUM of OEM Record Header (Zero CHECKSUM)</td> <td>148</td> <td>94</td>	173	AD	Header CHECKSUM of OEM Record Header (Zero CHECKSUM)	148	94
OEM RECORD         0         00           174         AE         Manufacturer ID (3 bytes, Default is 0)         0         00         00           176         B0         RESERVED         0         00         00           177         B1         RESERVED         0         00         00           178         B2         RESERVED         0         00         00           178         B2         RESERVED         0         00         00           178         B2         RESERVED         0         00         00           180         B4         RESERVED         0         00         00           181         B5         RESERVED         0         00         00           182         B6         RESERVED         0         00         00           184         B8         RESERVED         0         00         00           185         B5         RESERVED         0         00         00           188         B0         RESERVED         0         00         00           189         BC         0         0         00         00           191         BF			(256-(sum of bytes 169to 172)		
1/4       AL       Manufacturer ID (3 bytes, Default is 0)       0       00         175       AF       RESERVED       0       00         176       B0       RESERVED       0       00         177       B1       RESERVED       0       00         178       B2       RESERVED       0       00         179       B3       RESERVED       0       00         180       B4       RESERVED       0       00         181       B5       RESERVED       0       00         182       B6       RESERVED       0       00         183       B7       RESERVED       0       00         184       B8       RESERVED       0       00         185       B8       RESERVED       0       00         186       BA       RESERVED       0       00         188       B8       RESERVED       0       00       00         188       B8       RESERVED       0       00       00         189       B7       RESERVED       0       0       00         190       B2       A2       0       0       00			OEM RECORD	-	
176         Fr.         RESERVED         0         00           177         B1         RESERVED         0         00           178         B2         RESERVED         0         00           179         B3         RESERVED         0         00           180         B4         RESERVED         0         00           181         B5         RESERVED         0         00           182         B85ERVED         0         00         00           183         B7         RESERVED         0         00         00           184         B8         RESERVED         0         00         00           185         B9         RESERVED         0         00         00           186         BA         RESERVED         0         00         00           187         B8         PAD (reserved), Default value is 0.         0         00         00         00           188         BC         0         0         00         00         00         00           199         BF         5         0         0         00         00         00         00         00 <td< td=""><td>174</td><td>AE</td><td>Manutacturer ID (3 bytes, Default is 0)</td><td>0</td><td>00</td></td<>	174	AE	Manutacturer ID (3 bytes, Default is 0)	0	00
177       B1       RESERVED       0       00         178       B2       RESERVED       0       00         179       B3       RESERVED       0       00         180       B4       RESERVED       0       00         181       B5       RESERVED       0       00         181       B5       RESERVED       0       00         182       B6       RESERVED       0       00         183       B5       RESERVED       0       00         184       B8       RESERVED       0       00         186       BA       RESERVED       0       00         186       BA       RESERVED       0       00         187       B8       BC       0       00       00         188       BC       0       00       00       00         189       BD       0       0       00       00         190       BE       0       0       00       00         191       BF       0       0       00       00         192       C0       0       00       00       00	175			0	00
178         B2         RESERVED         0         00           179         B3         RESERVED         0         00           180         B4         RESERVED         0         00           181         B5         RESERVED         0         00           182         B6         RESERVED         0         00           183         B7         RESERVED         0         00           184         B8         RESERVED         0         00           186         B4         RESERVED         0         00           186         B9         RESERVED         0         00           187         B8         RESERVED         0         00           188         BC         0         00         00           189         BD         0         00         00           190         BE         0         0         00         00           191         BF         0         0         00         00           193         C1         0         0         00         00           194         C2         0         0         0         00      <	170	B1	RESERVED	0	00
179       B3       RESERVED       0       00         180       B4       RESERVED       0       00         181       B5       RESERVED       0       00         182       B6       RESERVED       0       00         183       B7       RESERVED       0       00         184       B8       RESERVED       0       00         186       B4       RESERVED       0       00         186       BA       RESERVED       0       00         188       BC       0       00       00         188       BC       0       00       00         189       BD       PAD (reserved), Default value is 0.       0       00         190       BE       0       00       00         191       BF       0       00       00         192       C0       0       00       00         194       C2       0       0       00         195       C3       0       00       00         196       C4       0       00       00         197       C5       0       0       00	178	B2	RESERVED	0	00
180         B4         RESERVED         0         00           181         B5         RESERVED         0         00           182         B6         RESERVED         0         00           183         B7         RESERVED         0         00           184         B8         RESERVED         0         00           185         B9         RESERVED         0         00           186         BA         RESERVED         0         00           187         B8         PAD (reserved), Default value is 0.         0         00           188         BC         0         00         00           189         BD         0         00         00           189         BC         0         00         00           190         BE         0         0         00           191         BF         0         0         00           192         C0         0         00         00           193         C1         0         0         00           194         C2         0         0         00           197         C5         0	179	B3	RESERVED	0	00
181         B5         RESERVED         0         00           182         B6         RESERVED         0         00           184         B7         RESERVED         0         00           184         B8         RESERVED         0         00           185         B9         RESERVED         0         00           186         BA         RESERVED         0         00           187         BB         PAD (reserved), Default value is 0.         0         00           188         BC         0         00         00           189         BD         0         00         00           189         BC         0         00         00           190         BF         0         0         00           191         BF         0         0         00           192         C0         0         00         00           194         C2         0         0         00           195         C3         0         00         00           196         C4         0         0         00           197         C5         0	180	B4	RESERVED	0	00
182         B6         RESERVED         0         00           183         B7         RESERVED         0         00           184         B8         RESERVED         0         00           185         B9         RESERVED         0         00           186         BA         RESERVED         0         00           187         B8         PAD (reserved), Default value is 0.         0         00           188         BC         0         00         00           189         BD         0         00         00           189         BD         0         00         00           190         BE         0         0         00           191         BF         0         0         00           192         C0         0         0         00           193         C1         0         00         00           194         C2         0         0         00           195         C3         0         0         00           196         C4         0         0         00           198         C6         0         0<	181	B5	RESERVED	0	00
183       B7       HESERVED       0       00         184       B8       RESERVED       0       00         185       B9       RESERVED       0       00         186       BA       RESERVED       0       00         187       B8       PAD (reserved), Default value is 0.       0       00       00         188       BC       0       00       00       00         189       B0       0       0       00       00         190       BE       0       0       00       00         191       BF       0       0       00       00         192       C0       0       0       00       00         193       C1       0       0       00       00         194       C2       0       0       00       00         195       C3       0       0       00       00         196       C4       0       0       00       00         199       C7       0       0       00       00         200       C8       0       0       00       00         204	182	B6	RESERVED	0	00
184         B6         RESERVED         0         00           185         B9         RESERVED         0         0           187         B8         PAD (reserved), Default value is 0.         0         00           188         BC         0         00         00           189         BD         0         00         00           189         B0         0         0         00           190         BE         0         0         00           191         BF         0         0         00           192         C0         0         0         00           192         C0         0         0         00           192         C0         0         0         0           193         C1         0         0         0         0           194         C2         0         0         0         0           195         C3         0         0         0         0           198         C6         0         0         0         0           201         C9         0         0         0         0           <	183	B7	RESERVED	0	00
183         D3         PLOSENVED         0         00         00           186         BA         RESSERVED         0         00         00           188         BC         0         00         00         00           188         BC         0         00         00         00           189         BD         0         00         00         00           189         BD         0         00         00         00           190         BE         0         0         00         00           191         BF         0         0         00         00           192         C0         0         0         00         00           193         C1         0         0         00         00           194         C2         0         0         00         00           195         C3         0         0         00         00           198         C6         0         0         00         00           201         C9         0         0         00         00           202         CA         0         0	184	B8 B0		0	00
100         DA         InductiveD         0         00           187         BB         PAD (reserved), Default value is 0.         0         00         00           189         BD         0         0         00         00           190         BE         0         0         00         00           191         BF         0         0         00         00           192         C0         0         0         00         00           193         C1         0         0         00         00           194         C2         0         0         00         00           195         C3         0         0         00         00           195         C3         0         0         00         00           196         C4         0         0         00         00           197         C5         0         0         00         00           200         C8         0         0         00         00           201         C9         0         0         00         00           202         CA         0         0	186	BA	RESERVED	0	00
167       DB       P AD (reserved), Default value is 0.       0       00       00         188       BC       0       00       00         190       BE       0       0       00         191       BF       0       0       00         192       C0       0       0       00         193       C1       0       0       00         194       C2       0       0       00         195       C3       0       0       00         196       C4       0       0       00         199       C7       0       0       00         200       C8       0       0       00         201       C9       0       00       00         202       CA       0       00       00         203       CB       0       00       00         204       CC       0       00       00         205       CD       0       00       00         204       CC       0       00       00         205       CD       0       00       00         206	100	DA DD	PAD (recerved) Default value is 0	0	00
180         BD         0         00           190         BE         0         00           191         BF         0         00           192         C0         0         00           193         C1         0         00           194         C2         0         0         00           195         C3         0         0         00           196         C4         0         0         00           197         C5         0         0         00           198         C6         0         0         00           199         C7         0         0         00           201         C9         0         0         00           202         CA         0         0         00           203         CB         0         0         00           204         CC         0         0         00           205         CD         0         0         00           205         CD         0         0         00           204         CC         0         0         00	188	BC	r AD (leselved), Delault value is 0.	0	00
190         BE         0         00           191         BF         0         00           192         C0         0         00           193         C1         0         00           194         C2         0         0         00           195         C3         0         00         00           196         C4         0         0         00           197         C5         0         0         00           198         C6         0         0         00           199         C7         0         0         00           200         C8         0         0         00           201         C9         0         0         00           203         CB         0         0         00           204         CC         0         0         00           205         CD         0         0         00           206         CE         0         0         00           208         D0         0         0         00           204         D2         0         0         0	189	BD		Ő	00
191       BF       0       00         192       C0       0       00         193       C1       0       00         194       C2       0       0       00         195       C3       0       0       00         196       C4       0       0       00         197       C5       0       0       00         198       C6       0       00       00         199       C7       0       0       00         200       C8       0       0       00         201       C9       0       0       00         202       CA       0       0       00         203       CB       0       0       00         204       CC       0       0       00         205       CD       0       0       00         206       CE       0       0       00         207       CF       0       0       00         208       D0       0       0       00         209       D1       0       0       00         211	190	BE		0	00
192       C0       0       00         193       C1       0       00         194       C2       0       00         195       C3       0       00         196       C4       0       00         197       C5       0       00         198       C6       0       00         199       C7       0       00         200       C8       0       00         201       C9       0       00         202       CA       0       00         203       CB       0       00         204       CC       0       00         205       CD       0       00         206       CE       0       00         207       CF       0       00         208       D0       0       00         209       D1       0       00         210       D2       0       00         211       D3       0       00         212       D4       0       00         213       D5       D7       0       00	191	BF		0	00
193       C1       0       00         194       C2       0       00         195       C3       0       00         196       C4       0       00         197       C5       0       00         198       C6       0       00         199       C7       0       00         200       C8       0       00         201       C9       0       00         202       CA       0       00         203       CB       0       00         204       CC       0       00         205       CD       0       00       00         206       CE       0       00       00         207       CF       0       00       00         208       D0       0       00       00         209       D1       0       00       00         210       D2       0       00       00         211       D3       0       0       00         213       D5       0       0       00         214       D7       0 <td< td=""><td>192</td><td>C0</td><td></td><td>0</td><td>00</td></td<>	192	C0		0	00
194       C2       0       00         195       C3       0       00         196       C4       0       00         197       C5       0       00         198       C6       0       00         199       C7       0       00         200       C8       0       00         201       C9       0       00         202       CA       0       00         203       CB       0       00         204       CC       0       00         205       CD       0       00         206       CE       0       00         207       CF       0       00         208       D0       0       00         209       D1       0       00         210       D2       0       00         211       D3       0       00         213       D5       07       00       00         214       D6       0       00       00         214       D6       0       00       00 <td>193</td> <td>C1</td> <td></td> <td>0</td> <td>00</td>	193	C1		0	00
195       C3       0       00         196       C4       0       00         197       C5       0       00         198       C6       0       00         199       C7       0       00         200       C8       0       00         201       C9       0       00         202       CA       0       00         203       CB       0       00         204       CC       0       00         205       CD       0       00         206       CE       0       00         207       CF       0       00         208       D0       0       00         209       D1       0       00         210       D2       0       0       00         211       D3       0       00       00         213       D5       07       00       00         214       D6       0       00       00         214       D6       0       00       00	194	C2		0	00
193       C4       0       00         197       C5       0       00         198       C6       0       00         199       C7       0       00         200       C8       0       0       00         201       C9       0       0       00         202       CA       0       0       00         203       CB       0       0       00         204       CC       0       0       00         205       CD       0       0       00         206       CE       0       0       00         207       CF       0       0       00         208       D0       0       0       00         209       D1       0       0       00         210       D2       0       0       00         211       D3       0       0       00         213       D5       0       0       00         214       D6       0       00       00	195	C3		0	00
107       00       00         198       C6       0       00         199       C7       0       00         200       C8       0       00         201       C9       0       00         202       CA       0       00         203       CB       0       00         204       CC       0       00         205       CD       0       00         206       CE       0       00         207       CF       0       00         208       D0       0       00         209       D1       0       00         210       D2       0       0       00         211       D3       0       00       00         211       D3       0       00       00         213       D5       07       0       00         214       D6       0       00       00         215       D7       0       0       00	197	C5		0	00
199       C7       0       00         200       C8       0       00         201       C9       0       0       00         202       CA       0       0       00         203       CB       0       0       00         204       CC       0       0       00         205       CD       0       0       00         206       CE       0       0       00         207       CF       0       0       00         208       D0       0       0       00         209       D1       0       0       00         210       D2       0       0       00         211       D3       0       0       00         213       D5       0       0       00         214       D6       0       0       00	198	C6		Ő	00
200       C8       0       00         201       C9       0       00         202       CA       0       00         203       CB       0       00         204       CC       0       00         205       CD       0       00         206       CE       0       00         207       CF       0       00         208       D0       0       00         209       D1       0       00         210       D2       0       00         211       D3       0       00         213       D5       0       00         214       D6       0       00	199	C7		0	00
201       C9       0       00         202       CA       0       00         203       CB       0       00         204       CC       0       00         205       CD       0       00         206       CE       0       00         207       CF       0       00         208       D0       0       00         209       D1       0       00         210       D2       0       00         211       D3       0       00         213       D5       0       00         214       D6       0       00	200	C8		0	00
202       CA       0       00         203       CB       0       00         204       CC       0       00         205       CD       0       00         206       CE       0       00         207       CF       0       00         208       D0       0       00         209       D1       0       00         210       D2       0       00         211       D3       0       00         213       D5       0       00         214       D6       0       00	201	C9		0	00
203       CB       0       00         204       CC       0       00         205       CD       0       00         206       CE       0       00         207       CF       0       00         208       D0       0       00         209       D1       0       00         210       D2       0       00         211       D3       0       00         213       D5       0       00         214       D6       0       00         215       D7       0       00	202	CA		0	00
204       00       00       00         205       CD       0       00         206       CE       0       00         207       CF       0       00         208       D0       0       00         209       D1       0       00         210       D2       0       00         211       D3       0       00         213       D5       0       00         214       D6       0       00         215       D7       0       00	203	CB		0	00
206       CE       0       00         207       CF       0       00         208       D0       0       00         209       D1       0       00         210       D2       0       00         211       D3       0       00         213       D5       0       00         214       D6       0       00         215       D7       0       00	204			0	00
207     CF     0     00       208     D0     0     00       209     D1     0     00       210     D2     0     00       211     D3     0     00       212     D4     0     00       213     D5     0     00       214     D6     0     00	205	CF		0	00
208       D0       0       00         209       D1       0       00         210       D2       0       00         211       D3       0       00         212       D4       0       00         213       D5       0       00         214       D6       0       00	207	CF		0	00
209       D1       0       00         210       D2       0       00         211       D3       0       00         212       D4       0       00         213       D5       0       00         214       D6       0       00         215       D7       0       00	208	D0		0	00
210       D2       0       00         211       D3       0       00         212       D4       0       00         213       D5       0       00         214       D6       0       00         215       D7       0       00	209	D1		0	00
211       D3       0       00         212       D4       0       00         213       D5       0       00         214       D6       0       00         215       D7       0       00	210	D2		0	00
212     D4     0     00       213     D5     0     00       214     D6     0     00       215     D7     0     00	211	D3		0	00
213     D3     0     00       214     D6     0     00       215     D7     0     00	212	D4		0	00
	213	05		0	00
	215	D7		0	00

![](_page_41_Picture_0.jpeg)

## DS1600SPE-3 FRU (EEPROM) Data:

(DEC)         (HEX)         (DEC)         (HEX)           INTERNAL USE AREA, 40 BYTES           216         D8         RESERVED, Default value is 0.         0         00           217         D9         0         00         0         00           218         DA         0         00         0         00         00           219         DB         0         0         00	OFFSET		DEFINITION	SPEC	VALUE
INTERNAL USE AREA, 40 BYTES           216         D8         RESERVED, Default value is 0.         0         00           217         D9         0         00         00           218         DA         0         00         00           219         DB         0         0         00         00           220         DC         0         0         00         00           221         DD         0         0         00         00           222         DE         0         0         00         00           224         DE         0         0         00         00           225         E1         0         0         00         00           226         E2         0         0         00         00           227         E3         0         0         00         00           230         E6         20         0         0         00         00           233         E9         0         0         0         0         00         00           236         EC         0         0         0         0         0	(DEC)	(HEX)	(REMARKS)	(DEC)	(HEX)
216         D8         RESERVED, Default value is 0.         0         00         00           217         D9         0         0         00         00         00           218         DA         0         0         00         00         00         00           219         DB         0         0         00			INTERNAL USE AREA, 40 BYTES	•	
217       D9       0       00       00         218       DA       0       00       00         220       DC       0       00       00         221       DD       0       00       00         222       DE       0       0       00         222       DE       0       0       00         222       DE       0       0       00         224       E0       0       0       00         225       E1       0       0       00         226       E2       0       0       00       00         228       E4       0       0       00       00         230       E6       0       0       00       00         231       E7       0       0       00       00         233       E9       0       0       00       00         234       EA       0       0       00       00         235       E8       0       0       00       00         236       EC       0       0       00       00      141       F1       0 <td>216</td> <td>D8</td> <td>RESERVED, Default value is 0.</td> <td>0</td> <td>00</td>	216	D8	RESERVED, Default value is 0.	0	00
218       DA       0       00         219       DB       0       00         220       DC       0       00         221       DD       0       00         222       DE       0       00         223       DF       0       00         224       E0       0       00         225       E1       0       00         226       E2       0       0       00         228       E4       0       0       00         229       E5       0       0       00         230       E6       0       0       00         231       E7       0       0       00         232       E8       0       0       00         231       E7       0       0       00         232       E8       0       0       00         233       E9       0       0       00         234       EA       0       0       00         233       E9       0       0       00         234       EA       0       0       00	217	D9		0	00
219       DB       0       00         220       DC       0       00         222       DE       0       00         223       DF       0       00         224       E0       0       00         225       E1       0       00         226       E2       0       0       00         227       E3       0       00       00         229       E5       0       0       00         231       E7       0       0       00         232       E8       0       0       00         233       E9       0       0       00         234       EA       0       0       00         235       E8       0       0       00         236       EC       0       0       00         237       ED       0       0       00         236       EC       0       0       00         237       ED       0       0       00         238       EF       0       0       00         241       F1       0       0	218	DA		0	00
220         DC         0         00         00           221         DD         0         00         00           222         DE         0         00         00           223         DF         0         00         00           224         E0         0         0         00           225         E1         0         0         00           226         E2         0         0         00           227         E3         0         0         00           229         E5         0         0         00           230         E6         0         0         00           231         E7         0         0         00           233         E9         0         0         00           234         EA         0         0         00           235         E8         0         0         00           236         E6         0         0         0           237         ED         0         0         0           238         EF         0         0         0           241	219	DB		0	00
221       DD       0       00       00         222       DF       0       0       00       00         224       E0       0       0       00       00         225       E1       0       0       00       00         226       E2       0       0       00       00         227       E3       0       0       00       00         230       E6       0       0       00       00         231       E7       0       0       00       00         233       E9       0       0       00       00         233       E9       0       0       00       00       00         234       EA       0       0       00       00       00       02       0       00	220	DC		0	00
222       DE       0       00         223       DF       0       00         224       E0       0       00         225       E1       0       00         226       E2       0       00         227       E3       0       00         228       E4       0       00         229       E5       0       00         230       E6       0       00         231       E7       0       00         232       E8       0       00         233       E9       0       00         234       EA       0       00         235       EB       0       00         236       EC       0       00         237       ED       0       00         238       EE       0       0       00         239       EF       0       0       00         241       F1       0       0       00         243       F3       0       0       00         244       F4       0       0       00         244	221	DD		0	00
223       DF       0       00         224       E0       0       00         225       E1       0       00         226       E2       0       00         227       E3       0       00         228       E4       0       00         229       E5       0       00         230       E6       0       00         231       E7       0       00         233       E9       0       00         234       EA       0       00         235       EB       0       00         236       EC       0       00       00         237       ED       0       00       00         238       EE       0       00       00         238       EE       0       00       00         240       F0       0       00       00         241       F1       0       0       00         242       F2       0       0       00         243       F3       0       0       00         244       F4       0	222	DE		0	00
224       E0       0       00         225       E1       0       00         226       E2       0       00         227       E3       0       00         228       E4       0       00         229       E5       0       00         230       E6       0       00         231       E7       0       00         232       E8       0       0       00         233       E9       0       0       00         234       EA       0       00       00         235       EB       0       0       00         236       EC       0       0       00         237       ED       0       0       00         238       EE       0       0       00         240       F0       0       0       00         241       F1       0       0       00         242       F2       0       0       00         243       F3       0       0       00         244       F4       0       0       0       00	223	DF		0	00
225       E1       0       00         226       E2       0       00         227       E3       0       00         228       E4       0       00         229       E5       0       0         230       E6       0       0       00         231       E7       0       0       00         232       E8       0       0       00         233       E9       0       0       00         234       EA       0       0       00         235       EB       0       0       00         236       EC       0       0       00         237       ED       0       0       00         238       EF       0       0       00         239       EF       0       0       00         241       F1       0       0       00         242       F2       0       0       00         243       F3       0       0       00         244       F4       0       0       00         245       F5       0	224	E0		0	00
226       E2       0       00         227       E3       0       00         228       E4       0       00         229       E5       0       00         230       E6       0       00         231       E7       0       00         232       E8       0       0         233       E9       0       00         234       EA       0       00         235       EB       0       0         236       EC       0       0         237       ED       0       0         238       EE       0       0         239       EF       0       0         230       EF       0       0         233       EF       0       0         234       FA       0       0         235       EB       0       0       0         238       EE       0       0       0         240       F0       0       0       0         241       F1       0       0       0         244       F4       0	225	E1		0	00
227       E3       0       00         228       E4       0       0       00         230       E6       0       0       00         231       E7       0       0       00         232       E8       0       0       00         231       E7       0       0       00         232       E8       0       0       00         233       E9       0       0       00         234       EA       0       0       00         235       EB       0       0       00         236       EC       0       0       00         237       ED       0       0       00         238       EF       0       0       00         239       EF       0       0       00         241       F1       0       0       00         242       F2       0       0       00         244       F4       0       0       00         244       F4       0       0       00         244       F4       0       0       0	226	E2		0	00
228       E4       0       00         229       E5       0       00         230       E6       0       00         231       E7       0       00         232       E8       0       00         233       E9       0       00         234       EA       0       00         235       EB       0       00         236       EC       0       00         237       ED       0       00         238       EF       0       00         239       EF       0       00         240       F0       0       00       00         241       F1       0       00       00         242       F2       0       0       00         243       F3       0       00       00         244       F4       0       0       00         245       F5       0       0       00         246       F6       0       00       00         247       F7       0       0       00         248       F8       0       0	227	E3		0	00
229       E5       0       00         230       E6       0       00         231       E7       0       00         232       E8       0       00         233       E9       0       0       00         234       EA       0       00       00         234       EA       0       00       00         235       EB       0       0       00         236       EC       0       0       00         237       ED       0       00       00         238       EE       0       0       00         240       F0       0       00       00         241       F1       0       0       00         242       F2       0       0       00         243       F3       0       0       00         244       F4       0       0       00         245       F5       0       0       00         246       F6       0       0       00         247       F7       0       0       00         250       FA	228	E4		0	00
230       E6       0       00         231       E7       0       00         232       E8       0       00         233       E9       0       00         234       EA       0       00         235       EB       0       00         236       EC       0       00         237       ED       0       00         238       EF       0       0         240       F0       0       00         241       F1       0       0         242       F2       0       0       00         243       F3       0       0       00         244       F4       0       0       00         245       F5       0       0       00         246       F6       0       0       00         249       F9       0       0       00         250       FA       0	229	E5		0	00
231       E7       0       00         232       E8       0       00         233       E9       0       00         234       EA       0       00         235       EB       0       00         236       EC       0       00         237       ED       0       00         238       EE       0       00         239       EF       0       00         240       F0       0       00         241       F1       0       00         242       F2       0       00         243       F3       0       00       00         244       F4       0       0       00         244       F4       0       0       00         244       F4       0       0       00         244       F6       0       0       00         244       F4       0       0       00         245       F5       0       0       00         246       F6       0       0       00         250       FA       0       0 <td>230</td> <td>E6</td> <td></td> <td>0</td> <td>00</td>	230	E6		0	00
232       E8       0       00         233       E9       0       00         234       EA       0       00         235       EB       0       00         236       EC       0       00         237       ED       0       00         238       EE       0       0       00         239       EF       0       0       00         241       F1       0       0       00         242       F2       0       0       00         243       F3       0       00       00         244       F4       0       0       00         244       F4       0       0       00         244       F4       0       0       00         245       F5       0       0       00         246       F6       0       0       00         247       F7       0       0       00         248       F8       0       0       00         250       FA       0       0       00         251       FB       0       0	231	E7		0	00
233       E9       0       00         234       EA       0       00         235       EB       0       00         236       EC       0       00         237       ED       0       00         238       EF       0       0       00         239       EF       0       0       00         240       F0       0       00       00         241       F1       0       00       00         243       F3       0       00       00         244       F4       0       0       00         245       F5       0       0       00         246       F6       0       0       00         248       F8       0       0       00         249       F9       0       0       00         250       FA       0       0       00         251       FB       0       0       00         252       FC       0       0       00         253       FD       0       0       00         254       FE       0	232	E8		0	00
234       EA       0       00         235       EB       0       00         236       EC       0       00         237       ED       0       00         238       EE       0       00         239       EF       0       0       00         241       F1       0       00       00         242       F2       0       0       00         243       F3       0       00       00         244       F4       0       0       00         245       F5       0       0       00         246       F6       0       0       00         247       F7       0       0       00         248       F8       0       0       00         250       FA       0       0       00         251       FB       0       0       00         252       FC       0       0       00         253       FD       0       0       0       0         254       FE       2       0       0       0	233	E9		0	00
235       EB       0       00         236       EC       0       00         237       ED       0       00         238       EE       0       0       00         239       EF       0       0       00         240       F0       0       0       00         241       F1       0       0       00         242       F2       0       0       00         243       F3       0       0       00         244       F4       0       0       00         245       F5       0       0       00         246       F6       0       0       00         248       F8       0       0       00         249       F9       0       0       00         250       FA       0       0       00         251       FB       0       0       00         252       FC       0       0       0         253       FD       0       0       0         254       FE       0       0       0	234	EA		0	00
236       EC       0       00         237       ED       0       00         238       EE       0       0         239       EF       0       0         240       F0       0       0         241       F1       0       0         242       F2       0       0         243       F3       0       0         244       F4       0       0         245       F5       0       0         246       F6       0       0         247       F7       0       0         248       F8       0       0         250       FA       0       0         250       FA       0       0         251       FB       0       0       0         252       FC       0       0       0         253       FD       0       0       0         254       FE       7       0       0       0         254       FE       7       0       0       0         254       FE       7       0       0       0	235	EB		0	00
237       ED       0       00         238       EE       0       00         239       EF       0       00         240       F0       0       00         241       F1       0       00         242       F2       0       0       00         243       F3       0       0       00         244       F4       0       0       00         245       F5       0       0       00         246       F6       0       0       00         247       F7       0       0       00         248       F8       0       0       00         249       F9       0       0       00         250       FA       0       0       0         251       FB       0       0       0       0         252       FC       0       0       0       0         253       FD       0       0       0       0         254       FE       7       7       7       0       0	236	EC		0	00
238       EE       0       00         239       EF       0       00         240       F0       0       00         241       F1       0       00         242       F2       0       0       00         243       F3       0       0       00         244       F4       0       0       00         245       F5       0       0       00         246       F6       0       0       00         247       F7       0       0       00         248       F8       0       0       00         249       F9       0       0       00         250       FA       0       0       00         251       FB       0       0       00         252       FC       0       0       00         253       FD       0       0       00         254       FE       0       0       00         254       FD       0       0       0	237	ED		0	00
239       EF       0       00         240       F0       0       00         241       F1       0       00         242       F2       0       0         243       F3       0       0         244       F4       0       0         245       F5       0       0         246       F6       0       0         247       F7       0       0         248       F8       0       0         249       F9       0       0         250       FA       0       0         251       FB       0       0       0         252       FC       0       0       0         253       FD       0       0       0         254       FE       0       0       0	238	EE		0	00
240       F0       0       00         241       F1       0       00         242       F2       0       00         243       F3       0       00         244       F4       0       00         245       F5       0       00         246       F6       0       00         247       F7       0       00         248       F8       0       00         249       F9       0       00         250       FA       0       00         251       FB       0       00         252       FC       0       00       00         253       FD       0       00       00         254       FE       0       00       00	239	EF		0	00
241       F1       0       00         242       F2       0       0         243       F3       0       0         244       F4       0       0         245       F5       0       0         246       F6       0       0         247       F7       0       0         248       F8       0       0         249       F9       0       0         250       FA       0       0         251       FB       0       0         252       FC       0       0         253       FD       0       0         254       FE       0       0	240	F0		0	00
242       F2       0       00         243       F3       0       00         244       F4       0       00         245       F5       0       0         246       F6       0       00         247       F7       0       00         248       F8       0       00         249       F9       0       00         250       FA       0       00         251       FB       0       00         252       FC       0       00         253       FD       0       00         254       FE       0       00	241	FI		0	00
243       F3       0       00         244       F4       0       00         245       F5       0       0         246       F6       0       0         247       F7       0       00         248       F8       0       00         249       F9       0       00         250       FA       0       00         251       FB       0       00         252       FC       0       00         253       FD       0       00         254       FE       0       00	242	F2		0	00
244       F4       0       00         245       F5       0       00         246       F6       0       0       00         247       F7       0       00       00         248       F8       0       0       00         249       F9       0       00       00         250       FA       0       00       00         251       FB       0       00       00         252       FC       0       00       00         253       FD       0       00       00         254       FE       0       00       00	243	F3		0	00
243       F5       0       00         246       F6       0       00         247       F7       0       00         248       F8       0       00         249       F9       0       00         250       FA       0       00         251       FB       0       00         252       FC       0       00         253       FD       0       00         254       FE       0       00	244	F4 E5		0	00
240       10       0       00         247       F7       0       00         248       F8       0       0       00         249       F9       0       0       00         250       FA       0       0       00         251       FB       0       00       00         252       FC       0       00       00         253       FD       0       00       00         254       FE       0       00       00	240	F3 E6		0	00
247       17       0       00         248       F8       0       00         249       F9       0       00         250       FA       0       00         251       FB       0       00         252       FC       0       00         253       FD       0       00         254       FE       0       00	240	F7		0	00
240         F0         0         00           249         F9         0         00           250         FA         0         00           251         FB         0         00           252         FC         0         00           253         FD         0         00           254         FE         0         00	247			0	00
250         FA         0         00           251         FB         0         00           252         FC         0         00           253         FD         0         00           254         FE         0         00	240	FQ		0	00
250         FR         0         00           251         FB         0         00           252         FC         0         00           253         FD         0         00           254         FE         0         00	243	ΕΔ		0	00
252         FC         0         00           253         FD         0         00           254         FE         0         00	250	FR		0	00
253         FD         0         00           254         FE         0         00	252	FC		0	00
254 FE 0 00	253	FD		0	00
	254	FE		0	00
255   FF   Zero CHECKSUM of Internal Use Area (if used). Default Value=0 0 00	255	FF	Zero CHECKSUM of Internal Use Area (if used). Default Value=0	0	00

![](_page_42_Picture_0.jpeg)

## DS1600SPE-3-001 FRU (EEPROM) Data:

OFFSET		DEFINITION	SPEC	SPEC VALUE		
(DEC)	(HEX)	(REMARKS)	(DEC)	(HEX)		
52	34	PRODUCT NAME BYTES (5 Byte sequence)	68	44		
53	35	"D"	83	53		
54	36	"S"	49	31		
55	37	"1"	54	36		
56	38	"6"	48	30		
57	39	"0"	48	30		
58	ЗA	"0"	83	53		
59	3B	"S"	80	50		
60	3C	"P"	69	45		
61	3D	"E"	45	2D		
62	3E	"D"	51	33		
63	3F	" <u>"</u>	45	2D		
64	40	"3"	48	30		
65	41	" <u>"</u>	48	30		
66	42	"0"	49	31		
		"0"				
		"1"				
67	43	PRODUCT PART/MODEL NUMBER Type/Length (CFH)	207	CF		
		Type = "ASCII+LATIN1" = (11)b Length = 15 Bytes = (001111)b				
68	44	PRODUCT PART/MODEL NUMBER BYTES	68	44		
69	45	"D"	83	53		
70	46	"S"	49	31		
71	47	"1"	54	36		
72	48	"6"	48	30		
73	49	"0"	48	30		
74	4A	"0"	83	53		
75	4B	"S"	80	50		
76	4C	"P"	69	45		
77	4D	"E"	45	2D		
78	4E	"D"	51	33		
79	4F	<i>"</i> "	45	2D		
80	50	"3"	48	30		
81	51	<u>""</u>	48	30		
82	52	"O"	49	31		
		"O"	1			
		"1"	ĺ			

![](_page_43_Picture_0.jpeg)

# PMBus<sup>™</sup> Interface Support

The DS1600SPE-3 is compliant with the industry standard PMBus<sup>™</sup> protocol for monitoring and control of the power supply via the I<sup>2</sup>C interface port.

## DS1600SPE-3 Series PMBus<sup>™</sup> General Instructions

#### **Equipment Setup**

The following is typical I<sup>2</sup>C communication setup:

![](_page_43_Figure_7.jpeg)

#### PMBus<sup>™</sup> Writing Instructions

When writing to any PMBus<sup>™</sup> R/W registers, ALWAYS do the following:

Disable Write Protect (command 10h) by writing any of the following accordingly:

Levels: 00h - Enable writing to all writeable commends

- 20h Disables write except 10h, 01h, 00h, 02h and 21h commands
- 40h Disables write except 10h, 01h, and 00h commends
- 80h Disable write except 0x00h

To save changes on the USER PMBus<sup>™</sup> Table:

Use send byte command: 15h STORE\_USER\_ALL

To save changes on the DEFAULT PMBus<sup>™</sup> Table:

Use send byte command: 11h STORE\_DEFAULT\_ALL

Wait for 5 seconds, turn-off the PSU, wait for another 5 seconds before turning it on.

Artesyn Embedded Technologies

![](_page_44_Picture_0.jpeg)

## DS1600SPE-3 Series Support PMBus<sup>™</sup> Command List

The DS1600SPE-3 is compliant with the industry standard PMBus<sup>TM</sup> protocol for monitoring and control of the power supply via the i<sup>2</sup>C interface port.

## DS1600SPE-3 Series Supported PMBus<sup>™</sup> Command List:

Command Code	Command Name	Default Value	Access Type	Data Bytes	Data Format	Description
00h	Page	00	R	1		
01h	OPERATION	80h	R/W	1		Used to Turn the unit ON/OFF in conjunction with the input CONTROL pin. It is also used to set output to upper or lower Margin Voltages.
	b7:6	10b				00 – Immediate Turn OFF (No Sequencing) 01 – Soft Turn OFF (With Sequencing) 10 – PSU ON
	b5:4	00b				
	b3:2	00b				
	b1:0	00b				Reserved
02h	ON_OFF_CONFIG	1C	R/W	1		Configures the combination of CONTROL pin and serial communication commands needed to turn the Unit ON/OFF.
	b7:5	000				Reserved
	b4 – Enable CONTROL pin and Serial communication control.	1				<ul> <li>0 – Unit powers up any time power is present regardless of the state of CONTROL pin.</li> <li>1 – Unit powers up as dictated by CONTROL pin and OPERATION command (b3:0)</li> </ul>
	b3 – Serial communication Control	1				0 – Unit Ignores ON/OFF portion of the OPERATION command.1 – Enables Serial communication ON/OFF portion of OPERATION command. Requires CONTROL pin to be asserted for the unit to start and energize the output.
	b2 – Sets how the unit responds to CONTROL pin	1				<ul> <li>0 – Unit ignores CONTROL pin. (ON/OFF controlled by OPERATION command).</li> <li>1 – Unit requires CONTROL pin to be asserted to start the unit.</li> </ul>
	b1 - CONTROL pin polarity	0				0 – Active Low (Pull Low to start the unit) 1 – Active high (Pull high to start the unit)
	b0 – CONTROL pin Action	0				0 – Use programmed turn ON/OFF delay 1 – Turn OFF the output and stop transferring energy to the output as fast as possible.
03h	CLEAR_FAULTS	FF	S			
10h	WRITE_PROTECT	00	R/W	1		Used to Control Writing to the PMBus Device 80h - Disables write except 10h 40h – Disables write except 10h, 01h, 00h 20h – Disables write except 10h,01h,00h,02h and 21h commands 00 – Enables write to all writeable commands.
15h	STORE_USER_ALL	-	S	0		Copies the Operating memory table to the matching USER non-volatile memory.
19h	CAPABILITY	90	R	1		Provides a way for the hosts system to determine some key capabilities of a PMBus device.
	b7 - Packet Error Checking	1				0 - PEC not supported 1 - PEC supported
	b6 - Maximum Bus Speed	0				0 - Maximum supported bus speed, 100khz 1 - Maximum supported bus speed, 400khz
	b5 - SMBALERT#	0				0 – SMBus Alert Pin <i>not supported</i> 1 – SMBus Alert Pin <i>supported</i>
	b4:0	00000				Reserved
20h	VOUT_MODE	17	R	1		Specifies the mode and parameters of Output Voltage related Data Formats

## DS1600SPE-3 Series Supported PMBus<sup>™</sup> Command List:

Command Code	Command Name	Default Value (HEX)	Access Type	Data Bytes	Data Format	
21h	VOUT_COMMAND	1800	R/W	2	Linear	Sets the Output Voltage Reference
						Vout command sends discreet value to change
						or trim output voltage. Valid range is 11.4 tp 12.6V.
24h	VOUT_MAX	1933	R	2	Linear	Read Only (12.6V)
30h	COEFFICIENTS	-	BR	6		use to retrieve the m, b and R coefficients, needed for DIRECT data format
	byte 1:2					mlow Byte, m high byte
	byte 3:4					b low Byte, b high byte
	byte 5					R byte
35h	VIN_ON	EAC0	R	2	Linear	Sets the value of input, in volts, at which the unit should start. ACGOOD 88Vac
36h	VIN_OFF	EA98	R	2	Linear	Sets the value of input, in volts, at which the
						unit should stop power conversion. ACBAD
0.01						83Vac
3An	FAN_CONFIG_1_2	90	К	1		Read only to reflect setting of Fans
	07	I				0 – No Fan is installed in position 1
	b6	0				1 – Fan is commanded in RPM
						0 – Fan is commanded in DC
	b5:4	01				00 – 1 pulse per revolution
						01 – 2 pulses per revolution
						10 – 3 pulses per revolution
	h2	0				1 – 4 pulses per revolution
	03	0				1 - Fait is installed in position 2
	h2	0				1 – Fan is commanded in BPM
		Ŭ				0 - Fan is commanded in DC
	b1:0	00				00 – 1 pulse per revolution
						01 – 2 pulses per revolution
						10 – 3 pulses per revolution
						11 – 4 pulses per revolution
3Bh	FAN_COMMAND_1	0000	R/W	2	Linear	Adjusts the operation of the Fans. The device
						may override the command, if it requires higher
						value, to maintain proper device temperature.
						RPM Control – Commands Speeds from 0-
						65535 RPM.
						Duty cycle Control – Commands Speeds from 0
101		1000	DAM			to 100%
40h	VOUI_OV_FAULI_LIMII	1C33	R/W	2	Linear	Sets Output Over voltage threshold. (14.1V)
41b	VOUT OV EAULT RESPONSE	80	D	1		Valid Range: 12.6 to 15.5 V
4111		80	п	I		CONTROL pin recycle or AC recycle.
42h	VOUT OV WARN LIMIT	1999	R/W	2	Linear	Sets Over-voltage Warning threshold. (12.8V)
43h	VOUT_UV_WARN_LIMIT	1666	R/W	2	Linear	Sets Under-voltage Warning threshold. (11.2V)
44h	VOUT_UV_FAULT_LIMIT	1599	R/W	2	Linear	Sets Under-voltage Fault threshold. (10.8V)
45h	VOUT_UV_FAULT_RESPONSE	80	R	1		Turn PSU OFF
46h	IOUT_OC_FAULT_LIMIT	F280	R	2	Linear	Sets the Over current threshold in Amps. (160A)
17h	IOUT OC FAULT DESDONSE	<u> </u>	P	1		Vallu halige: 150 to 166.7 A
4/11 4 <b>4</b> h	IOUT OC WARN LIMIT	E258	R	2	Linear	Sets the Over Current Warning threshold in
4711		1200	n	۷	Lineal	Amps. (150A) Valid Range: 150 to 166.7 A
4Fh	OT_FAULT_LIMIT	EBC0	R/W	2	Linear	Secondary ambient temperature Fault threshold,
						in degree C. (120degC), Valid Range: 51 to 125
						deg C
50h	OT_FAULT_RESPONSE	78	R	1		Turn PSU OFF and will retry indefinitely.
						Supported enable/disable of protection and
<b>E</b> 41		5000			1.5	recoverability.
510		ER98	К	2	Linear	becondary amplent temperature warning
						deaC) Valid Bange: 51 to 125 dea C
1		1	1		1	Lacy of valid hange. JI to 120 deg O

## DS1600SPE-3 Series Supported PMBus<sup>™</sup> Command List:

55h         VIN_OV_FAULT_LIMIT         FA28         R         2         Linear         Sets input over-roligative input overoligatingating ascourred ovelat -roligative input over-roligati	Command Code	Command Name	Default Value (HEX)	Access Type	Data Bytes	Data Format	
Ben         VIN, OV_FAULT_RESPONSE         F8         R         1         Default: 270 Vac           57n         VIN, OV_MAN, LIMIT         EABS         R         2         Linear Default: 270 Vac           59n         VIN, UV_FAULT_LIMIT         EABS         R         2         Linear Default: 87 Vac           59n         VIN, UV_FAULT_LIMIT         EABS         R         2         Linear Default: 87 Vac           58n         VIN, UV_FAULT_RESPONSE         F9         R         1         Linear Set the threshold by which the Power Good           58n         VIN, UV_FAULT_RESPONSE         F9         R         1         Linear Set the threshold by which the Power Good           58n         POWER_GOOD_OFF         1666         R         2         Linear         Set the threshold by which the Power Good           61n         TON_DELAY         EB20         R         2         Linear         Set the time (sec, Iron satt condition (Power Good)           64n         TOFF_DELAY         E280         R         2         Linear         Set the time (sec, Iron satt condition (Power Good)           64n         TOFF_DELAY         C200         R         2         Linear         Set the time (sec, Iron satt condition (Power Good)           64n         TOFF_DELAY <td>55h</td> <td>VIN_OV_FAULT_LIMIT</td> <td>FA26</td> <td>R</td> <td>2</td> <td>Linear</td> <td>Sets input over-voltage threshold. (275Vac) Valid Range: 264 to 300 Vac</td>	55h	VIN_OV_FAULT_LIMIT	FA26	R	2	Linear	Sets input over-voltage threshold. (275Vac) Valid Range: 264 to 300 Vac
5h         VIN_OV_WARN_LIMIT         ???         Default 20 Vac           5h         VIN_UV_WARN_LIMIT         EA88         R         2         Linear         Default 27 Vac           5h         VIN_UV_FAULT_LIMIT         EA88         R         2         Linear         Default 28 Vac           5h         VIN_UV_FAULT_LIMIT         EA88         R         2         Linear         Default 28 Vac           5h         VIN_UV_FAULT_LIMIT         EA88         R         2         Linear         Default 28 Vac           5h         VIN_UV_FAULT_RESPONSE         F8         R         1         Linear         Sate the threshold by which the Power Good Default 114 V           6h         POWER_GOOD_OFF         1666         R         2         Linear         Sate the threshold by which the Power Good Default 114 V           60h         TON_DELAY         EB20         R         2         Linear         Sate the threshold by which the office torse (.2); forn start condition (Power OF) Unit to output rises from 0 to regulation. Store (.2); forn start condition (Power OF) Default 20 Vac           61h         TON_DELAY         EB20         R         2         Linear         Sate the thres (IN); for the output rises from 0 to regulation. Store (.2); forn start condition (Power OF); Default 20 Vac           63h         TON_	56h	VIN_OV_FAULT_RESPONSE	F8	R	1		
58h         VIN_UV_WARN_LIMIT         EAB8         R         2         Linear         Default 8 Yus         Point 8 Yus           59h         VIN_UV_FAULT_LIMIT         EA88         R         2         Linear         Default 83 Yus         Yus           5Ah         VIN_UV_FAULT_RESPONSE         F8         R         1         VIN_UV_RAULT_RESPONSE         F8         R         1           55h         POWER_GOOD_ON         16CC         R         2         Linear         Sets the threshold by which the Power Good Default 11.4 v           56h         POWER_GOOD_OFF         1666         R         2         Linear         Sets the time (see), rom sist condition (Power COV) until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to Other visit to rise. (2.1 sec mat) ON until to Other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to other visit to rise. (2.1 sec mat) ON until to Other visit to rise. (2.1 sec mat) ON until to Other visit to rise. (2.1 sec mat) ON until to Other visit to rise. (2.1 sec mat) O	57h	VIN_OV_WARN_LIMIT	???				Default: 270 Vac Valid Bange: 264 to 300 Vac
S9h         VIN_UV_FAULT_LIMIT         EA96         R         2         Linear         Default: 35 ward         25 ward           SAh         VIN_UV_FAULT_RESPONSE         F8         R         1         Valid Rang: 70 to 90 Vac           Seh         POWER_GOOD_ON         16CC         R         2         Linear         Sets the threshold by which the Power Good Default: 11.4 V           SFh         POWER_GOOD_OFF         1666         R         2         Linear         Sets the threshold by which the Power Good Default: 11.2 V           60h         TON_DELAY         EB20         R         2         Linear         Sets the time (sec), from start condition (Power Good Default: 10.2 V           61h         TON_RISE         EB20         R         2         Linear         Sets the time (sec), from start condition (Power Good Default: 10.0 W           63h         TON_RISE         EB20         R         2         Linear         Sets the time (sec), from start condition (to sec), from start condition (to sec), from start condition (to sec), from start condition to to regulation (Som smat) Default: 20.8 V           64h         TOFF_DELAY         C200         R         2         Linear         Sets the time (sc), from a stop condition (to sec), from start condition (to sec), f	58h	VIN_UV_WARN_LIMIT	EAB8	R	2	Linear	Default: 87 Vac Valid Bang: 70 to 90 Vac
SAh         VIN_UV_FAULT_RESPONSE         F8         R         1         Calculation of the descent of the provided by which the Power Good Default: 11.4 V           5Fh         POWER_GOOD_OFF         1666         R         2         Linear         Sets the threshold by which the Power Good Default: 11.4 V           60h         TON_DELAY         EB20         R         2         Linear         Sets the threshold by which the Power Good Default: 11.2 V           60h         TON_DELAY         EB20         R         2         Linear         Sets the time (see), from start condition (Power ON) until the output starts to rise. (2.1 sec max) Default=100ms           61h         TON_RISE         E280         R         2         Linear         Sets the time (ms), form a stop condition (Power ON) until the output starts to drop (converter OFF). Default: 22.8 Stop the time (ms), form a stop condition (Power OFF).           64h         TOFF_DELAY         C200         R         2         Linear           55h         FOUT_OP_WARN_LIMIT         Default: 1360 V         Vaile Range: 10.4 V         Vaile Range: 10.4 V           78h         STATUS_BYTE         -         R         1         Returns the summary of critical faults           64. FOUT_OC         -         Output over-current taut has occurred         D4 - FOUT_OC         Output over-current taut has occurred	59h	VIN_UV_FAULT_LIMIT	EA98	R	2	Linear	Default: 83 Vac Valid Rang: 70 to 90 Vac
SEh         POWER_GOOD_ON         18CC         R         2         Linear         Sets the threshold by which the Power Good Default: 11.4 V           SFh         POWER_GOOD_OFF         1666         R         2         Linear         Sets the threshold by which the Power Good Default: 11.4 V           60h         TON_DELAY         EB20         R         2         Linear         Sets the threshold by which the Power Good Default: 11.4 V           60h         TON_DELAY         EB20         R         2         Linear         Sets the threshold by which the Power Good Default: 12.4 V           60h         TON_DELAY         EB20         R         2         Linear         Sets the time (sec), from starts to rise, (2: Issee max) Default-100ms           61h         TON_RISE         E280         R         2         Linear         Sets the time (ms), form e output rises from 0 to regulation. (Bors max) Default-22.5           6Ah         TONF_DELAY         C200         R         2         Linear         Sets the time (ms), from a stop condition (Power Good Default: 2.2 S           78h         STATUS_BYTE         -         R         1         Elstication (Comore of CFF). Default: 2.2 S           64n         TOFF_DELAY         -         R         1         Returns the socured           65A         POUT_O	5Ah	VIN UV FAULT RESPONSE	F8	R	1		
SFh         POWER_GOOD_OFF         1666         R         2         Linear         Sets the time (add by which the Power Good Default: 11.2 V Valid Range <= 11.4 V           60h         TON_DELAY         EB20         R         2         Linear         Sets the time (set), from start condition (Power Ob) until the output starts to rise. (2.1 sec max) Default=100ms           61h         TON_RISE         E280         R         2         Linear         Sets the time (ms), fort the output rises from 0 to regulation. (50ms max) Default=40ms           63h         TON_MAX_FAULT_RESPONSE         80         2         Linear         Sets the time (ms), fort a stop condition (Power OFF) until the output starts to drop (correver OFF) protectit 2.2 S           64h         TOFF_DELAY         C200         R         2         Linear         Sets the time (ms), fort a stop condition (Power OFF) until the output starts to drop (correver OFF) until the output starts to drop (correver OFF) protectit 2.2 S           64h         POUT_OP_WARN_LIMIT         Polarit 1600 to 1920 W         Valid Range: 10.25 S           65h         FT_BUSY         -         R         1         Net supported           65 - OFF         -         Unit is coverage fault has occurred         D         D           65 - VOUT OV         -         -         Output over-outpate fault ano courred         D <td< td=""><td>5Eh</td><td>POWER_GOOD_ON</td><td>16CC</td><td>R</td><td>2</td><td>Linear</td><td>Sets the threshold by which the Power Good Default: 11.4 V Valid Range: 11.4 to 12.6 V</td></td<>	5Eh	POWER_GOOD_ON	16CC	R	2	Linear	Sets the threshold by which the Power Good Default: 11.4 V Valid Range: 11.4 to 12.6 V
60h         TON_DELAY         EB20         R         2         Linear         Sets the time (seo), from start condition (Power DN) until the output starts to rise. (2.1 sec may) Default=100ms           61h         TON_RISE         E20         R         2         Linear         Sets the time (rms), for the output starts to rise. (2.1 sec may) Default=100ms           63h         TON_MAX_FAULT_RESPONSE         80         P         Linear         Sets the time (rms), for the output starts to drop (converter OFF). Default: 2.2 S           6Ah         POUT_OP_WARN_LIMIT         E         Default: 1600 W         Valid Range: 2 to 2.5 S           6Ah         POUT_OP_WARN_LIMIT         E         Default: 1600 W         Valid Range: 2 to 2.5 S           6Ah         POUT_OP_WARN_LIMIT         E         Not supported         Valid Range: 1600 W           78h         STATUS_BYTE         -         R         1         Not supported           62 - OFF         -         Unit is OFF         -         Output over-voltage fault has occurred           16 - OFF         -         -         Output over-voltage fault has occurred         -           16 - OFIC         -         Output over-voltage fault has occurred         -           16 - CML         -         Courder         -         -           1	5Fh	POWER_GOOD_OFF	1666	R	2	Linear	Sets the threshold by which the Power Good Default: 11.2 V Valid Range <= 11.4 V
61h         TON_RISE         E280         R         2         Linear         Sets the time (ms), for the output rises from 0 to regulation. (50m max) Default=40ms           63h         TON MAX_FAULT_RESPONSE         80         - <t< td=""><td>60h</td><td>TON_DELAY</td><td>EB20</td><td>R</td><td>2</td><td>Linear</td><td>Sets the time (sec), from start condition (Power ON) until the output starts to rise. (2.1sec max) Default=100ms</td></t<>	60h	TON_DELAY	EB20	R	2	Linear	Sets the time (sec), from start condition (Power ON) until the output starts to rise. (2.1sec max) Default=100ms
63h         TON MAX FAULT RESPONSE         80         Image         Sets the time (ms), from a stop condition (Power OFF) until the output starts to drop (converter OFF). Default: 2.2 S           64h         POUT_OP_WARN_LIMIT         Valid Range: 2 to 2.5 S         Valid Range: 2 to 2.5 S           6Ah         POUT_OP_WARN_LIMIT         Valid Range: 2 to 2.5 S         Valid Range: 2 to 2.5 S           6Ah         STATUS BYTE         -         R         1         Returns the summary of critical faults           b5 - VOUT_OV         -         Not supported         Unit is OFF         Unit is OFF           b6 - OFF         -         Unit is OFF         Output over-outrage fault has occurred           b3 - VIN_UV         -         An input under-voltage fault has occurred           b3 - VIN_UV         -         An input under-voltage fault has occurred           b1 - CML         -         A communication.           b1 - CML         -         A communication.           b1 - CML         -         A communication.           b1 - OUT/POUT         An input witage fault has occurred.           b1 - INPUT         An output voltage fault or warning has occurred.           b1 - INPUT         An output voltage fault or warning has occurred.           b13 - INPUT         An anuitaturer specific fault or warning has occurred. <td>61h</td> <td>TON_RISE</td> <td>E280</td> <td>R</td> <td>2</td> <td>Linear</td> <td>Sets the time (ms), for the output rises from 0 to regulation. (50ms max) Default=40ms</td>	61h	TON_RISE	E280	R	2	Linear	Sets the time (ms), for the output rises from 0 to regulation. (50ms max) Default=40ms
64h         TOFF_DELAY         C200         R         2         Linear         Sets the time (ms), from a stop condition (Power OFF) until the output stors to drop (converter OFF). Default: 22.S           6Ah         POUT_OP_WARN_LIMIT         Vaid Range: 2 to 25.S           6Ah         POUT_OP_WARN_LIMIT         Vaid Range: 2 to 25.S           6Ah         STATUS_BYTE         -         R           1         Returns the summary of critical faults         Vaid Range: 2 to 25.S           66 - OFF         -         Unit SOFF         -           65 - OVUT_OV         -         Output over-oventage fault has occurred           64 - IOUT_OC         -         Output over-oventage fault has occurred           64 - IOUT_OC         -         Output over-oventage fault has occurred           64 - IOUT_OC         -         Output over-oventage fault has occurred           64 - IOUT_OC         -         -         Output over-oventage fault has occurred           65 - VOUT_OC         -         -         -         Output over-oventage fault has occurred           61 - CML         -         -         -         -           60 - NONE OF THE ABOVE         -         -         -         -           79h         STATUS WORD         -         R         2	63h	TON_MAX_FAULT_RESPONSE	80				
6Ah         POUT_OP_WARN_LIMIT         Default: 1600 W           78h         STATUS_BYTE         -         R         1         Returns the summary of critical faults           67 - BUSY         -         Not supported         Not supported           66 - OFF         -         Unit is OFT           b5 - VOUT_OV         -         Output over-voltage fault has occurred           b4 - IOUT_OC         -         Output over-current fault has occurred           b3 - VIN_UV         -         A temperature fault or warning has occurred           b1 - CML         -         A temperature fault or warning has occurred           b1 - CML         -         A temperature fault or warning has occurred           b1 - CML         -         A communication, memory or logic fault has occurred           b1 - CML         -         A communication memory or logic fault has occurred           b1 - CML         -         A communication memory or logic fault has occurred           b1 - CML         -         A communication memory or logic fault has occurred           b1 - CML         -         A communication memory or logic fault has occurred           b1 - NOUT/POUT         -         A noutput voltage fault or warning has occurred           b13 - INPUT         An output voltage current or power fault or warning has occur	64h	TOFF_DELAY	C200	R	2	Linear	Sets the time (ms), from a stop condition (Power OFF) until the output starts to drop (converter OFF). Default: 2.2 S Valid Range: 2 to 2.5 S
78h       STATUS BYTE       -       R       1       Returns the summary of critical faults         b7 - BUSY       -       Not supported       Not supported         b6 - OFF       -       Unit is OFF         b4 - IOUT OC       -       Output over-current fault has occurred         b3 - VIN UV       -       An input undervoltage fault has occurred         b3 - VIN UV       -       A temperature fault or warning has occurred         b1 - CML       -       A communication, memory or logic fault has occurred         b1 - CML       -       A communication, memory or logic fault has occurred.         b0 - NONE OF THE ABOVE       -       R       2         b1 - CML       -       -       A communication, memory or logic fault has occurred.         b1 - CML       -       -       A communication, memory or logic fault has occurred.         b1 - CML       -       -       A communication, memory or logic fault has occurred.         b1 - CML       -       -       R       2         b1 - CML       -       -       R and warning has occurred.         b1 - IOUT/POUT       -       An output voltage fault or warning has occurred.         b13 - INPUT       -       An output voltage, current or power fault or warning has occurred.	6Ah	POUT_OP_WARN_LIMIT					Default: 1600 W Valid Rang: 1600 to 1920 W
b7-BUSY         -         Not supported           b6-OFF         -         Unit is OFF           b5-VOUT_OC         -         Output over-voltage fault has occurred           b4-IOUT_OC         -         Output over-ournent fault has occurred           b3-VIN_UV         -         An input under-voltage fault has occurred           b2-TEMPERATURE         -         A temperature fault or warning has occurred           b1-OML         -         A communication, memory or logic fault has occurred.           b0-NONE OF THE ABOVE         -         A fault Warning not listed in bits[7:1] has occurred.           b0-NONE OF THE ABOVE         -         R         2           b1-OUT/POUT         -         An output voltage fault or warning status.           b14-IOUT/POUT         -         An output voltage, current or power fault or warning has occurred.           b13-INPUT         -         An anufacturer specific fault or warning has occurred.           b10-FANS         -         A faunt valtage, current or power fault or warning has occurred.           b11-POWER_GOOD#         -         R fault ard warning status.           b10-FANS         -         A fault or warning has occurred.           b11-POWER_GOOD#         -         A fault or warning has occurred.           b12-MFR         -	78h	STATUS_BYTE	-	R	1		Returns the summary of critical faults
b6 - OFF         -         Unit is OFF           b5 - VOUT OV         -         Output over-ourged fault has occurred           b4 - IOUT_OC         -         Output over-ourged fault has occurred           b3 - VIN_UV         -         An input under-voltage fault has occurred           b2 - TEMPERATURE         -         An input under-voltage fault has occurred           b1 - CML         -         A communication, memory or logic fault has occurred.           b0 - NONE OF THE ABOVE         -         R 2         Summary of units Fault and warning status.           b0 - NONE OF THE ABOVE         -         R 2         Summary of units Fault and warning status.           b15 - VOUT         -         R 2         Summary of units Fault and warning has occurred.           b14 - IOUT/POUT         -         R 2         Summary of units Fault and warning has occurred.           b13 - INPUT         An output voltage, current or power fault or warning has occurred.         b11 - POWER_GOOD#           b11 - POWER_GOOD#         -         R 4         A manufacturer specific fault or warning has occurred.           b10 - FANS         -         A fault and rait or warning has occurred.         b10 - FANS           b10 - FANS         -         A fault and rait or warning has occurred.           b7 - BUSY         A fault or warning has occ		b7 – BUSY	-				Not supported
bb         - VOUT_OV         -         Output over-ourrent fault has occurred           b4 - IOUT_OC         -         Output over-ourrent fault has occurred           b3 - VIN_UV         -         An input under-voltage fault has occurred           b1 - CML         -         A temperature fault or warning has occurred           b1 - CML         -         A temperature fault or warning has occurred           b0 - NONE OF THE ABOVE         -         A fault Warning not listed in bits[7:1] has occurred.           row         -         R         2         Summary of units Fault and warning status.           b15 - VOUT         -         An output voltage fault or warning has occurred.         occurred.           b14 - IOUT/POUT         -         R         2         Summary of units Fault and warning status.           b13 - INPUT         An output voltage fault or warning has occurred.         occurred.         occurred.           b12 - MFR         -         An output voltage, current or power fault or warning has occurred.         occurred.           b11 - POWER_GOOD#         -         R         A fan or airflow fault or warning has occurred.           b11 - POWER_GOOD#         -         Not supported         b8 - UKNOWN           b8 - UKNOWN         -         Not supported         b8 - UKNOWN		b6 – OFF	-				Unit is OFF
b4 - IOUT_OC       -       Cutput over-current fault has occurred         b3 - VIN_UV       -       A temperature fault or warning has occurred         b1 - CML       -       A communication, memory or logic fault has occurred         b0 - NONE OF THE ABOVE       -       A Fault Warning not listed in bits[7:1] has occurred.         79h       STATUS WORD       -       R       2         b15 - VOUT       -       A noutput voltage fault or warning has occurred.         b14 - IOUT/POUT       An output voltage fault or warning has occurred.         b15 - VOUT       -       R       2         b15 - VOUT       -       An output current or power fault or warning has occurred.         b14 - IOUT/POUT       An output current or power fault or warning has occurred.         b13 - INPUT       An aningut voltage, current or power fault or warning has occurred.         b12 - MFR       -       A manufacturer specific fault or warning has occurred.         b11 - POWER_GOOD#       -       The POWER_GOOD isgnal is de-asserted         b10 - FANS       -       -       Not supported         b8 - UKNOWN       -       Not supported       -         b8 - OFF       -       -       Output over-outrent fault has occurred         b7 - BUSY       -       A temperature fault has		b5 – VOUT_OV	-				Output over-voltage fault has occurred
b3       - NR_UV       -       An input under-voltage fault has occurred         b2       - CML       -       A temperature fault or warning has occurred         b1       - CML       -       A communication, memory or logic fault has occurred.         b0       - NONE OF THE ABOVE       -       A Fault Warning not listed in bits[7:1] has occurred.         79h       STATUS_WORD       -       R       2       Summary of units Fault and warning has occurred.         b15       - VOUT       -       An output voltage fault or warning has occurred.       An output voltage, current or power fault or warning has occurred.         b13       - INPUT       -       An input voltage, current or power fault or warning has occurred.         b13       - INPUT       -       A manufacturer specific fault or warning has occurred.         b14       - IOUT/POUT       -       A manufacturer specific fault or warning has occurred.         b12       - MFR       -       -       -         ib1       - POWER_GOOD#       -       The POWER_GOOD signal is de-asserted         b10       - FANS       -       -       Not supported         b8<- OTHER		b4 – IOUT_OC	-				Output over-current fault has occurred
b2 - IEMPERATURE       -       A temperature fault or warning has occurred         b1 - CML       -       A communication, memory or logic fault has occurred.         b0 - NONE OF THE ABOVE       -       A Fault Warning not listed in bits[7:1] has occurred.         79h       STATUS WORD       -       R       2       Summary of units Fault and warning status.         155 - VOUT       An output voltage fault or warning has occurred.       An output voltage fault or warning has occurred.         b13 - INPUT       An nutput voltage, current or power fault or warning has occurred.       An input voltage, current or power fault or warning has occurred.         b12 - MFR       A manufacturer specific fault or warning has occurred.       An anufacturer specific fault or warning has occurred.         b11 - POWER_GOOD#       The POWER_GOOD signal is de-asserted       b10 - FANS         b11 - POWER_GOOD#       Not supported       Not supported         b7 - BUSY       A fault was declared because the device was busy and unable to respond.       De- OFF         b5 - VOUT_OV       Output over-voltage fault has occurred       Da - TEMPERATURE         b3 - INU_V       An input under-voltage fault has occurred       Da - TEMPERATURE         b0 - NONE_OF_THE_ABOVE       A temperature fault or warning has occurred       Dupt over-voltage fault has occurred         b1 - CML       C       A commu		b3 - VIN_UV	-				An input undervoltage fault has occurred
b1 - CML       -       A communication, memory or logic fault has occurred.         b0 - NONE OF THE ABOVE       -       A Fault Warning not listed in bits[7:1] has occurred.         79h       STATUS_WORD       -       R       2       Summary of units Fault and warning status.         b15 - VOUT       An output voltage fault or warning has occurred.       An output voltage fault or warning has occurred.         b13 - INPUT       An input voltage, current or power fault or warning has occurred.       A manufacturer specific fault or warning has occurred.         b12 - MFR       A manufacturer specific fault or warning has occurred.       A fan or airflow fault or warning has occurred.         b10 - FANS       A fan or airflow fault or warning has occurred.       A fan or airflow fault or warning has occurred.         b9 - OTHER       Not supported       Not supported         b7 - BUSY       A fault was declared because the device was busy and unable to respond.         b6 - OFF       Unit is OFF         b5 - VOUT_OV       Output over-outrage fault has occurred         b3 - VIN_UV       A temperature fault or warning has occurred         b4 - IOUT_OC       Output over-outrage fault has occurred         b5 - VOUT_OV       Output over-voltage fault has occurred         b7 - BUSY       A fault or warning has occurred         b4 - IOUT_OC       Output over-outrage f		62 - TEMPERATURE	-				A temperature fault or warning has occurred
B0 - NONE OF THE ABOVE     -     A Fault Warning not listed in bits[/:1] has occurred.       79h     STATUS_WORD     -     R     2     Summary of units Fault and warning status.       b15 - VOUT     An output voltage fault or warning has occurred     An output voltage fault or warning has occurred.       b13 - INPUT     An input voltage, current or power fault or warning has occurred.       b12 - MFR     A manufacturer specific fault or warning has occurred.       b11 - POWER_GOOD#     The POWER_GOOD signal is de-asserted       b10 - FANS     A fan or airflow fault or warning has occurred.       b9 - OTHER     Not supported       b8 - UKNOWN     Not supported       b6 - OFF     Unit is OFF       b5 - VOUT_OV     Output over-ourrent fault has occurred.       b4 - IOUT_OC     Unit is OFF       b3 - VIN_UV     An input under-voltage fault has occurred.       b7 - BUSY     Output over-ourrent fault has occurred.       b6 - OFF     Unit is OFF       b5 - VOUT_OV     Output over-voltage fault has occurred.       b4 - IOUT_OC     An input under-voltage fault has occurred.       b2 - TEMPERATURE     A communication, memory or logic fault has occurred.       b2 - CML     A communication, memory or logic fault has occurred.       b0 - NONE_OF_THE_ABOVE     A fault or warning not listed in bits[7:1] of this byet has occurred.			-				A communication, memory or logic fault has occurred.
Y9h       SIATUS_WORD       -       R       2       Summary of units Pault and warning status.         b15 - VOUT       An output voltage fault or warning has occurred       An output voltage fault or warning has occurred.         b13 - INPUT       An input voltage, current or power fault or warning has occurred.         b12 - MFR       A manufacturer specific fault or warning has occurred.         b11 - POWER_GOOD#       A manufacturer specific fault or warning has occurred.         b10 - FANS       A fan or airflow fault or warning has occurred.         b9 - OTHER       Not supported         b8 - UKNOWN       Not supported         b7 - BUSY       A fault or warning has occurred.         b6 - OFF       Unit is OFF         b5 - VOUT_OV       Output over-voltage fault has occurred.         b7 - BUSY       A fault or varning has occurred.         b7 - BUSY       A fault or varning has occurred.         b6 - OFF       Unit is OFF         b5 - VOUT_OV       Output over-voltage fault has occurred.         b7 - TEMPERATURE       A temperature fault has occurred.         b7 - NN_UV       A temperature fault has occurred.         b0 - NONE_OF_THE_ABOVE       A fault or warning not listed in bits[7:1] of this byte has occurred.		DO - NONE OF THE ABOVE	-				A Fault Warning not listed in bits[/:1] has occurred.
b15 - VOUT       An Output Voitage fault or warning has occurred         b14 - IOUT/POUT       An Output current or power fault or warning has occurred.         b13 - INPUT       An input voltage, current or power fault or warning has occurred.         b12 - MFR       A manufacturer specific fault or warning has occurred.         b11 - POWER_GOOD#       The POWER_GOOD signal is de-asserted         b10 - FANS       A fan or airflow fault or warning has occurred.         b9 - OTHER       Not supported         b8 - UKNOWN       Not supported         b7 - BUSY       A fault was declared because the device was busy and unable to respond.         b6 - OFF       Unit is OFF         b5 - VOUT_OV       Output over-outrage fault has occurred         b3 - VIN_UV       An input under-voltage fault has occurred         b4 - IOUT_OC       Output over-outrage fault has occurred         b5 - VOUT_OV       An input under-voltage fault has occurred         b4 - IOUT_OC       An input under-voltage fault has occurred         b5 - VIN_UV       An input and ervoltage fault has occurred         b1 - CML       A communication, memory or logic fault has occurred         b1 - CML       A fault or warning not listed in bits[7:1] of this byte has occurred.	79h	STATUS_WORD	-	R	2		Summary of units Fault and warning status.
b11 - ROST CONTROL       Intervention of porton reaction of porton reaction reac		b15 - VOUT b14 - IOUT/POUT					An output voltage fault or warning has occurred An Output current or power fault or warning has
b13 - INPUT       An input voltage, current or power fault or warning as occurred.         b12 - MFR       A manufacturer specific fault or warning has occurred.         b11 - POWER_GOOD#       The POWER_GOOD signal is de-asserted         b10 - FANS       A fan or airflow fault or warning has occurred.         b9 - OTHER       Not supported         b8 - UKNOWN       Not supported         b6 - OFF       Unit is OFF         b5 - VOUT_OV       Output over-voltage fault has occurred         b4 - IOUT_OC       Output over-current fault has occurred         b2 - TEMPERATURE       A temperature fault or warning has occurred         b1 - CML       A fault or warning not listed in bits[7:1] of this byte has occurred.							occurred.
b12 - MFR       A manufacturer specific fault or warning has occurred.         b11 - POWER_GOOD#       The POWER_GOOD signal is de-asserted         b10 - FANS       A fan or airflow fault or warning has occurred.         b9 - OTHER       Not supported         b8 - UKNOWN       Not supported         b7 - BUSY       A fault was declared because the device was busy and unable to respond.         b6 - OFF       Unit is OFF         b5 - VOUT_OV       Output over-voltage fault has occurred         b3 - VIN_UV       An input under-voltage fault has occurred         b3 - VIN_UV       An input under-voltage fault has occurred         b1 - CML       A communication, memory or logic fault has occurred         b1 - CML       A fault or warning not listed in bits[7:1] of this byte has occurred.		b13 – INPUT					An input voltage, current or power fault or warning as occurred.
b11 - POWER_GOOD#       The POWER_GOOD signal is de-asserted         b10 - FANS       A fan or airflow fault or warning has occurred.         b9 - OTHER       Not supported         b8 - UKNOWN       Not supported         b7 - BUSY       A fault was declared because the device was busy and unable to respond.         b6 - OFF       Unit is OFF         b5 - VOUT_OV       Output over-voltage fault has occurred         b3 - VIN_UV       An input under-voltage fault has occurred         b3 - VIN_UV       A temperature fault or warning has occurred         b1 - CML       A communication, memory or logic fault has occurred         b1 - CML       A fault or warning not listed in bits[7:1] of this byte has occurred.		b12 – MFR					A manufacturer specific fault or warning has occurred.
b10 - FANS       A fan or airflow fault or warning has occurred.         b9 - OTHER       Not supported         b8 - UKNOWN       Not supported         b7 - BUSY       A fault was declared because the device was busy and unable to respond.         b6 - OFF       Unit is OFF         b5 - VOUT_OV       Output over-voltage fault has occurred         b4 - IOUT_OC       Output over-current fault has occurred         b3 - VIN_UV       An input under-voltage fault has occurred         b2 - TEMPERATURE       A temperature fault or warning has occurred         b1 - CML       A communication, memory or logic fault has occurred.         b0 - NONE_OF_THE_ABOVE       A fault or warning not listed in bits[7:1] of this byte has occurred.		b11 – POWER_GOOD#					The POWER_GOOD signal is de-asserted
b9 - OTHER       Not supported         b8 - UKNOWN       Not supported         b7 - BUSY       A fault was declared because the device was busy and unable to respond.         b6 - OFF       Unit is OFF         b5 - VOUT_OV       Output over-voltage fault has occurred         b4 - IOUT_OC       Output over-current fault has occurred         b3 - VIN_UV       An input under-voltage fault has occurred         b2 - TEMPERATURE       A temperature fault or warning has occurred         b1 - CML       A communication, memory or logic fault has occurred.         b0 - NONE_OF_THE_ABOVE       A fault or warning not listed in bits[7:1] of this byte has occurred.		b10 - FANS					A fan or airflow fault or warning has occurred.
b8 – UKNOWN       Not supported         b7 – BUSY       A fault was declared because the device was busy and unable to respond.         b6 – OFF       Unit is OFF         b5 – VOUT_OV       Output over-voltage fault has occurred         b4 – IOUT_OC       Output over-current fault has occurred         b3 - VIN_UV       An input under-voltage fault has occurred         b2 – TEMPERATURE       A temperature fault or warning has occurred         b1 – CML       A communication, memory or logic fault has occurred.         b0 – NONE_OF_THE_ABOVE       A fault or warning not listed in bits[7:1] of this byte has occurred.		b9 – OTHER					Not supported
b7 - BUSY       A fault was declared because the device was busy and unable to respond.         b6 - OFF       Unit is OFF         b5 - VOUT_OV       Output over-voltage fault has occurred         b4 - IOUT_OC       Output over-current fault has occurred         b3 - VIN_UV       An input under-voltage fault has occurred         b2 - TEMPERATURE       A temperature fault or warning has occurred         b1 - CML       A communication, memory or logic fault has occurred.         b0 - NONE_OF_THE_ABOVE       A fault or warning not listed in bits[7:1] of this byte has occurred.		b8 – UKNOWN					Not supported
b6 - OFF       Unit is OFF         b5 - VOUT_OV       Output over-voltage fault has occurred         b4 - IOUT_OC       Output over-current fault has occurred         b3 - VIN_UV       An input under-voltage fault has occurred         b2 - TEMPERATURE       A temperature fault or warning has occurred         b1 - CML       A communication, memory or logic fault has occurred.         b0 - NONE_OF_THE_ABOVE       A fault or warning not listed in bits[7:1] of this byte has occurred.		b7 – BUSY					A fault was declared because the device was busy and unable to respond.
b5 - VOUT_OV       Output over-voltage fault has occurred         b4 - IOUT_OC       Output over-current fault has occurred         b3 - VIN_UV       An input under-voltage fault has occurred         b2 - TEMPERATURE       A temperature fault or warning has occurred         b1 - CML       A communication, memory or logic fault has occurred.         b0 - NONE_OF_THE_ABOVE       A fault or warning not listed in bits[7:1] of this byte has occurred.		b6 – OFF					Unit is OFF
b4 - IOUT_OC       Output over-current fault has occurred         b3 - VIN_UV       An input under-voltage fault has occurred         b2 - TEMPERATURE       A temperature fault or warning has occurred         b1 - CML       A communication, memory or logic fault has occurred.         b0 - NONE_OF_THE_ABOVE       A fault or warning not listed in bits[7:1] of this byte has occurred.		b5 – VOUT_OV					Output over-voltage fault has occurred
b3 - VIN_UV       An input under-voltage fault has occurred         b2 - TEMPERATURE       A temperature fault or warning has occurred         b1 - CML       A communication, memory or logic fault has occurred.         b0 - NONE_OF_THE_ABOVE       A fault or warning not listed in bits[7:1] of this byte has occurred.		b4 – IOUT_OC					Output over-current fault has occurred
b2 – TEMPERATURE       A temperature fault or warning has occurred         b1 – CML       A communication, memory or logic fault has occurred.         b0 – NONE_OF_THE_ABOVE       A fault or warning not listed in bits[7:1] of this byte has occurred.		b3 - VIN_UV		ļ		L	An input under-voltage fault has occurred
b1 - CML       A communication, memory or logic fault has occurred.         b0 - NONE_OF_THE_ABOVE       A fault or warning not listed in bits[7:1] of this byte has occurred.		b2 – TEMPERATURE		ļ		L	A temperature fault or warning has occurred
b0 - NONE_OF_THE_ABOVE A fault or warning not listed in bits[7:1] of this byte has occurred.		b1 – CML					A communication, memory or logic fault has occurred.
		b0 - NONE_OF_THE_ABOVE					A fault or warning not listed in bits[7:1] of this byte has occurred.

Artesyn Embedded Technologies

Rev.10.10.14\_#1.0 DS1600SPE-3 Series Page 48

DS1600SPE-3 Series Supported PMBus<sup>™</sup> Command List:

Command Code	Command Name	Default Value (HEX)	Access Type	Data Bytes	Data Format	
7Ah	STATUS_VOUT	-	R	1		Output voltage related faults and warnings
	b7					VOUT Over-voltage Fault
	b5					VOUT Under-voltage Warning
	b4					VOUT Under-voltage Fault
	b3					VOUT_MAX Warning, an attempt has been
						made to set output to a value higher that the
	b2					TON MAX FAULT
	b1					TOFF_MAX Warning. Not supported
	b0					Not supported.
7Bh		00	R	1		Output Current related faults and warnings
	b6					IOUT Over current And Low Voltage shutdown
						Fault
	b5					IOUT Overcurrent Warning
	b4					IOUT Undercurrent Fault
	b3					Current Share Fault
	b2					Power Limiting
	b1					POUT Overpower Fault
	b0					POUT Overpower Warning
7Ch	STATUS_INPUT	-	R	1		Input related faults and warnings
	b7					VIN Overvoltage Fault
	b6					VIN Overvoltage Warning
	b5					VIN Undervoltage Warning
	b4					VIN Undervoltage Fault
	b3					Unit is OFF for insufficient Input Voltage
	b2					IIN Overcurrent Fault
	b1					IIN Overcurrent Warning
	b0					PIN Overpower Warning
7Dh	STATUS_TEMPERATURE	-	R	1		Temperature related faults and warnings
	b7					Overtemperature Fault
	b6					Overtemperature Warning
	b5					Undertemperature Warning
	b4					Undertemperature Fault
	b3:0					Reserved
7Eh	STATUS_CML	-	R	1		Communications, Logic and Memory
	b7					Invalid or unsupported Command Received
	b6					Invalid Data
	b5					Packet Error Check Failed
	b4					Memory Fault Detect, CRC Error
	b3					Not Supported
	b2					Not Supported
	b1					Not Supported
	b0					Not Supported

Rev.10.10.14\_#1.0 DS1600SPE-3 Series Page 49

## DS1600SPE-3 Series Supported PMBus<sup>™</sup> Command List:

Command Code	Command Name	Default Value (HEX)	Access Type	Data Bytes	Data Format	
80h	STATUS_MFR_SPECIFIC	-	R	1		Manufacturer Status codes
	b7					Not Used
	b6					Not Used
	b5					Not Used
	b4					Not Used
	b3					Not Uesd
	b2					Not Uesd
	b1				1	Not Uesd
	b0				1	MFR SPECIFIC FAULT. FOR Trouble shooting
81h	STATUS FANS 1 2	00	R	1	1	
_	b7					Fan 1 Fault
	b6					Fan 2 Fault
	b5					Fan 1 Warning
	b4					Fan 2 Warning
	b3					Fan 1 Speed Overridden
	b2					Fan 2 Speed Overridden
	b1					Not Used
	b0					Not Used
86h	BEAD VIN	-	B	2	Linear	Beturns the accumulated input power over time
87h		-	B	2	Linear	Beturns the accumulated output power over over
0/11				-	Linear	time
88h	READ_VIN	-	R	2	Linear	Returns input Voltage in Volts ac.
89h	READ_IIN	-	R	2	Linear	Returns input Current in Amperes
8Ah	READ_VCAP	-	R	2	Linear	Returns Bulk Capacitor voltage in Volts
8Bh	READ_VOUT	-	R	2	Direct	Returns the actual, measured voltage in Volts.
8Ch	READ_IOUT	-	R	2	Linear	Returns the output current in amperes.
8Dh	READ_TEMPERATURE_1	-	R	2	Linear	PSU's inter hot spot temperature typically that
						of the main output rall heat sink. Format is
						Linear-11
8Eh	READ_TEMPERATURE_2	-	R	2	Linear	PSU's system-side air inlet or internal ambient
						temperature . Format is Linear-11.
8Fh	READ_TEMPERATURE_3	-	R	2	Linear	PSU's chassis-side air exhaust temperature.
						Format is Linear-11.
90h	READ_FAN_SPEED_1	-	R	2	Linear	Speed of Fan 1
96h	READ_POUT	-	R	2	Linear	Returns the output power, in Watts.
97h	READ_PIN	-	R	2	Linear	Returns the input power, in Watts.
98h	PMBUS_REVISION	22	R	1		Reads the PMBus revision number
	b7:5	0001				Part 1 Revision
						0000 – Revision 1.0
	b4:0	0001				Bort 2 Pavision
	54.0	0001				Part 2 Revision 1.0
00h		"ADTEQVNI"	BD	7		Abbrov or symbol of manufacturors name
3311		ANILOIN		1		
0Ab		"DO16000DE 2"	ASCII			ASUI (EMERSON) Manufacturara Madal number ASOII format
9A11		D310003FE-3				Manufacturers Model number, ASCII format
ODh		"^ ^ "	ASCII	0	1	Manufacturere regisien number ACOII formet
9BU	MFR_REVISION	AA	BR,	2		Manufacturers, revision number, ASCII format
001		"Obine"	ASCII			Manufacture facility ACOII format
9Ch	MFR_LOCATION	China	BR,			Manufacturers facility, ASCII format
		«\.A./\.A./!!	ASCII	0		Manufashara Dala AQQII (awas)
9Dh	MFR_Date	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	BR	6		Manufacture Date, ASCII format
055		"K000M/M00000	00	10		
9En	MFR_DATE	K369WW55555A	BR	13		Unit serial number, ASCII format.
Aob		AZ EADO	P	0	Lincor	Minimum Input Voltage (90V/20)
A16			n	2	Linear	Maximum Input Voltage (20VaC)
AIII				2	Linear	Movimum Input Current (10A)
A20		D280	К	2	Linear	Nevinum Input Current (10A)
AJ		-			Linear	
A4h	MFR_VOUT_MIN	16CC	R	2	Linear	Minimum Output Voltage
						Regulation Window. (11.4V)

## DS1600SPE-3 Series Supported PMBus<sup>™</sup> Command List:

Command Code	Command Name	Default Value (HEX)	Access Type	Data Bytes	Data Format	
A5h	MFR_VOUT_MAX	1933	R	2	Linear	Maximum Output Voltage.
						Regulation Window (12.6V)
A6h	MFR_IOUT_MAX	-	R	2	Linear	Maximum Output Current (133.3A)
A7h	MFR_POUT_MAX	-	R	2	Linear	Maximum Output Power (1600W)
A8h	MFR_TAMBIENT_MAX	E320	R	2	Linear	Maximum Operating Ambient Temperature
						(Secondary Ambient) (50 degC)
A9h	MFR_TAMBIENT_MIN	000A	R	2	Linear	Minimum Operating Ambient Temperature
						(Secondary Ambient) (0 degC)
AAh	MFR_EFFICIENCY_LL		R	14		Default: 115 V, 160 W, 89 %,
						400 W, 91.5%, 800 W, 89%
ABh	MFR_EFFICIENCY_HL		R	14		Default: 230 V, 320 W, 93 %,
						800 W, 94 %, 1600W, 92 %
B0h	USER_DATA_00		R/W			
E0h	FW_PRI_VERSION		R	8	ASCII	
E1h	FW_SEC_VERSION		R	8	ASCII	
F0	PMBUS_IMP_SPEC_REVISION	AC	R	2		
F1h	ISP_UNLOCK_CODE		R/W	4		
F2h	ISP_CTRL_CMD		R/W	1		
F3h	ISP_STATUS_BYTE		R	1		
F4h	ISP_FLASH_ADDR		R/W	4		
F5h	ISP_FLASH_DATA.		R/W	4		

![](_page_50_Picture_0.jpeg)

### **Current Sharing**

The DS1600SPE-3 series' main output  $V_0$  is equipped with current sharing capability. This will allow up to 6 power supplies to be connected in parallel for higher power application. Current share accuracy is typically 5% of full load. When supplying light loads between 10% and 100% of its rated load, the power supplies will share within 5% accuracy. Below 10% total loading, there is no guarantee of output current sharing.

DS1600SPE-3 Series

Page 51

The current sharing has been tested with a distribution impedance of about 200 micro-ohm.

![](_page_51_Picture_0.jpeg)

## **Redundancy / Fault Tolerance**

The DS1600SPE-3 series power supplies must be able to current share with 2(1+1) up to 4(2+2) or 6(3+3) power supplies in parallel and operate in a hot swap/redundant N+N configuration where N=1, 2, or 3. The 12Vsb outputs of the power supplies are connected together in the system so that a failure or hot swap of a redundant power supply does not cause these outputs to go out of regulation in the system.

All power supply outputs will be designed for redundant mode operation. No internal failure in any power supply in this configuration should cause the bus voltage to fall below the regulation limits specified. All output voltages should stay within the regulation limits during cold swapping or hot swapping operation.

![](_page_51_Figure_5.jpeg)

![](_page_52_Picture_0.jpeg)

## **Output Ripple and Noise Measurement**

The setup outlined in the diagram below has been used for output voltage ripple and noise measurements on the DS1600SPE-3 Series. When measuring output ripple and noise, a scope jack in parallel with a 0.1µF ceramic chip capacitor, and a 10 µF aluminum electrolytic capacitor should be used. Oscilloscope should be set to 20 MHz bandwidth for this measurement.

![](_page_52_Figure_4.jpeg)

## WORLDWIDE OFFICES

#### Americas

2900 S.Diablo Way Tempe, AZ 85282 USA +1 888 412 7832 Europe (UK) Waterfront Business Park Merry Hill, Dudley West Midlands, DY5 1LX United Kingdom

+44 (0) 1384 842 211

## Asia (HK)

14/F, Lu Plaza 2 Wing Yip Street Kwun Tong, Kowloon Hong Kong +852 2176 3333

![](_page_52_Picture_11.jpeg)

www.artesyn.com

For more information: www.artesyn.com/power For support: productsupport.ep@artesyn.com

While every precaution has been taken to ensure accuracy and completeness in this literature, Artesyn Embedded Technologies assumes no responsibility, and disclaims all liability for damages resulting from use of this information or for any errors or omissions. Artesyn Embedded Technologies, Artesyn and the Artesyn Embedded Technologies logo are trademarks and service marks of Artesyn Technologies, Inc. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. © 2014 All rights reserved.

![](_page_53_Picture_0.jpeg)

Компания «ЭлектроПласт» предлагает заключение долгосрочных отношений при поставках импортных электронных компонентов на взаимовыгодных условиях!

Наши преимущества:

- Оперативные поставки широкого спектра электронных компонентов отечественного и импортного производства напрямую от производителей и с крупнейших мировых складов;
- Поставка более 17-ти миллионов наименований электронных компонентов;
- Поставка сложных, дефицитных, либо снятых с производства позиций;
- Оперативные сроки поставки под заказ (от 5 рабочих дней);
- Экспресс доставка в любую точку России;
- Техническая поддержка проекта, помощь в подборе аналогов, поставка прототипов;
- Система менеджмента качества сертифицирована по Международному стандарту ISO 9001;
- Лицензия ФСБ на осуществление работ с использованием сведений, составляющих государственную тайну;
- Поставка специализированных компонентов (Xilinx, Altera, Analog Devices, Intersil, Interpoint, Microsemi, Aeroflex, Peregrine, Syfer, Eurofarad, Texas Instrument, Miteq, Cobham, E2V, MA-COM, Hittite, Mini-Circuits, General Dynamics и др.);

Помимо этого, одним из направлений компании «ЭлектроПласт» является направление «Источники питания». Мы предлагаем Вам помощь Конструкторского отдела:

- Подбор оптимального решения, техническое обоснование при выборе компонента;
- Подбор аналогов;
- Консультации по применению компонента;
- Поставка образцов и прототипов;
- Техническая поддержка проекта;
- Защита от снятия компонента с производства.

![](_page_53_Picture_19.jpeg)

#### Как с нами связаться

**Телефон:** 8 (812) 309 58 32 (многоканальный) **Факс:** 8 (812) 320-02-42 **Электронная почта:** <u>org@eplast1.ru</u> **Адрес:** 198099, г. Санкт-Петербург, ул. Калинина, дом 2, корпус 4, литера А.